California Proposition 65 Warning

WARNING: This product contains or emits chemicals known to the state of California to cause cancer and birth defects or other reproductive harm.

Event Data Recorders

This vehicle is equipped with an event data recorder (EDR).

The main purpose of an EDR is to record, in certain crash or near crash-like situations, such as an air bag deployment or hitting a road obstacle, data that will assist in understanding how a vehicle's systems performed. The EDR is designed to record data related to vehicle dynamics and safety systems for a short period of time, typically 30 seconds or less. The EDR in this vehicle is designed to record such data as:

- · How various systems in your vehicle were operating;
- Whether or not the driver and passenger safety belts were buckled/fastened:
- How far (if at all) the driver was depressing the accelerator and/or brake pedal; and,
- · How fast the vehicle was traveling.

These data can help provide a better understanding of the circumstances in which crashes and injuries occur. NOTE: EDR data are recorded by your vehicle only if a non-trivial crash situation occurs; no data are recorded by the EDR under normal driving conditions and no personal data (e.g., name, gender, age, and crash location) are recorded. However, other parties, such as law enforcement, could combine the EDR data with the type of personally identifying data routinely acquired during a crash investigation.

To read data recorded by an EDR, special equipment is required, and access to the vehicle or the EDR is needed. In addition to the vehicle manufacturer, other parties, such as law enforcement, that have the special equipment, can read the information if they have access to the vehicle or the EDR.

The data belongs to the vehicle owner and may not be accessed by anyone else except as legally required or with the permission of the vehicle owner.

Service Diagnostic Recorders

This vehicle is equipped with service-related devices that record information about powertrain performance. The data can be used to verify emissions law requirements and/or help technicians diagnose and solve service problems. It may also be combined with data from other sources for research purposes, but it remains confidential

California Perchlorate Contamination Prevention Act

The airbags, seat belt tensioners, and CR type batteries in this vehicle may contain perchlorate materials - special handling may apply. See www.dtsc.ca.gov/hazardouswaste/perchlorate/

As you read this manual, you will find information that is preceded by a NOTICE symbol. This information is intended to help you avoid damage to your vehicle, other property, or the environment.

A Few Words About Safety

Your safety, and the safety of others, is very important. And operating this vehicle safely is an important responsibility.

To help you make informed decisions about safety, we have provided operating procedures and other information on labels and in this manual. This information alerts you to potential hazards that could hurt you or others.

Of course, it is not practical or possible to warn you about all the hazards associated with operating or maintaining your vehicle. You must use your own good judgment.

You will find this important safety information in a variety of forms, including:

- Safety Labels on the vehicle.
- Safety Messages preceded by a safety alert symbol and one of three signal words: DANGER, WARNING, or CAUTION.
 These signal words mean:

ADANGER

You WILL be KILLED or SERIOUSLY HURT if you don't follow instructions.

AWARNING

You CAN be KILLED or SERIOUSLY HURT if you don't follow instructions.

ACAUTION

You CAN be HURT if you don't follow instructions.

- Safety Headings such as Important Safety Precautions.
- Safety Section such as Safe Driving.
- **Instructions** how to use this vehicle correctly and safely.

This entire book is filled with important safety information - please read it carefully.

This owner's manual should be considered a permanent part of the vehicle and should remain with the vehicle when it is sold

This owner's manual covers all models of your vehicle. You may find descriptions of equipment and features that are not on your particular model.

Images throughout this owner's manual (including the front cover) represent features and equipment that are available on some, but not all, models. Your particular model may not have some of these features

This owner's manual is for vehicles sold in the United States and Canada.

The information and specifications included in this publication were in effect at the time of approval for printing. Honda Motor Co., Ltd. reserves the right, however, to discontinue or change specifications or design at any time without notice and without incurring any obligation.

⇒ Safe Driving P. 31

For Safe Driving P. 32 Seat Belts P. 36

Instrument Panel P. 73

Indicators P. 74 Gauges and Displays P. 103

Controls P. 121

Clock P. 122 Locking and Unlocking the Doors P. 124

Opening and Closing the Moonroof* P. 150

Adjusting the Seats P. 167 Climate Control System* P. 190

→ Features P. 197

Audio System P. 198 Audio System Basic Operation P. 205, 223

Customized Features P. 302 Bluetooth® HandsFreeLink®* P. 333, 356

Airbags P. 44

Driving P. 389

Before Driving P. 390 Towing a Trailer P. 395
Multi-View Rear Camera P. 468 Refueling P. 470

► Maintenance P 475

Before Performing Maintenance P. 476 Maintenance Minder™ P. 479

Checking and Maintaining Wiper Blades P. 513

Heating System*/Climate Control System* Maintenance P. 529

Handling the Unexpected P. 535

Tools P. 536 If a Tire Goes Flat P. 537

Overheating P. 550 Indicator, Coming On/Blinking P. 552

When You Cannot Open the Trunk P. 564 Refueling P. 565

→ Information P. 567

Specifications P. 568 Identification Numbers P. 572
Emissions Testing P. 575 Warranty Coverages P. 577

				h.	Quick F
Child Safety P. 58	Exhaust Gas Hazard P. 70		Safety Labels P. 71		
				(h	
				h. 'th	l I
Opening and Closing the Trunk P. 141 Operating the Switches Around the Steeri Interior Lights/Interior Convenience Items	_		Opening and Closing the Windows P. 147 Adjusting the Mirrors P. 165 Heating System* P. 187		
				llis.	
Avalia Faran Masasana D. 202	C - f + i + i	A	D 200		
Audio Error Messages P. 293	General Information on the	Audio System	P. 296	444	
When Driving P. 396	Braking P. 451		Parking Your Vehicle P. 467		
Fuel Economy P. 473	Accessories and Modificatio	ons P. 474			
Maintenance Under the Hood P. 489	Replacing Light Bulbs P. 504	4			
Checking and Maintaining Tires P. 516	Battery P. 525		Remote Transmitter Care P. 527		
Cleaning P. 530				[]	Handling
Engine Does Not Start P. 543	Jump Starting P. 546		Shift Lever Does Not Move P. 549	- 4	
Fuses P. 558 Emergency To	owing P. 562	When You Ca	annot Unlock the Fuel Fill Door P. 563	(1)	
				- بال	
				J ^{I)''}	
Devices that Emit Radio Waves P. 573	Reporting Safety Defects P.	574			
Authorized Manuals P. 579	Customer Service Information	on P. 580			

Contents

ick Reference Guide P. 4

Safe Driving P. 31

Instrument Panel P. 73

Controls P. 121

Driving P. 389

Features P. 197


Maintenance P. 475

dling the Unexpected P. 535


Information P. 567

Index P. 581


Visual Index




^{*1:} Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.




Visual Index





Visual Index



Eco Assist System CR410

Ambient Meter -

 Changes color to reflect your driving style.

Green: Fuel efficient driving

White green: Moderate acceleration/


deceleration

White: Aggressive acceleration/

deceleration

 The ambient meter color changes in accordance with your brake or accelerator pedal operation.






Safe Driving

Airbags Airbags

 Your vehicle is fitted with airbags to help protect you and your passengers during a moderate-to-severe collision.

Child Safety CR. 58

- All children 12 and younger should be seated in the rear seat.
- Smaller children should be properly restrained in a forward-facing child seat.
- Infants must be properly restrained in a rear-facing child seat.



-Exhaust Gas Hazard

 Your vehicle emits dangerous exhaust gases that contain carbon monoxide. Do not run the engine in confined spaces where carbon monoxide gas can accumulate.

Seat Belts CARBO

- Fasten your seat belt and sit upright well back in the seat.
- Check that your passengers are wearing their seat belts correctly.

Before Driving Checklist P. 35

 Before driving, check that the front seats, head restraints, steering wheel, and mirrors have been properly adjusted.




Fasten your lap belt as low as possible.

Instrument Panel

Gauges (No. 103) / Information Display* (No. 104) / Driver Information Interface* (No. 104) / System Indicators (No. 104) / Sy

Models with information display

System Indicators
















BRAKE HOLD System Indicator

HOLD U.S. Automatic Brake Hold

(A) Indicator

BRAKE Parking Brake and U.S. Brake System (Indicator (Red)

BRAKE SYSTEM Parking Brake and U.S. Brake System

Indicator (Amber)


Shift Lever Position Indicator*

Immobilizer System Indicator/
Security System Alarm Indicator

Tachometer

Temperature Gauge Speedometer Fuel Gauge

System Indicators



Low Tire Pressure/ TPMS Indicator*

Lights Indicators

≥00€ Lights On Indicator



High Beam Indicator

System Indicators



Turn Signal and Hazard Warning Indicators



Electric Power Steering (EPS) System Indicator



Low Fuel Indicator



Seat Belt Reminder Indicator



Supplemental Restraint System Indicator



CRUISE MAIN Indicator*



CRUISE CONTROL Indicator*



Continuously variable transmission models

Brake Depressing Indicator



Manual transmission models

Brake Depressing Indicator



Maintenance Minder Indicator



Washer Level Indicator*

System Indicators

Malfunction Indicator Lamp



Low Oil Pressure Indicator



Charging System Indicator



Anti-lock Brake System (ABS) Indicator

Vehicle Stability Assist



(VSA®) System Indicator



VSA® OFF Indicator



Automatic Brake Hold **System Indicator**



Automatic Brake Hold Indicator




ECON Mode Indicator

(I) Canada

BRAKE Parking Brake and **Brake System** Indicator (Red)

BRAKE SYSTEM Parking Brake and **Brake System** Indicator (Amber) Canada



System Indicators



System Message Indicator



Low Tire Pressure/ TPMS Indicator*

Lights Indicators

-00=

Lights On Indicator



High Beam Indicator



Fog Light Indicator*

System Indicators



Turn Signal and Hazard Warning Indicators



Electric Power Steering (EPS) System Indicator



Low Fuel Indicator



Seat Belt Reminder Indicator



Supplemental Restraint System Indicator

Adaptive Cruise Control (ACC) with



Low Speed Follow (LSF) Indicator (Amber/Green)*



Road Departure Mitigation (RDM) Indicator*



Collision Mitigation Braking System™ (CMBS™) Indicator*

Lane Keeping Assist System (LKAS)

LKAS

Indicator (Amber/ Green)*

Controls CRIED

Clock CTRIP2

Models with color audio system



- Press and hold the MENU/CLOCK button.
- **2** Rotate ♂ to change hour, then press ⊗.
- **3** Rotate [♠] to change minute, then press [♠].
- 4 Select SET, then press ♂.

These indications are used to show how to operate the LIST/SELECT (List/Selector) knob.

- Rotate 🗇 to select.

Models with Display Audio

The audio system receives signals from GPS satellites, updating the clock automatically.



- Select the (HOME) icon, then select Settings.
- 2 Select Clock, then Clock Adjustment.
- 3 Touch the respective ▲ / ▼ icon to adjust the hours or minutes up or down.
- 4 Select OK.

ENGINE START/STOP Button*

 Press the button to change the vehicle's power mode.



Turn Signals P. 156

Turn Signal Control Lever



Lights P. 156

Light Control Switches



Wipers and Washers

→P. 160

Wiper/Washer Control Lever


Adjustment Ring*

: Low sensitivity*1

: Lower speed, fewer sweeps*2

+: High sensitivity*1

+: Higher speed, moer sweeps*2



MIST OFF

AUTO*1: Wiper speed varies automatically

 \mathbf{INT}^{\star_2} : Low speed with intermittent

LO: Low speed wipe **HI**: High speed wipe

- *1:Models with automatic intermittent wipers
- *2:Models without automatic intermittent wipers

Steering Wheel R 164

 To adjust, pull the adjustment lever towards you, adjust to the desired position, then lock the lever back in place.



Unlocking the Front Doors from the Inside

○P. 134

 Pull either front door inner handle to unlock and open it at the same time.



Trunk CRIM



Trunk Release Button


- To unlock and open the trunk:
- Press the trunk release button on the driver's door.
- Press the trunk release button on the remote transmitter or the smart entry remote.
- Press the trunk release button* on the trunk lid.

Power Door Mirrors

→P. 166

- With the ignition switch in ON II *1, move the selector switch to L or R.
- Push the appropriate edge of the adjustment switch to adjust the mirror.

Selector Switch




Adjustment Switch -

Power Windows CR 147

- With the ignition switch in ON II, open and close the power windows.
- If the power window lock button is in the off position, each passenger's window can be opened and closed with its own switch.
- If the power window lock button is in the on position (indicator is on), each passenger's window switch is disabled.

Indicator




Power Window Lock Button

*1:Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

Heating System* ← P. 187

- Press the **AUTO** button to activate the heating system.
- Press the SOFF button to turn the system on or off.
- Press the button to defrost the windshield.

Canadian models with color audio system




Air flows from floor vents.
Air flows from floor and dashboard vents.
Air flows from dashboard

vents.


Climate Control System* →P.190

- Press the **AUTO** button to activate the climate control system.
- Press the SOFF button to turn the system on or off.
- Press the button to defrost the windshield.


U.S. models with color audio system












Features CRIPA

Audio Remote Controls

◯ P. 201

Models with information display




- + / Button
 Press to adjust the volume up/down.
- SOURCE Button
 Press to change the audio mode: FM/AM/
 USB/iPod/Bluetooth® Audio.
- A) / Button
 Radio: Press to change the preset station.

 Press and hold to select the next or previous strong station.

USB device:

Press to skip to the beginning of the next song or return to the beginning of the current song. Press and hold to change a folder.

Models with driver information interface



● 🕂 / 🖃 Bar

Audio Apps*

Press to adjust the volume up/down. Sliding up or down also increases or decreases the volume.

Swipe down quickly to mute the volume and swipe up to cancel the mute.

▲ / ▼ Button
 Press ▲ or ▼ to cycle through the audio mode as follows:

 FM→AM→SiriusXM®*→USB→iPod→
 Bluetooth® Audio→Pandora®*→Apps*→

- When listening to the radio and SiriusXM®*
- Press ENTER to switch the display to a preset list you stored in the preset
- Press ▲ or ▼ to select a preset, then press ENTER.
- When listening to a USB flash drive
- 1 Press **ENTER** to display the folder list.
- 2 Press ▲ or ▼ to select a folder.
- Press **ENTER** to display a list of tracks in that folder.
- Press ▲ or ▼ to select a track, then press ENTER.

You can also swipe up or down to scroll through the list of tracks alphabetically.

- When listening to an iPod
- Press **ENTER** to display the iPod music list.
- Press ▲ or ▼ to select a category.
- Press **ENTER** to display a list of items in the category.
- Press ▲ or ▼ to select an item, then press ENTER.
 - ▶ Press ENTER and press or repeatedly until a desired item you want to listen is displayed.

You can also swipe up or down to scroll through the list of tracks alphabetically.

- When listening to Internet Radio*
- 1 Press ENTER to display the station list.
- Press ▲ or ▼ to select an item, then press ENTER.
- When listening to Bluetooth® Audio
- 1 Press ENTER to display the track list.
- Press ▲ or ▼ to select a track, then press ENTER.

● / ▶ Button

Radio: Press to change the preset station.

Press and hold to select the next or
previous strong station.


USB device:

Press to skip to the beginning of the next song or return to the beginning of the current song. Press and hold to change a folder.

B Button:


Press to change contents: Trip Computer/Turbo Booster Meter*/ Compass/Engine Oil Life/ Customize*/Audio*/Phone*/Change Units/Warning Messages.

Audio system R 198





For navigation system operation See the Navigation System Manual



Driving CTESSO

Manual Transmission* ← 407 Continuously Variable Transmission* ← 405

• Shift to P and depress the brake pedal when starting the engine.

Shifting



Park

Turn off or start the engine.
Transmission is locked.



Reverse

 $\mathbf{\Lambda} \mid$ Used when reversing.



Neutral

Transmission is not locked.



Drive

Normal driving.



Drive (S)


- Better acceleration.
- Increased engine braking.
- Going up or down hills.



Low

- Further increased engine braking.
- Going up or down hills.







Depress the brake pedal and press the release button to move out of P.



Press the release button to move the shift lever.



Move the shift lever without pressing the release button.

VSA® OFF Button CR 442

- The vehicle stability assist (VSA®) system helps stabilize the vehicle during cornering, and helps maintain traction while accelerating on loose or slippery road surfaces.
- VSA® comes on automatically every time you start the engine.
- To partially disable or fully restore VSA® function, press and hold the button until you hear a beep.

Cruise Control*

- Cruise control allows you to maintain a set speed without keeping your foot on the accelerator pedal.
- To use cruise control, press the **CRUISE** button, then press the -/SET button once you have achieved the desired speed (above 25 mph or 40 km/h).

Collision Mitigation Braking System™ (CMBS™) OFF Button*

- When a possible collision is likely unavoidable, the CMBS™ can help you to reduce the vehicle speed and the severity of the collision.

 ■ To turn the CMBSTM on or off, press and
- hold the button until you hear a beep.

U.S. models

Tire Pressure Monitoring System (TPMS) P. 446


- Detects a change in tire conditions and overall dimensions due to decrease in tire pressures.
- The TPMS is turned on automatically every time you start the engine.
- A calibration procedure must be performed when certain conditions arise.

Refueling (

Fuel recommendation: Unleaded gasoline with a pump octane number 87 or higher required

Fuel tank capacity: 12.39 US gal (46.9 L)

- Press on the edge of the fuel fill door to make it pop up sliahtly.
- After refueling, wait for about five seconds before removing the filler nozzle.



Maintenance CREATE

Under the Hood →P. 489


- Check engine oil, engine coolant, and windshield washer fluid. Add when necessary.
- Check brake fluid.
- Check the battery condition monthly.
- Pull the hood release handle under the corner of the dashboard.



2 Locate the hood latch lever, push the lever in the center to the right, and lift up the hood.



When finished, close the hood and make sure it is firmly locked in place.



- Check tire pressures regularly.
- Install snow tires for winter driving.

Handling the Unexpected CRESS

Flat Tire CREST

 Park in a safe location and replace the flat tire with the compact spare tire in the trunk.



Engine Won't Start

→P. 543

• If the battery is dead, jump start using a booster battery.



Indicators Come On


→P. 552

• Identify the indicator and consult the owner's manual.



Blown Fuse C>P. 558

 Check for a blown fuse if an electrical device does not operate.



Overheating P. 550

 Park in a safe location. If you do not see steam under the hood, open the hood, and let the engine cool down.



Emergency Towing

→P. 562

 Call a professional towing service if you need to tow your vehicle.



What to Do If



Models with smart entry system

The power mode does not change from VEHICLE OFF (LOCK) to ACCESSORY. Why?



The steering wheel may be locked.


Models without smart entry system

 Try to turn the steering wheel left and right while turning the ignition key.



Models with smart entry system*1

 Move the steering wheel left and right after pressing the ENGINE START/STOP button.




Models with smart entry system

The power mode does not change from ACCESSORY to VEHICLE OFF (LOCK). Why?



The shift lever should be moved to P.









This can occur when the ABS activates, and does not indicate a problem. Apply firm, steady pressure on the brake pedal. Never pump the brake pedal.

^{*1:}Except U.S. models with continuously variable transmission






Check if the childproof lock is in the lock position. If so, open the rear door with the outside door handle. To cancel this function, push the lever to the unlock position.



Why do the doors lock after I unlocked the doors using a remote transmitter?



If you do not open the doors within 30 seconds, the doors are relocked automatically for security.






The beeper sounds when:

- The key is left in the ignition switch*.
- The power mode* is in ACCESSORY.
- The exterior lights are left on.

Why does the beeper sound when I start driving?




The beeper sounds when the driver and/or front passenger are not wearing their seat belts.






The brake pads may need to be replaced. Have your vehicle inspected by a dealer.





Press the electric parking brake switch with the brake pedal depressed.





- Fasten the driver's seat belt.
- Check if the transmission is in P or N. If so, select any other position.

Safe Driving

You can find many safety recommendations throughout this chapter, and throughout this manual.

For Safe Driving	
Important Safety Precautions	32
Your Vehicle's Safety Features	34
Safety Checklist	35
Seat Belts	
About Your Seat Belts	36
Fastening a Seat Belt	40
Seat Belt Inspection	43
Airbags	
Airbag System Components	44
Types of Airbags	47
Front Airbags (SRS)	47

Side Airbags	5
Side Curtain Airbags	
Airbag System Indicators	55
Airbag Care	
Child Safety	
Protecting Child Passengers	58
Safety of Infants and Small Children	60
Safety of Larger Children	68
Exhaust Gas Hazard	
Carbon Monoxide Gas	70
Safety Labels	
Label Locations	7′

For Safe Driving

The following pages explain your vehicle's safety features and how to use them properly. The safety precautions below are ones that we consider to be among the most important.

Important Safety Precautions

■ Always wear your seat belt

A seat belt is your best protection in all types of collisions. Airbags are designed to supplement seat belts, not replace them. So even though your vehicle is equipped with airbags, make sure you and your passengers always wear your seat belts, and wear them properly.

■ Restrain all children

Children ages 12 and under should ride properly restrained in a back seat, not the front seat. Infants and small children should be restrained in a child seat. Larger children should use a booster seat and a lap/shoulder seat belt until they can use the belt properly without a booster seat.

■ Be aware of airbag hazards

While airbags can save lives, they can cause serious or fatal injuries to occupants who sit too close to them, or are not properly restrained. Infants, young children, and short adults are at the greatest risk. Be sure to follow all instructions and warnings in this manual.

■ Don't drink and drive

Alcohol and driving don't mix. Even one drink can reduce your ability to respond to changing conditions, and your reaction time gets worse with every additional drink. So don't drink and drive, and don't let your friends drink and drive, either.

∑Important Safety Precautions

Some states, provinces and territories prohibit the use of cell phones other than hands-free devices by the driver while driving.

■ Pay appropriate attention to the task of driving safely

Engaging in cell phone conversation or other activities that keep you from paying close attention to the road, other vehicles, and pedestrians could lead to a crash. Remember, situations can change quickly, and only you can decide when it is safe to divert some attention away from driving.


■ Control your speed

Excessive speed is a major factor in crash injuries and deaths. Generally, the higher the speed, the greater the risk, but serious injuries can also occur at lower speeds. Never drive faster than is safe for current conditions, regardless of the maximum speed posted.

■ Keep your vehicle in safe condition

Having a tire blowout or a mechanical failure can be extremely hazardous. To reduce the possibility of such problems, check your tire pressures and condition frequently, and perform all regularly scheduled maintenance.

Your Vehicle's Safety Features



The following checklist will help you take an active role in protecting yourself and your passengers.

∑Your Vehicle's Safety Features

Your vehicle is equipped with many features that work together to help protect you and your passengers during a crash.

Some features do not require any action on your part. These include a strong steel framework that forms a safety cage around the passenger compartment, front and rear crush zones, a collapsible steering column, and tensioners that tighten the front seat belts in a sufficient crash.

However, you and your passengers cannot take full advantage of these features unless you remain seated in the correct position and always wear your seat belts. In fact, some safety features can contribute to injuries if they are not used properly.

Safety Checklist

For the safety of you and your passengers, make a habit of checking these items each time before you drive.

After everyone has entered the vehicle, be sure all doors are closed and locked.
 Locking the doors helps prevent an occupant from being ejected and an outsider from unexpectedly opening a door.

■ Locking/Unlocking the Doors from the Inside P. 134

• Adjust your seat to a position suitable for driving. Be sure the front seats are adjusted as far to the rear as possible while allowing the driver to control the vehicle. Sitting too close to a front airbag can result in serious or fatal injury in a crash.

Adjusting the Seats P. 167

• Adjust head restraints to the proper position. Head restraints are most effective when the center of the head restraint aligns with the center of your head. Taller persons should adjust their head restraint to the highest position.

Adjusting the Front Head Restraints P. 170

• Always wear your seat belt, and make sure you wear it properly. Confirm that any passengers are properly belted as well.

Fastening a Seat Belt P. 40

 Protect children by using seat belts or child seats according to a child's age, height and weight.

Child Safety P. 58

Safety Checklist

Models with information display

If the door and trunk open indicator is on, a door or the trunk is not completely closed. Close all doors tightly until the indicator goes off.

Door and Trunk Open Indicator* P. 80



Models with driver information interface

If the door and trunk open message appears on the driver information interface, a door and/or the trunk is not completely closed. Close all doors and the trunk tightly until the message disappears.

Driver Information Interface Warning and Information Messages* P. 91



* Not available on all models

About Your Seat Belts

Seat belts are the single most effective safety device because they keep you connected to the vehicle so that you can take advantage of many built-in safety features. They also help keep you from being thrown against the inside of the vehicle, against other passengers, or out of the vehicle. When worn properly, seat belts also keep your body properly positioned in a crash so that you can take full advantage of the additional protection provided by the airbags.

In addition, seat belts help protect you in almost every type of crash, including:

- frontal impacts
- side impacts
- rear impacts
- rollovers

■ Lap/shoulder seat belts

All five seating positions are equipped with lap/shoulder seat belts with emergency locking retractors. In normal driving the retractor lets you move freely while keeping some tension on the belt. During a collision or sudden stop the retractor locks to restrain your body. The front passenger's and rear seat belts also have a lockable retractor for use with child seats.

Installing a Child Seat with a Lap/Shoulder Seat Belt P. 65

■ About Your Seat Belts

AWARNING

Not wearing a seat belt properly increases the chance of serious injury or death in a crash, even though your vehicle has airbags.

Be sure you and your passengers always wear seat belts and wear them properly.

Seat belts cannot completely protect you in every crash. But in most cases, seat belts can reduce your risk of serious injury.

Most states and all Canadian provinces and territories require you to wear seat belts.

The emergency locking retractor may lock if you lean forward too quickly. Slower movements will allow the belt to extend fully without locking.

■ Proper use of seat belts


Follow these guidelines for proper use:

- All occupants should sit upright, well back in the seat, and remain in that position for the duration of the trip. Slouching and leaning reduce the effectiveness of the belt and can increase the chance of serious injury in a crash.
- Never place the shoulder part of a lap/shoulder seat belt under your arm or behind your back. This could cause very serious injuries in a crash.
- Two people should never use the same seat belt. If they do, they could be very seriously injured in a crash.
- Do not put any accessories on the seat belts. Devices intended to improve comfort or reposition the shoulder part of a seat belt can reduce the protective capability and increase the chance of serious injury in a crash.

■ About Your Seat Belts

If a rear seat passenger moves around and extends the seat belt, the lockable retractor may activate. If this happens, release the retractor by unfastening the seat belt and allow the belt to retract completely. Then refasten the belt.

Seat Belt Reminder



Your vehicle monitors front seat belt use. If the ignition switch is turned to ON II *1 before the driver's seat belt is fastened, the beeper will sound and the indicator will blink. If the driver does not fasten the belt before the beeper stops, the indicator will remain on.

The beeper will also periodically sound and the indicator will blink while driving until the driver's and front passenger's seat belts are fastened.

Seat Belt Reminder

The indicator will also come on if a front passenger does not fasten their seat belt within six seconds after the ignition switch is turned to ON $[II]^{*1}$. When no one is sitting in the front passenger's seat, the indicator will not come on and the beeper will not sound. The indicator also may not come on and the beeper may not sound when the occupant is not heavy enough to trigger the weight sensor. Such occupants (e.g., infants and smaller children) should be moved to the rear seat as a deploying front airbag likely will injure or kill them.

Protecting Child Passengers P. 58

^{*1:} Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

Automatic Seat Belt Tensioners

The front seats are equipped with automatic seat belt tensioners to enhance safety.

The tensioners automatically tighten the front seat belts during a moderate-tosevere frontal collision, sometimes even if the collision is not severe enough to inflate the front airbags.




The seat belt tensioners can only operate once. If a tensioner is activated, the SRS indicator will come on. Have a dealer replace the tensioner and thoroughly inspect the seat belt system as it may not offer protection in a subsequent crash.

During a moderate-to-severe side impact, the tensioner on that side of the vehicle also activates.


Fastening a Seat Belt

After adjusting a front seat to the proper position, and while sitting upright and well back in the seat:

Adjusting the Seats P. 167



1. Pull the seat belt out slowly.



- 2. Insert the latch plate into the buckle, then tug on the belt to make sure the buckle is secure.
 - ► Make sure that the belt is not twisted or caught on anything.

∑Fastening a Seat Belt

No one should sit in a seat with an inoperative seat belt or one that does not appear to be working correctly. Using a seat belt that is not working properly may not protect the occupant in a crash. Have a dealer check the belt as soon as possible.

Never insert any foreign objects into the buckle or retractor mechanism.



- **3.** Position the lap part of the belt as low as possible across your hips, then pull up on the shoulder part of the belt so the lap part fits snugly. This lets your strong pelvic bones take the force of a crash and reduces the chance of internal injuries.
- **4.** If necessary, pull up on the belt again to remove any slack, then check that the belt rests across the center of your chest and over your shoulder. This spreads the forces of a crash over the strongest bones in your upper body.

>> Fastening a Seat Belt

AWARNING

Improperly positioning the seat belts can cause serious injury or death in a crash.


Make sure all seat belts are properly positioned before driving.

To release the belt, push the red **PRESS** button then guide the belt by hand until it has retracted completely.

When exiting the vehicle, be sure the belt is out of the way and will not get caught by closing the door.

Adjusting the Shoulder Anchor

The front seats have adjustable shoulder anchors to accommodate taller and shorter occupants.



- **1.** Move the anchor up and down while pulling the release outward.
- **2.** Position the anchor so that the belt rests across the center of your chest and over your shoulder.


→ Adjusting the Shoulder Anchor Output Description:

The shoulder anchor height can be adjusted to four levels. If the belt contacts your neck, lower the height one level at a time.

After an adjustment, make sure that the shoulder anchor position is secure.

Advice for Pregnant Women

If you are pregnant, the best way to protect yourself and your unborn child when driving or riding in a vehicle is to always wear a seat belt and keep the lap part of the belt as low as possible across the hips.



Each time you have a checkup, ask your doctor if it is okay for you to drive.

To reduce the risk of injuries to both you and your unborn child that can be caused by an inflating front airbag:

- When driving, sit upright and adjust the seat as far back as possible while allowing full control of the vehicle.
- When sitting in the front passenger's seat, adjust the seat as far back as possible.

Seat Belt Inspection

Regularly check the condition of your seat belts as follows:

- Pull each belt out fully, and look for frays, cuts, burns, and wear.
- Check that the latches work smoothly and the belts retract easily.
 - ▶ If a belt does not retract easily, cleaning the belt may correct the problem. Only use a mild soap and warm water. Do not use bleach or cleaning solvents. Make sure the belt is completely dry before allowing it to retract.

Any belt that is not in good condition or working properly will not provide proper protection and should be replaced as soon as possible.

A belt that has been worn during a crash may not provide the same level of protection in a subsequent crash. Have your seat belts inspected by a dealer after any collision.


Seat Belt Inspection

AWARNING

Not checking or maintaining seat belts can result in serious injury or death if the seat belts do not work properly when needed.

Check your seat belts regularly and have any problem corrected as soon as possible.

Airbag System Components



The front, front side, and side curtain airbags are deployed according to the direction and severity of impact. Both side curtain airbags are deployed in a rolloyer. The airbag system includes:

- 1 Two SRS (Supplemental Restraint System) front airbags. The driver's airbag is stored in the center of the steering wheel; the front passenger's airbag is stored in the dashboard Both are marked SRS AIRBAG
- 2 Two side airbags, one for the driver and one for a front passenger. The airbags are stored in the outer edges of the seatbacks. Both are marked **SIDE AIRBAG**.
- 3 Two side curtain airbags, one for each side of the vehicle. The airbags are stored in the ceiling, above the side windows. The front and rear pillars are marked SIDE CURTAIN AIRBAG.

- An electronic control unit that continually monitors and can record information about the sensors, the airbag activators, the seat belt tensioners, and driver and front passenger seat belt use when the ignition switch is in ON II *1.
- Automatic front seat belt tensioners. The driver's and front passenger's seat belts incorporate sensors that detect whether or not they are fastened.
- 6 A driver's seat position sensor. If the seat is too far forward, the airbag will inflate with less force
- Weight sensors in the front passenger's seat. The front passenger's airbag will be turned off if the weight on the seat is approximately 65 lbs (29 kg) or less (the weight of an infant or small child).

- Impact sensors that can detect a moderate-to-severe front impact or side impact.
- An indicator on the dashboard that alerts you that the front passenger's front airbag has been turned off.
- **10** An indicator on the instrument panel that alerts you to a possible problem with your airbag system or seat belt tensioners.
- A rollover sensor that detects if your vehicle is about to roll over and signal the control unit to deploy both side curtain airbags.
- *1: Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

45

■ Important Facts About Your Airbags

Airbags can pose serious hazards. To do their job, airbags must inflate with tremendous force. So, while airbags help save lives, they can cause burns, bruises, and other minor injuries, sometimes even fatal ones if occupants are not wearing their seat belts properly and sitting correctly.

What you should do: Always wear your seat belt properly, and sit upright and as far back from the steering wheel as possible while allowing full control of the vehicle. A front passenger should move their seat as far back from the dashboard as possible.

Remember, however, that no safety system can prevent all injuries or deaths that can occur in a severe crash, even when seat belts are properly worn and the airbags deploy.

Do not place hard or sharp objects between yourself and a front airbag. Carrying hard or sharp objects on your lap, or driving with a pipe or other sharp object in your mouth, can result in injuries if your front airbag inflates.

Do not attach or place objects on the front airbag covers. Objects on the covers marked **SRS AIRBAG** could interfere with the proper operation of the airbags or be propelled inside the vehicle and hurt someone if the airbags inflate.

Do not attempt to deactivate your airbags. Together, airbags and seat belts provide the best protection.

When driving, keep hands and arms out of the deployment path of the front airbag by holding each side of the steering wheel. Do not cross an arm over the airbag cover.

Types of Airbags

Your vehicle is equipped with three types of airbags:

- Front airbags: Airbags in front of the driver's and front passenger's seats.
- **Side airbags:** Airbags in the driver's and front passenger's seat-backs.
- **Side curtain airbags:** Airbags above the side windows.

Each is discussed in the following pages.

Front Airbags (SRS)

The front SRS airbags inflate in a moderate-to-severe frontal collision to help protect the head and chest of the driver and/or front passenger.

SRS (Supplemental Restraint System) indicates that the airbags are designed to supplement seat belts, not replace them. Seat belts are the occupant's primary restraint system.

Housing Locations

The front airbags are housed in the center of the steering wheel for the driver, and in the dashboard for the front passenger. Both airbags are marked **SRS AIRBAG**.

*1: Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

∑Types of Airbags

The airbags can inflate whenever the ignition switch is in ON $[II]^{*1}$.

After an airbag inflates in a crash, you may see a small amount of smoke. This is from the combustion process of the inflator material and is not harmful. People with respiratory problems may experience some temporary discomfort. If this occurs, get out of the vehicle as soon as it is safe to do so.

Dual-Stage, Multiple-Threshold Front Airbags (SRS)

Your vehicle is equipped with dual-stage, multiplethreshold front airbags (SRS).


During a frontal crash severe enough to cause one or both front airbags to deploy, the airbags can inflate at different rates, depending on the severity of the crash, whether or not the seat belts are latched, and/ or other factors. Frontal airbags are designed to supplement the seat belts to help to reduce the likelihood of head and chest injuries in frontal crashes.

Operation

Front airbags are designed to inflate during moderate-to-severe frontal collisions. When the vehicle decelerates suddenly, the sensors send information to the control unit which signals one or both front airbags to inflate.

A frontal collision can be either head-on or angled between two vehicles, or when a vehicle crashes into a stationary object, such as a concrete wall.

■ How the Front Airbags Work



While your seat belt restrains your torso, the front airbag provides supplemental protection for your head and chest.

The front airbags deflate immediately so that they won't interfere with the driver's visibility or the ability to steer or operate other controls.

The total time for inflation and deflation is so fast that most occupants are not aware that the airbags deployed until they see them lying in front of them.

Although the driver's and front passenger's airbags normally inflate within a split second of each other, it is possible for only one airbag to deploy. This can happen if the severity of a collision is at the margin, or threshold, that determines whether or not the airbags will deploy. In such cases, the seat belt will provide sufficient protection, and the supplemental protection offered by the airbag would be minimal.

■ When front airbags should not deploy

Minor frontal crashes: Front airbags were designed to supplement seat belts and help to save lives, not to prevent minor scrapes, or even broken bones that might occur during a less than moderate-to-severe frontal crash.

Side impacts: Front airbags can provide protection when a sudden deceleration causes a driver or front passenger to move towards the front of the vehicle. Side airbags and side curtain airbags have been specifically designed to help to reduce the severity of injuries that can occur during a moderate-to-severe side impact which can cause the driver or passenger to move towards the side of the vehicle.

Rear impacts: Head restraints and seat belts are your best protection during a rear impact. Front airbags cannot provide any significant protection and are not designed to deploy in such collisions.

Rollovers: Seat belts, and in vehicles equipped with a rollover sensor, side airbags, and side curtain airbags offer the best protection in a rollover. Because front airbags could provide little if any protection, they are not designed to deploy during a rollover

■ When front airbags deploy with little or no visible damage


Because the airbag system senses sudden deceleration, a strong impact to the vehicle framework or suspension might cause one or more of the airbags to deploy. Examples include running into a curb, the edge of a hole, or other low fixed object that causes a sudden deceleration in the vehicle chassis. Since the impact is underneath the vehicle, damage may not be readily apparent.

■ When front airbags may not deploy, even though exterior damage appears severe

Since crushable body parts absorb crash energy during an impact, the amount of visible damage does not always indicate proper airbag operation. In fact, some collisions can result in severe damage but no airbag deployment because the airbags would not have been needed or would not have provided protection even if they had deployed.


Advanced Airbags

Your front airbags have advanced features to help reduce the likelihood of airbag related injuries to smaller occupants.



The driver's advanced front airbag system includes a seat position sensor.

If the seat is too far forward, the airbag inflates with less force, regardless of the severity of the impact.



The passenger's advanced front airbag system has weight sensors.

Although we recommend against carrying an infant or small child in front, if the sensors detect the weight of a child (up to about 65 lbs or 29 kg), the system will automatically turn off the passenger's front airbag.

■ Advanced Airbags

If there is a problem with the driver's seat position sensor, the SRS indicator will come on and the airbag will inflate with full (normal) force, regardless of the driver's seating position.

For both advanced front airbags to work properly:

- Do not spill any liquid on or under the seats.
- Do not put any object under the passenger's seat.
- Make sure any objects are positioned properly on the floor. Improperly positioned objects can interfere with the advanced airbag sensors.
- All occupants should sit upright and wear their seat belts properly.
- Do not place any cover over the passenger side dashboard.

Side Airbags

The side airbags help protect the torso and pelvis of the driver or a front passenger during a moderate-to-severe side impact.

Housing Locations



The side airbags are housed in the outside edge of the driver's and passenger's seat-backs.

Both are marked **SIDE AIRBAG**.

Operation



When the sensors detect a moderate-tosevere side impact, the control unit signals the side airbag on the impact side to immediately inflate.

Side Airbags

Make sure you and your front seat passenger always sit upright. Leaning into the path of a side airbag can prevent the airbag from deploying properly and increases your risk of serious injury.

Do not attach accessories on or near the side airbags. They can interfere with the proper operation of the airbags, or hurt someone if an airbag inflates.

Do not cover or replace the front seat-back covers without consulting a dealer.

Improperly replacing or covering front seat-back covers can prevent your side airbags from properly deploying during a side impact.

■ When a side airbag deploys with little or no visible damage

Because the airbag system senses sudden acceleration, a strong impact to the side of the vehicle's framework can cause a side airbag to deploy. In such cases, there may be little or no damage, but the side impact sensors detected a severe enough impact to deploy the airbag.


■ When a side airbag may not deploy, even though visible damage appears severe

It is possible for a side airbag to not deploy during an impact that results in apparently severe damage. This can occur when the point of impact was toward the far front or rear of the vehicle, or when the vehicle's crushable body parts absorbed most of the crash energy. In either case, the side airbag would not have been needed nor provided protection even if it had deployed.

Side Curtain Airbags


The side curtain airbags help protect the heads of the driver and passengers in outer seating positions during a moderate-to-severe side impact. The side curtain airbags equipped in this vehicle are also designed to help reduce the likelihood of partial and complete ejection of vehicle occupants through side windows in crashes, particularly rollover crashes

Housing Locations



The side curtain airbags are located in the ceiling above the side windows on both sides of the vehicle.

Operation



The side curtain airbag is designed to deploy in a rollover or a moderate-to-severe side impact.

Side Curtain Airbags

If the SRS control unit senses that your vehicle is about to rollover, it immediately deploys both side curtain airbags and activates both front seat belt tensioners.

If the impact is on the passenger's side, the passenger's side curtain airbag deploys even if there is no passenger in the passenger seat.

To get the best protection from the side curtain airbags, occupants should wear their seat belts properly and sit upright and well back in their seats.

Do not attach any objects to the side windows or roof pillars as they can interfere with the proper operation of the side curtain airbags.


■ When side curtain airbags deploy in a frontal collision
One or both side curtain airbags may inflate in a moderate-to-severe angled frontal collision.

In this case, the side curtain airbags will deploy slightly after the front airbags.

Airbag System Indicators

If a problem occurs in the airbag system, the SRS indicator will come on and a message appears on the driver information interface*.

Supplemental Restraint System (SRS) Indicator




■ When the ignition switch is turned to ON III*1

The indicator comes on for a few seconds, then goes off. This tells you the system is working properly. Supplemental Restraint System (SRS) Indicator

AWARNING


Ignoring the SRS indicator can result in serious injury or death if the airbag systems or tensioners do not work properly.

Have your vehicle checked by a dealer as soon as possible if the SRS indicator alerts you to a possible problem.



- *1: Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.
- * Not available on all models

■ Passenger Airbag Off Indicator



■ When the passenger airbag off indicator comes on

The indicator comes on to alert you that the passenger's front airbag has been turned off. This occurs when the weight sensors detect about 65 lbs (29 kg) or less, the weight of an infant or small child, on the seat.

Infants and small children should always ride properly restrained in a back seat.

Child Safety P. 58

If the front passenger seat is empty, the passenger's front airbag will not deploy and the indicator will come on.

To ensure the passenger is detected properly, confirm that:

- There is no child seat or other object pressing against the rear of the seat-back.
- There is no rear passenger pushing or pulling on the back of the front passenger's seat.
- The front seat or seat-back is not forced back against an object on the seat or floor behind it.
- There is no object placed under or beside the front passenger's seat.
- The occupant is sitting in an upright position and the seat back is not excessively reclined.
- The occupant is not leaning against the door or center console.
- The occupant's feet are placed on the floor in front of them.
- There are no objects hanging from the front passenger's seat.
- Only small, lightweight objects are in the seat-back pocket.

The passenger airbag off indicator may come on and go off periodically if the total weight on the seat is near the airbag cutoff threshold.

Have your vehicle checked by a dealer as soon as possible if:

- All of the above conditions are met, and the indicator comes on with an adult seated in the front passenger seat.
- The seat is empty and the indicator is off.

Do not allow an adult passenger to ride in the front seat when the indicator is on.

Airbag Care

You do not need to, and should not, perform any maintenance on or replace any airbag system components yourself. However, you should have your vehicle inspected by a dealer in the following situations:

■ When the airbags have deployed

If an airbag has inflated, the control unit and other related parts must be replaced. Similarly, once an automatic seat belt tensioner has been activated, it must be replaced.

■ When the vehicle has been in a moderate-to-severe collision

Even if the airbags did not inflate, have your dealer inspect the following: the driver's seat position sensor, weight sensors in the passenger's seat, front seat belt tensioners, and each seat belt that was worn during the crash.

■ Do not remove or modify a front seat without consulting a dealer

This would likely disable or affect the proper operation of the driver's seat position sensor or the weight sensors in the passenger's seat. If it is necessary to remove or modify a front seat to accommodate a person with disabilities, contact a Honda dealer, or for U.S. vehicles, American Honda Automobile Customer Service at 800-999-1009 and for Canadian vehicles, Honda Canada Customer Relations at 888-9-HONDA-9.

We recommend against the use of salvaged airbag system components, including the airbag, tensioners, sensors, and control unit.

Child Safety

Protecting Child Passengers

Each year, many children are injured or killed in vehicle crashes because they are either unrestrained or not properly restrained. In fact, vehicle accidents are the number one cause of death of children ages 12 and under.

To reduce the number of child deaths and injuries, every state, Canadian province and territory requires that infants and children be properly restrained when they ride in a vehicle.

Children should sit properly restrained in a rear seat. This is because:



- An inflating front or side airbag can injure or kill a child sitting in the front seat.
- A child in the front seat is more likely to interfere with the driver's ability to safely control the vehicle.
- Statistics show that children of all sizes and ages are safer when they are properly restrained in a rear seat.

AWARNING

Children who are unrestrained or improperly restrained can be seriously injured or killed in a crash.

Any child too small for a seat belt should be properly restrained in a child seat. A larger child should be properly restrained with a seat belt, using a booster seat if necessary.

The National Highway Traffic Safety Administration and Transport Canada recommend that all children ages 12 and under be properly restrained in a rear seat. Some states or provinces/territories have laws restricting where children may ride.

- Any child who is too small to wear a seat belt correctly must be restrained in an approved child seat that is properly secured to the vehicle using either the lap belt portion of the lap/shoulder belt or the lower anchors of the LATCH system.
- Never hold a child on your lap because it is impossible to protect them in the event of a collision.
- Never put a seat belt over yourself and a child. During a crash, the belt would likely press deep into the child and cause serious or fatal injuries.
- Never let two children use the same seat belt. Both children could be very seriously injured in a crash.
- Do not allow children to operate the doors, windows or seat adjustments.
- Do not leave children in the vehicle unattended, especially in hot weather when the inside of the vehicle can get hot enough to kill them. They could also activate vehicle controls causing it to move unexpectedly.

▶ Protecting Child Passengers

AWARNING

Allowing a child to play with a seat belt or wrap one around their neck can result in serious injury or death.

Instruct children not to play with any seat belt and make sure any unused seat belt a child can reach is buckled, fully retracted, and locked.

To deactivate a lockable retractor, release the buckle and allow the seat belt to wind up all the way.


To remind you of the passenger's front airbag hazards and child safety, your vehicle has warning labels on the dashboard (U.S. models) and on the front visors. Please read and follow the instructions on these labels.

Safety Labels P. 71

Safety of Infants and Small Children

Protecting Infants

An infant must be properly restrained in a rear-facing, reclining child seat until the infant reaches the seat maker's weight or height limit for the seat, and the infant is at least one year old. Many experts recommend use of a rear-facing seat for a child up to two years old if the child's height and weight are appropriate for a rear-facing seat.



■ Positioning a rear-facing child seat Child seats must be placed and secured in a rear seating position.

When properly installed, a rear-facing child seat may prevent the driver or a front passenger from moving their seat all the way back, or from locking their seat-back in the desired position.

It can also interfere with proper operation of the passenger's advanced front airbag system.

Airbags P. 44

If this occurs, we recommend that you install the child seat directly behind the front passenger's seat, move the seat as far forward as needed, and leave it unoccupied. Or, you may wish to get a smaller rear-facing child seat.

▶ Protecting Infants

AWARNING

Placing a rear-facing child seat in the front seat can result in serious injury or death during a crash.

Always place a rear-facing child seat in the rear seat, not the front.

Rear-facing child seats should never be installed in a forward facing position.

Always refer to the child seat manufacturer's instructions before installation.

Protecting Smaller Children

If a child is at least one year old and within the weight range indicated by the child seat manufacturer, the child should be properly restrained in a firmly secured forward-facing child seat.



■ Forward-facing child seat placement We strongly recommend placing a forward-facing child seat in a rear seating position.

Placing a forward-facing child seat in the front seat can be hazardous, even with advanced front airbags that automatically turn the passenger's front airbag off. A rear seat is the safest place for a child.

AWARNING

Placing a forward-facing child seat in the front seat can result in serious injury or death if the front airbag inflates.

If you must place a forward-facing child seat in front, move the vehicle seat as far back as possible, and properly restrain the child.

Educate yourself about the laws and regulations regarding child seat use where you are driving, and follow the child seat manufacturer's instructions.

Many experts recommend use of a rear-facing seat for a child up to two years old if the child's height and weight are appropriate for a rear-facing seat.

Selecting a Child Seat

Most child seats are LATCH-compatible (Lower Anchors and Tethers for CHildren). Some have a rigid-type connector, while others have a flexible-type connector. Both are equally easy to use. Some existing and previously owned child seats can only be installed using the seat belt. Whichever type you choose, follow the child seat manufacturer's use and care instructions as well as the instructions in this manual. Proper installation is key to maximizing your child's safety.

In seating positions and vehicles not equipped with LATCH, a LATCH-compatible child seat can be installed using the seat belt and a top tether for added security. This is because all child seats are required to be designed so that they can be secured with a lap belt or the lap part of a lap/shoulder belt. In addition, the child seat manufacturer may advise that a seat belt be used to attach a LATCH-compatible seat once a child reaches a specified weight. Please read the child seat owner's manual for proper installation instructions.

■ Important consideration when selecting a child seat

Make sure the child seat meets the following three requirements:

- The child seat is the correct type and size for the child.
- The child seat is the correct type for the seating position.
- The child seat is compliant with Federal Motor Vehicle Safety Standard 213 or Canadian Motor Vehicle Safety Standard 213.

■ Selecting a Child Seat

Installation of a LATCH-compatible child seat is simple.


LATCH-compatible child seats have been developed to simplify the installation process and reduce the likelihood of injuries caused by incorrect installation.

■ Installing a LATCH-Compatible Child Seat


A LATCH-compatible child seat can be installed in either of the two outer rear seats. A child seat is attached to the lower anchors with either the rigid or flexible type of connectors.




1. Locate the lower anchors under the marks



- **2.** Place the child seat on the vehicle seat then attach the child seat to the lower anchors according to the instructions that came with the child seat.
 - ➤ When installing the child seat, make sure that the lower anchors are not obstructed by the seat belt or any other object.






- **3.** Open the tether anchor cover behind the head restraint.
- **4.** Route the tether strap over the top of the head restraint and secure the tether strap hook onto the anchor.
- **5.** Tighten the tether strap as instructed by the child seat manufacturer.
- **6.** Make sure the child seat is firmly secured by rocking it forward and back and side to side; little movement should be felt.
- Make sure any unused seat belt that a child can reach is buckled, the lockable retractor is activated, and the belt is fully retracted and locked.

For your child's safety, when using a child seat installed using the LATCH system, make sure that the child seat is properly secured to the vehicle. A child seat that is not properly secured will not adequately protect a child in a crash and may cause injury to the child or other vehicle occupants.

■ Installing a Child Seat with a Lap/Shoulder Seat Belt




- **1.** Place the child seat on the vehicle seat
- 2. Route the seat belt through the child seat according to the seat manufacturer's instructions, and insert the latch plate into the buckle.
 - Insert the latch plate fully until it clicks.





- **3.** Slowly pull the shoulder part of the belt all the way out until it stops. This activates the lockable retractor.
- 4. Let the seat belt completely wind up into the retractor, then try to pull it out to make sure the retractor is locked.
 - If you are able to pull the shoulder belt out, the lockable retractor is not activated. Pull the seat belt all the way out, and repeat steps 3 - 4.



► When doing this, place your weight on the child seat and push it into the vehicle seat.

A child seat that is not properly secured will not adequately protect a child in a crash and may cause injury to the child or other vehicle occupants.






- **6.** Make sure the child seat is firmly secured by rocking it forward and back and side to side; little movement should be felt.
- **7.** Make sure any unused seat belt that a child can reach is buckled, the lockable retractor is activated, and the belt is fully retracted and locked.

≥ Installing a Child Seat with a Seat Belt

To deactivate a lockable retractor, release the buckle and allow the seat belt to wind up all the way.

Adding Security with a Tether



Straight Top Tether Type in Outer Position

Tether Strap Hook


Anchor


A tether anchorage point is provided behind each rear seating position. A child seat that is installed with a seat belt and comes with a tether can use the tether for additional security.


- **1.** Locate the appropriate tether anchorage point and lift the cover.
- **2.** Route the tether strap over the head restraint. Make sure the strap is not twisted.

■ Adding Security with a Tether

Since a tether can provide additional security to the lap/shoulder seat belt installation, we recommend using a tether whenever one is available.







- **3.** Secure the tether strap hook onto the anchor.
- **4.** Tighten the tether strap as instructed by the child seat manufacturer.

Safety of Larger Children

■ Protecting Larger Children

The following pages give instructions on how to check proper seat belt fit, what kind of booster seat to use if one is needed, and important precautions for a child who must sit in front.

Checking Seat Belt Fit

When a child is too big for a child seat, secure the child in a rear seat using the lap/ shoulder seat belt. Have the child sit upright and all the way back, then answer the following questions.



■ Checklist

- Do the child's knees bend comfortably over the edge of the seat?
- Does the shoulder belt cross between the child's neck and arm?
- Is the lap part of the seat belt as low as possible, touching the child's thighs?
- Will the child be able to stay seated like this for the whole trip?

If you answer yes to all these questions, the child is ready to wear the lap/shoulder seat belt correctly. If you answer no to any question, the child needs to ride on a booster seat until the seat belt fits properly without a booster seat.

Safety of Larger Children

AWARNING

Allowing a child ages 12 or under to sit in front can result in injury or death if the passenger's front airbag inflates.

If a larger child must ride in front, move the vehicle seat as far to the rear as possible, have the child sit up properly and wear the seat belt properly, using a booster seat if needed.

Booster Seats



If a lap/shoulder seat belt cannot be used properly, position the child in a booster seat in a rear seating position. For the child's safety, check that the child meets the booster seat manufacturer's recommendations.

■ Protecting Larger Children-Final Checks

Your vehicle has a rear seat where children can be properly restrained. If you ever have to carry a group of children, and a child must ride in front:

- Make sure you read and fully understand the instructions and safety information in this manual.
- Move the front passenger seat as far back as possible.
- Have the child sit upright and well back in the seat.
- Check that the seat belt is properly positioned so that the child is secure in the seat.

■ Monitoring child passengers

We strongly recommend that you keep an eye on child passengers. Even older, more mature children sometimes need to be reminded to fasten their seat belts and sit up properly.

■Booster Seats

When installing a booster seat, make sure to read the instructions that came with it, and install the seat accordingly.

There are high- and low-type booster seats. Choose a booster seat that allows the child to wear the seat belt correctly.

Some U.S. states, and Canadian provinces and territories require children to use a booster seat until they reach a given age or weight (e.g. six years or 60 lbs). Be sure to check current laws in the state or province, or territory where you intend to drive.

Exhaust Gas Hazard

Carbon Monoxide Gas

The engine exhaust from this vehicle contains carbon monoxide, a colorless, odorless, and highly toxic gas. As long as you properly maintain your vehicle, carbon monoxide gas will not get into the interior.

■ Have the exhaust system inspected for leaks whenever

- The exhaust system is making an unusual noise.
- The exhaust system may have been damaged.
- The vehicle is raised for an oil change.

When you operate a vehicle with the trunk open, airflow can pull exhaust gas into the interior and create a hazardous condition. If you must drive with the trunk open, open all the windows and set the heating system*/climate control system* as shown below.

- 1. Select the fresh air mode.
- 2. Select the mode.
- 3. Set the fan speed to high.
- **4.** Set the temperature control to a comfortable setting.

Adjust the heating system*/climate control system* in the same manner if you sit in your parked vehicle with the engine running.

○ Carbon Monoxide Gas

AWARNING

Carbon monoxide gas is toxic. Breathing it can cause unconsciousness and even kill you.

Avoid any enclosed areas or activities that expose you to carbon monoxide.

An enclosed area such as a garage can quickly fill up with carbon monoxide gas.


Do not run the engine with the garage door closed. Even when the garage door is open, drive out of the garage immediately after starting the engine.

Safety Labels

Label Locations

These labels are in the locations shown. They warn you of potential hazards that can cause serious injury or death. Read these labels carefully.

If a label comes off or becomes hard to read (except for the U.S. dashboard label which may be removed by the owner), contact a dealer for a replacement.



* Not available on all models 71

Instrument Panel

This chapter describes the buttons, indicators, and gauges that are used while driving.

ndicators	74
Information Display Warning and	
Information Messages *	90
Driver Information Interface Warnir	ng an
Information Messages*	9
Gauges and Displays	
Gauges	10
Information Display*	104
Driver Information Interface *	10

Indicator	Name	On/Blinking	Explanation	Message*
U.S. BRAKE Canada (Red)	Parking Brake and Brake System Indicator (Red)	 Comes on for a few seconds when you turn the ignition switch to ON [II]*1, then goes off if the parking brake has been released. Comes on when the parking brake is applied, and goes off when it is released. Comes on when the brake fluid level is low. Comes on if there is a problem with the brake system. The beeper sounds and the indicator comes on if you drive with the parking brake not fully released. Comes on for about 15 seconds when you pull the electric parking brake switch while the ignition switch is in LOCK [0]*1. Stays on for about 15 seconds when you turn the ignition switch to LOCK [0]*1 while the electric parking brake is set. 	 Comes on while driving - Make sure the parking brake is released. Check the brake fluid level. What to do when the indicator comes on P. 554 Comes on along with the ABS indicator - Have your vehicle checked by a dealer. If the Brake System Indicator (Red) Comes On or Blinks P. 554 Blinks and the brake system indicator (amber) comes on at the same time - There is a problem with the electric parking brake system. The parking brake may not be set. Avoid using the parking brake and have your vehicle checked by a dealer immediately. If the Brake System Indicator (Red) Comes On or Blinks at the Same Time When the Brake System Indicator (Amber) Comes On P. 555 	Perkins Brake WASHING Brake Fluid Low Brake System Problem

^{*1:}Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

Indicator	Name	On/Blinking	Explanation	Message*
Canada	Parking Brake and Brake System Indicator (Amber)	 Comes on for a few seconds when you turn the ignition switch to ON [II]*1, then goes off. Comes on if there is a problem with a system related to braking other than the conventional brake system. Comes on if there is a problem with the electric parking brake system or the automatic brake hold system. 	 Stays on constantly - Have your vehicle checked by a dealer. Comes on while driving - Avoid using the parking brake and have your vehicle checked by a dealer immediately. 	Brake System Problem Brake Hold System Problem Canada Brake System Problem Canada Brake System Problem Canada Brake System Problem Canada

^{*1:}Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

Indicator	Name	On/Blinking	Explanation	Message*
BRAKE HOLD	Automatic Brake Hold System Indicator	 Comes on for a few seconds when you turn the ignition switch to ON III *1, then goes off. Comes on when the automatic brake hold system is on. 	▶ Automatic Brake Hold P. 454	Brake Hold System Standby
U.S. HOLD Canada (A)	Automatic Brake Hold Indicator	 Comes on for a few seconds when you turn the ignition switch to ON II *1, then goes off. Comes on when the automatic brake hold is activated. 	▶ Automatic Brake Hold P. 454	-
75%	Low Oil Pressure Indicator	 Comes on when you turn the ignition switch to ON III *1, and goes off when the engine starts. Comes on when the engine oil pressure is low. 	• Comes on while driving - Immediately stop in a safe place. ☑ If the Low Oil Pressure Indicator Comes On P. 552	Check Engine Oil Level

^{*1:}Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

77

Indicator	Name	On/Blinking	Explanation	Message*
(Malfunction Indicator Lamp	 Comes on when you turn the ignition switch to ON II *1, and goes off when the engine starts, or after several seconds if the engine did not start. If "readiness codes" have not been set, it blinks five times before it goes off. Comes on if there is a problem with the emissions control system. Blinks when a misfire in the engine's cylinders is detected. 	 Readiness codes are part of the on board diagnostics for the emissions control systems. Testing of Readiness Codes P. 575 Comes on while driving - Have your vehicle checked by a dealer. Blinks while driving - Stop in a safe place where there are no flammable objects. Stop the engine for 10 minutes or more, and wait for it to cool down. Then, take your vehicle to a dealer. If the Malfunction Indicator Lamp Comes On or Blinks P. 553 	Emissions System Problem
<u>= =</u>	Charging System Indicator	 Comes on when you turn the ignition switch to ON II *1, and goes off when the engine starts. Comes on when the battery is not charging. 	• Comes on while driving - Turn off the heating system*/climate control system* and rear defogger in order to reduce electricity consumption. ■ If the Charging System Indicator Comes On P. 552	12 Volt Battery Charging System Problem
	Shift Lever Position Indicator*	 Indicates the current shift lever position. 	▶ Shifting P. 405	_

^{*1:}Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

* Not available on all models Continued

Indicator	Name	On/Blinking	Explanation	Message*
	Transmission Indicator*	 Comes on for a few seconds when you turn the ignition switch to ON III *1, then goes off. Blinks if the transmission system has a problem. 	Blinks while driving - Avoid sudden starts and acceleration and have your vehicle checked by a dealer immediately.	Transmission System Problem Stop Driving When Safe Prophing Problem See Manual
	Seat Belt Reminder Indicator	 Comes on and the beeper sounds if you are not wearing a seat belt when you turn the ignition switch to ON III*1. If the front passenger is not wearing a seat belt, the indicator comes on a few seconds later. Blinks while driving if either you or the front passenger has not fastened a seat belt. The beeper sounds and the indicator blinks at regular intervals. 	 The beeper stops and the indicator goes off when you and the front passenger fasten their seat belts. Stays on after you or the front passenger has fastened the seat belt A detection error may have occurred in the sensor. Have your vehicle checked by a dealer. Seat Belt Reminder P. 38 	Fasten Seut Fasten Fast
[]	Low Fuel Indicator	 Comes on when the fuel reserve is running low (approximately 1.8 U.S. gal/7.0 Liter left). Blinks if there is a problem with the fuel gauge. 	 Comes on - Refuel your vehicle as soon as possible. Blinks - Have your vehicle checked by a dealer. 	Fuel Cause System Problem

^{*1:}Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

Indicator	Name	On/Blinking	Explanation	Message*
(ABS)	Anti-lock Brake System (ABS) Indicator	 Comes on for a few seconds when you turn the ignition switch to ON III *1, then goes off. If it comes on at any other time, there is a problem with the ABS. 	• Stays on constantly - Have your vehicle checked by a dealer. With this indicator on, your vehicle still has normal braking ability but no anti-lock function. ▶ Anti-lock Brake System (ABS) P. 457	Anti-Lock Brake System Problem
	Supplemental Restraint System Indicator	 Comes on for a few seconds when you turn the ignition switch to ON [II]*1, then goes off. Comes on if a problem with any of the following is detected: Supplemental restraint system Side airbag system Side curtain airbag system Seat belt tensioner 	Stays on constantly or does not come on at all - Have your vehicle checked by a dealer.	g - Alrhaig Syntom (SIGS) Problem
,	Vehicle Stability Assist (VSA®) System Indicator	 Comes on for a few seconds when you turn the ignition switch to ON II *1, then goes off. Blinks when VSA® is active. Comes on if there is a problem with the VSA® system or hill start assist system. 	• Stays on constantly - Have your vehicle checked by a dealer. ▶ Vehicle Stability Assist (VSA®), aka Electronic Stability Control (ESC), System P. 441	Vehicle Assist (VSA) Problem Hill Start Assist Problem
		 Comes on if the VSA® system is deactivated temporarily after the battery has been disconnected, then re-connected. 	Drive a short distance at more than 12 mph (20 km/h). The indicator should go off. If it does not, have your vehicle checked by a dealer.	Drive Carefully Systems Initializing

^{*1:}Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

^{*} Not available on all models

Indicator	Name	On/Blinking	Explanation	Message*
	Vehicle Stability Assist (VSA®)	 Comes on for a few seconds when you turn the ignition switch to ON [II]*1, then goes off. Comes on when you partially disable VSA®. 	IJ VSA® On and Off P. 442	Vehicle Stability Assist (VSA) OFF
ÕFF	OFF Indicator	 Comes on if the VSA® system is deactivated temporarily after the battery has been disconnected, then re-connected. 	 Drive a short distance at more than 12 mph (20 km/h). The indicator should go off. If it does not, have your vehicle checked by a dealer. 	Drive Carefully Systems Initializing.
	Door and Trunk Open Indicator*	 Comes on for a few seconds if you turn the ignition switch to ON [II]*1, then goes off. Comes on if any door or the trunk is not completely closed. The beeper sounds and the indicator comes on if any door or the trunk is opened while driving. 	Goes off when all doors and the trunk are closed.	_
⊕!	Electric Power Steering (EPS) System Indicator	 Comes on when you turn the ignition switch to ON [II]*1, and goes off when the engine starts. Comes on if there is a problem with the EPS system. 	• Stays on constantly or does not come on at all - Have your vehicle checked by a dealer. ■ If the Electric Power Steering (EPS) System Indicator Comes On P. 556	Power Steering System (EPS) Problem

^{*1:}Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

Indicator	Name	On/Blinking	Explanation	Message*
U.S. models Low Tire Pressure/TPMS Indicator	 Comes on for a few seconds when you turn the ignition switch to ON [II]*1. May come on briefly if the ignition switch is turned to ON [II]*1 and the vehicle is not moved within 45 seconds, to indicate the calibration process is not yet complete. Comes on and stays on when: One or more tires' pressures are determined to be significantly low. The system has not been calibrated. 	 Comes on while driving - Stop in a safe place, check tire pressures, and inflate the tire(s) if necessary. Stays on after the tires are inflated to the recommended pressures - The system needs to be calibrated. TPMS Calibration P. 446 	(1) The Pressures	
	 Blinks for about one minute, and then stays on if there is a problem with the TPMS, or when a compact spare tire is temporarily installed. 	• Blinks and remains on - Have your vehicle checked by a dealer. If the vehicle is fitted with a compact spare, get your regular tire repaired or replaced and put back on your vehicle as soon as you can.	Tire Pressure Monitor Problem	
		• Comes on if the TPMS is deactivated temporarily after the battery has been disconnected, then re-connected.	Drive a short distance at more than 12 mph (20 km/h). The indicator should go off. If it does not, have your vehicle checked by a dealer.	Orive Carefully Systems Initializing.

^{*1:}Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

Indicator	Name	On/Blinking	Explanation	Message*
i	System Message Indicator*	 Comes on for a few seconds when you turn the ignition switch to ON [II]*1, then goes off. Comes on along with a beep when a problem is detected. A system message on the driver information interface appears at the same time. 	 While the indicator is on, press the (display/information) button to see the message again. Refer to the Indicators information in this chapter when a system message appears on the driver information interface. Take the appropriate action for the message. The driver information interface does not return to the normal screen unless the warning is canceled, or the button is pressed. 	_
++	Turn Signal and Hazard Warning Indicators	 Blink when you operate the turn signal lever. Blink along with all turn signals when you press the hazard warning button. 	 Does not blink or blinks rapidly - A turn signal light bulb has blown. Change the bulb immediately. ▶ Replacing Light Bulbs P. 508, 511 	_
	High Beam Indicator	Comes on when the high beam headlights are on.	_	_
<u> </u>	Lights On Indicator	 Comes on whenever the light switch is on, or in AUTO* when the exterior lights are on. 	• If you remove the key from the ignition switch*1 while the exterior lights are on, a chime sounds when the driver's door is opened.	_
钓	Fog Light Indicator*	• Comes on when the fog lights are on.	_	_

^{*1:}Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

^{*} Not available on all models

Indicator	Name	On/Blinking	Explanation	Message*
Indicator	Immobilizer System Indicator	Blinks if the immobilizer system cannot recognize the key information.	 Blinks - You cannot start the engine. Turn the ignition switch to LOCK 0 *1, pull the key out*2, and then insert the key and turn it to ON II *1 again. Repeatedly blinks - The system may be malfunctioning. Have your vehicle checked by a dealer. Do not attempt to alter this system or add other devices to it. Electrical problems can occur. 	_
indicator	Security System Alarm Indicator	Blinks when the security system alarm has been set.	▶ Security System Alarm P. 144	_

^{*1:}Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch. *2:Canadian models only: Apply and hold the brake pedal before turning the ignition on.

Indicator	Name	On/Blinking	Explanation	Message*
*	ECON Mode Indicator	• Comes on when you press the ECON button.	EXECON Button P. 410	ECON ON
CRUISE MAIN	CRUISE MAIN Indicator*	Comes on when you press the CRUISE button.	☐ Cruise Control * P. 411	-
CRUISE CONTROL	CRUISE CONTROL Indicator*	• Comes on if you have set a speed for cruise control.	☐ Cruise Control * P. 411	-
	Washer Level Indicator*	Comes on when the washer fluid gets low.	 Refill the washer fluid. Refilling Window Washer Fluid P. 503 	-
~ C	Maintenance Minder Indicator*	Comes on when the scheduled maintenance is due soon.	▶ Maintenance Minder™ P. 479	-

Indicator	Name	On/Blinking	Explanation	Message*
Continuously variable transmission models		 Comes on for a few seconds when you turn the ignition switch to ON III *1, then goes off. Electric Parking Brake System Blinks when the electric parking brake switch is pressed without depressing the brake pedal while the electric parking brake is in operation. 	 Blinks while driving - Press the electric parking brake switch with the brake pedal depressed. ▶ Parking Brake P. 451 	_
Manual transmission models	Depressing Indicator*	 Automatic Brake Hold System Blinks when the automatic brake hold button is pressed without depressing the brake pedal while the automatic brake hold is in operation. Blinks if the automatic brake hold is automatically canceled while it is in operation. The beeper sounds. 	 Blinks while driving - Press the automatic brake hold button with the brake pedal depressed. Automatic Brake Hold P. 454 Immediately depress the brake pedal. 	_

^{*1:}Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

85

Indicator	Name	On/Blinking	Explanation	Message*
		 Comes on for a few seconds when you turn the ignition switch to ON [II]*1, then goes off. Comes on if there is a problem with the RDM system. 	• Stays on constantly - Have your vehicle checked by a dealer.	Road Departure Milegrium System Problem
	Road Departure Mitigation (RDM) Indicator*	Comes on when the RDM system shuts itself off.	• Stays on - The temperature inside the camera is too high. Use the climate control system to cool down the camera. The system activates when the temperature inside the camera cools down. ▶ Front Sensor Camera* P. 414	Bring State Austi Striken Creat Strukt Green Strukter Striken Strukter Striken
			 Stays on - The area around the camera is blocked by dirt, mud, etc. Stop your vehicle in a safe place, and wipe it off with a soft cloth. Have your vehicle checked by a dealer if the indicator and message come back on after you cleaned the area around the camera. Front Sensor Camera* P. 414 	Some Driver Assist. System Consul General Closer Fourt Windsheld

^{*1:}Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

Indicator	Name	On/Blinking	Explanation	Message*
	Adaptive Cruise Control (ACC)	 Comes on for a few seconds when you turn the ignition switch to ON [II]*1, then goes off. Comes on if there is a problem with ACC with LSF. 	Comes on while driving - Have your vehicle checked by a dealer.	Adaptive Cruise Control Problem
ACC	with Low Speed Follow (LSF) Indicator (Amber)*	 Comes on if anything covers the radar sensor cover and prevents the sensor from detecting a vehicle in front. May come on when driving in bad weather (rain, snow, fog, etc.) ACC with LSF has been automatically canceled. 	 When the radar sensor gets dirty, stop your vehicle in a safe place, and wipe off dirt using a soft cloth. Have your vehicle checked by a dear if the indicator does not go off even after you clean the sensor cover. 	Some Driver Assist Systems Carnot Operate: Radar Obstructed
		• Comes on when you press the MAIN button.	Adaptive Cruise Control (ACC) with Low Speed Follow (LSF)* P. 416	_
ACC	Adaptive Cruise Control (ACC) with Low Speed Follow (LSF) Indicator (Green)*	 Comes on if the temperature inside the camera is too high. ACC with LSF has been automatically canceled. 	 Use the climate control system to cool down the camera. Goes off - The camera has been cooled down. Pressing the MAIN button can resume the system. ► Front Sensor Camera* P. 414 ► Adaptive Cruise Control (ACC) with Low Speed Follow (LSF)* P. 416 	Sales Phone Asset School Count Counts Count Share-shoot See Ref.

^{*1:}Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

Indicator	Name	On/Blinking	Explanation	Message*
LKAS	Lane Keeping Assist System (LKAS) Indicator (Amber)*	 Comes on for a few seconds when you turn the ignition switch to ON [II]*1, then goes off. Comes on if there is a problem with the LKAS. 	• Stays on constantly - Have your vehicle checked by a dealer.	Lane Keepine Assist Problem
		• Comes on when you press the MAIN button.	D Lane Keeping Assist System (LKAS)* P. 434	_
LKAS	Lane Keeping Assist System (LKAS) Indicator (Green)*	 Comes on if the temperature inside the camera is too high. The LKAS has been automatically canceled. 	 P. 434 Use the climate control system to cool down the camera. Goes off - The camera has been cooled down. Pressing the LKAS button can resume the system. ➡ Front Sensor Camera* P. 414 ➡ Lane Keeping Assist System (LKAS)* P. 434 	
	(Green)	 Comes on when the area around the camera is blocked by dirt, mud, etc. Stop your vehicle in a safe place, and wipe it off with a soft cloth. May come on when driving in bad weather (rain, snow, fog, etc.) 	 Have your vehicle checked by a dealer if the indicator and message come back on after you cleaned the area around the camera. 	Some Diver Assist. Systems Cancel Consuler Chess Front Windsheld

^{*1:}Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

Indicator	Name	On/Blinking	Explanation	Message*
		 Comes on for a few seconds when you turn the ignition switch to ON [II]*1, then goes off. Comes on when you deactivate the CMBSTM. A driver information interface message appears for five seconds. Comes on if there is a problem with the CMBSTM. 	• Stays on constantly without the CMBS™ off - Have your vehicle checked by a dealer. ▶ Collision Mitigation Braking System™ (CMBS™)* P. 459	Collision Milepation Busine Busine System OFF Collision Milepation System Problem
N B Sy	Collision Mitigation Braking System™	• Comes on if the CMBS™ is deactivated temporarily after the battery has been disconnected, then re-connected.	Drive a short distance at more than 12 mph (20 km/h). The indicator should go off. If it does not, have your vehicle checked by a dealer.	Drive Carefully Systems Initializing.
	(CMBS™) Indicator*	system shuts itself off. blocked by vehicle in a a soft cloth	• Stays on - The area around the camera is blocked by dirt, mud, etc. Stop your vehicle in a safe place, and wipe it off with a soft cloth. ▶ Front Sensor Camera* P. 414	Some Down Assis. Systems Cassel Operator Close Foort Windmind
			• Stays on - The temperature inside the camera is too high. Use the climate control system to cool down the camera. The system activates when the temperature inside the camera cools down. ► Front Sensor Camera* P. 414	Sales Street Asset Technic Count Security County Security Technic County Security Technic Security Technic Security

^{*1:}Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

^{*} Not available on all models

Information Display Warning and Information Messages*

The following messages appear only on the information display.

Message	Condition	Explanation
CHECK ← CHRRSE SYSTEM	• Appears when there is a problem with the sensor on the battery.	• Stays on constantly - Have your vehicle checked by a dealer.

Driver Information Interface Warning and Information Messages*

The following messages appear only on the driver information interface. Press the (display/information) button to see the message again with the system message indicator on.

Message	Condition	Explanation
Door And Trunk Open	 Appears if any door or the trunk is not completely closed. Appears if any door or the trunk is opened while driving. The beeper sounds. 	Goes off when all doors and the trunk are closed.
Canadian models	Appears when the washer fluid gets low.	 Refill the washer fluid. ■ Refilling Window Washer Fluid P. 503
Dur Soon A 1 2 2 4 5	 Appears when the scheduled maintenance is due soon. Consequently, Maintenance Due Now and Maintenance Past Due follow. 	
Charging System Problem	• Appears when there is a problem with the sensor on the battery.	 Have your vehicle checked by a dealer. Checking the Battery P. 525
	 Appears along with the battery charging system indicator when the battery is not charging. 	 Turn off the climate control system and rear defogger to reduce electricity consumption. If the Charging System Indicator Comes On P. 552

Message	Condition	Explanation
Continuously variable transmission models Manual transmission models	Appears if the automatic brake hold is automatically canceled while it is in operation.	Immediately depress the brake pedal.
Brake Hold System OFF	• Appears when the automatic brake hold system is turned off.	▶ Automatic Brake Hold P. 454
To Enable Brake Hold: Seat Belt + Push	 Appears when the automatic brake hold button is pressed without wearing the driver's seat belt. 	 Fasten the driver's seat belt. Automatic Brake Hold P. 454
Continuously variable transmission models Manual transmission models	 Appears when the automatic brake hold button is pressed without depressing the brake pedal while the automatic brake hold is in operation. 	 Press the automatic brake hold button with the brake pedal depressed. ▶ Automatic Brake Hold P. 454
Parking Brake Engaged	 Appears when the parking brake is applied automatically while it is in operation. 	▶ Automatic Brake Hold P. 454▶ Parking Brake P. 451

Message	Condition	Explanation
Continuously variable transmission models Manual transmission models	Appears when the electric parking brake switch is pressed without depressing the brake pedal while the electric parking brake is in operation.	• Appears while driving - Press the electric parking brake switch with the brake pedal depressed. ▶ Parking Brake P. 451

Models without smart entry system

Message	Condition	Explanation
(i)-∈ (i) Turn Ignifion Switch To Lock (ii) Position	• Appears when you open the driver's door while the ignition key is in ACCESSORY 1.	• Turn the ignition switch to LOCK 0, then remove the key.
Remove Key From Ignition	 Appears when you open the driver's door while the ignition key is in LOCK 0. 	Remove the key from the ignition switch.

Models with smart entry system

Message	Condition	Explanation
Continuously variable transmission models Manual transmission models	Appears after you set the power mode to ACCESSORY or ON.	₽ Starting the Engine P. 398
Except U.S. models with continuously variable transmission	Appears when the steering wheel is locked.	Move the steering wheel left and right while pressing the ENGINE START/STOP button.

Message	Condition	Explanation
Continuously variable transmission models	• Appears if you push the ENGINE START/STOP button to turn the engine off without the shift lever in P.	 U.S. models Move the shift lever to P. The power mode changes to VEHICLE OFF. Canadian models Move the shift lever to P, then press the ENGINE START/STOP button twice.
⊕ ∰ Accessory Mode	Appears when the power mode is in ACCESSORY.	_
To Switch Vehicle OFF: Push Twice	Appears after the driver's door is opened when the power mode is in ACCESSORY.	• Press the ENGINE START/STOP button twice with your foot off the brake pedal to change the power mode to VEHICLE OFF (LOCK).
RO Keyless Remote Not Detected	Appears when you close the door with the power mode in ON without the smart entry remote inside the vehicle.	 Disappears when you bring the smart entry remote back inside the vehicle and close the door. Smart Entry Remote Reminder P. 154
Keyless Renote Battery Low	Appears when the smart entry remote battery becomes weak.	 Replace the battery as soon as possible. Replacing the Button Battery P. 527

Message	Condition	Explanation
To Start, Hold Remote Mage Start Button	 Appears if the smart entry remote battery is too weak to start the engine or the key is not within operating range to start the engine. A beeper sounds six times. 	 Bring the smart entry remote in front of the ENGINE START/STOP button to be touched with. ☑ If the Smart Entry Remote Battery is Weak P. 544
U.S. Starter System Problem Canada Starter System Problem	Appears when the starter system has a problem.	• As a temporary measure, press and hold the ENGINE START/STOP button for up to 15 seconds while pressing the brake pedal and manually start the engine. Have your vehicle checked by a dealer.
Kerlino Start - d System Problem	 Appears as soon as a problem is detected in the smart entry system or push button starting system. 	 Appears constantly - Have your vehicle checked by a dealer.

Models with LED headlight

Message	Condition	Explanation
Light Control System Problem	 Appears if there is a problem with the light control system. 	 Appears while driving - Manually turn the lights on, and have your vehicle checked by a dealer.
≨D Headlight Problem	Appears if there is a problem with the headlights.	• Appears while driving - The headlights may not be on. When conditions allow you to drive safely, have your vehicle checked by a dealer as soon as possible.

Models with ACC with LSF

Message	Condition	Explanation
ASS LIXAS	 Appears when ACC with LSF has been automatically canceled. 	 You can resume the set speed after the condition that caused ACC with LSF to cancel improves. Press the RES/ + button. Adaptive Cruise Control (ACC) with Low Speed Follow (LSF)* P. 416
Spring Spring Conclusion Volume About	 Appears when the distance between your vehicle and the vehicle ahead of you is too close while ACC with LSF is in operation. 	 ACC with LSF has been automatically canceled. Adaptive Cruise Control (ACC) with Low Speed Follow (LSF)* P. 416
Connect feet Connect To See Connect	 Appears when pressing the –/SET button while the distance between your vehicle and the vehicle ahead of you is too close. 	 ACC with LSF cannot be set. Adaptive Cruise Control (ACC) with Low Speed Follow (LSF)* P. 416
Control Constant Control Contr	 Appears when the driver's seat belt is unfastened while your vehicle is automatically stopped by ACC with LSF. 	 ACC with LSF has been automatically canceled. ■ Adaptive Cruise Control (ACC) with Low Speed Follow (LSF)* P. 416
Commot find Common Common Sout find	 Appears when pressing the –/SET button while the driver's seat belt is unfastened. 	 ◆ ACC with LSF cannot be set. ➡ Adaptive Cruise Control (ACC) with Low Speed Follow (LSF)* P. 416

Models with ACC with LSF

Message	Condition	Explanation
T-R Souther Constraint Control	 Appears when the shift lever is moved into any position other than D or S while ACC with LSF is in operation. 	 ACC with LSF has been automatically canceled. Adaptive Cruise Control (ACC) with Low Speed Follow (LSF)* P. 416
Covered fact Country C	 Appears when pressing the –/SET button while the shift lever is in any position other than D or S. 	 ACC with LSF cannot be set. Adaptive Cruise Control (ACC) with Low Speed Follow (LSF)* P. 416
Contract Con	 Appears when the vehicle is stopped on a very steep slope while ACC with LSF is in operation. 	 ACC with LSF has been automatically canceled. ■ Adaptive Cruise Control (ACC) with Low Speed Follow (LSF)* P. 416
Connot be come to come	 Appears when pressing the –/SET button while the vehicle is stopped on a very steep slope. 	 ACC with LSF cannot be set. Adaptive Cruise Control (ACC) with Low Speed Follow (LSF)* P. 416

* Not available on all models

99

Models with ACC with LSF

Message	Condition	Explanation
Challens Constitute Cons	 Appears when the parking brake is applied automatically while ACC with LSF is in operation. 	 ACC with LSF has been automatically canceled. Adaptive Cruise Control (ACC) with Low Speed Follow (LSF)* P. 416 Parking Brake P. 451
Conno Sel Conno Sel Parana Seria S. Apprint	 Appears when pressing the –/SET button while the parking brake is applied. 	 ACC with LSF cannot be set. Adaptive Cruise Control (ACC) with Low Speed Follow (LSF)* P. 416 Parking Brake P. 451
Continuously variable transmission models	• Appears when pressing the -/SET button while the vehicle is moving and the brake pedal is depressed.	 ACC with LSF cannot be set. Adaptive Cruise Control (ACC) with Low Speed Follow (LSF)* P. 416
TO Contract POR PAGE TRANS	• Appears if ACC with LSF is canceled while your vehicle is automatically stopped by ACC with LSF.	Immediately depress the brake pedal.
BRAKE	Flashes when the system senses a likely collision with a vehicle in front of you.	 Take the appropriate means to prevent a collision (apply the brakes, change lanes, etc.) Collision Mitigation Braking System™ (CMBS™)* P. 459 Adaptive Cruise Control (ACC) with Low Speed Follow (LSF)* P. 416

101

Models with LKAS

Message	Condition	Explanation
	 Lane Keeping Assist System (LKAS) Appears when the vehicle is driving out of a detected line. The steering wheel vibrates rapidly. 	 Keep the vehicle within the lane you are driving. The color of either line changes from white to amber as the vehicle gets closer to that side of the lane line. ▶ Lane Keeping Assist System (LKAS)* P. 434
Line Desirates	Road Departure Mitigation (RDM) System Appears when the vehicle is driving out of a detected lane. When you selected Warning Only The steering wheel vibrates rapidly when the vehicle is drifting out of a detected lane. When you selected Normal or Wide The steering wheel vibrates rapidly when the vehicle is drifting out of a detected line. The system also steers the vehicle to help you remain within your driving lane.	 Keep the vehicle within the lane you are driving. The color of either line changes from white to amber as the vehicle gets closer to that side of the lane line. ▶ Road Departure Mitigation (RDM) System* P. 430 You can change the setting for the road departure mitigation system. Normal, Wide, and Warning Only can be selected. ▶ Customized Features P. 111, 302
Promp heared	• Blinks when you fail to steer the vehicle. The beeper sounds simultaneously.	Operate the steering wheel to resume the LKAS.

Models with remote engine starter

Message	Condition	Explanation
To bed To bed State + Pub	 Appears when you unlock and open the driver's door while the engine is running by one-way smart entry remote. 	▶ Remote Engine Start with Vehicle Feedback* P. 400

Gauges and Displays

Gauges

Gauges include the speedometer, tachometer, fuel gauge, and related indicators. They are displayed when the ignition switch is in ON \overline{II}^{*1} .

Speedometer

Displays your driving speed in mph or km/h.

■ Tachometer

Shows the number of engine revolutions per minute.

■ Fuel Gauge

Displays the amount of fuel left in the fuel tank.

■ Temperature Gauge

Displays the temperature of the engine coolant.

Gauges

Models with information display

Press and hold the km/mile change knob until you hear a beep. The speedometer reading and the displayed measurements switch between mph and km/h.

Models with driver information interface

Press the (display/information) button repeatedly until the icon is shown on the driver information interface. Press **ENTER**, then press and hold it again. The speedometer reading and the displayed measurements will switch between mph and km/h.

∑Fuel Gauge

NOTICE

You should refuel when the reading approaches **E**. Running out of fuel can cause the engine to misfire, damaging the catalytic converter.

The actual amount of remaining fuel may differ from the fuel gauge reading.

∑Temperature Gauge

NOTICE

Driving with the temperature gauge pointer in the upper zone can cause serious engine damage. Pull safely to the side of the road and allow engine temperature to return to normal.

Overheating P. 550

^{*1:} Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

Information Display*

The information display shows the odometer, trip meter, engine oil life and maintenance service item codes, and other gauges.

Switching the Display

Press the ((TRIP) knob to change the display.



Odometer

Shows the total number of miles or kilometers that your vehicle has accumulated.

Trip Meter


Shows the total number of miles or kilometers driven since the last reset. Meters A and B can be used to measure two separate trips.

■ Resetting a trip meter

To reset a trip meter, display it, then press and hold the knob. The trip meter is reset to **0.0**.

Switching the Display

Each time you press the 🙆 knob, the information display changes as follows:



∑Trip Meter

Switch between trip meter A and trip meter B by pressing the 🙆 knob.

Average Fuel Economy

Shows the estimated average fuel economy of each trip meter in mpg or l/100 km. The display is updated at set intervals. When a trip meter is reset, the average fuel economy is also reset.

■ Instant Fuel Economy Gauge

Shows the instant fuel economy as a bar graph in mpg or I/100km.

■ Engine Oil Life

Shows the remaining oil life and Maintenance Minder™.

■ Maintenance Minder[™] P. 479

Range

Shows the estimated distance you can travel on the remaining fuel. This distance is estimated from the fuel economy of your previous trips.

Press and hold the km/mile change knob to switch the measurement.

Continued 105

Outside Temperature

Shows the outside temperature in Fahrenheit (U.S.) or Celsius (Canada).

■ Adjusting the outside temperature indicator

Adjust the temperature reading up to \pm 5°F or \pm 3°C if the temperature reading seems incorrect.

- **1.** Turn the ignition switch to ON III^{*1} .
- **2.** Press and hold the (TRIP) knob for 10 seconds or more while the outside temperature is shown on the information display.
 - ► The information display goes into temperature adjustment mode. The display starts showing from -5°F to +5°F (U.S.) or -3°C to +3°C (Canada).
- **3.** Release the knob when the right adjustment amount is shown.
 - ► The adjustment is complete.

Outside Temperature

The temperature sensor is in the front bumper. Road heat and exhaust from another vehicle can affect the temperature reading when your vehicle speed is less than 19 mph (30 km/h).

It may take several minutes for the display to be updated after the temperature reading has stabilized.

^{*1:} Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

Driver Information Interface*


The driver information interface shows the odometer, trip meter, outside temperature indicator, and other gauges.

It also displays important messages such as warnings and other helpful information.

■ Switching the Display


■ Main displays

Press the (display/information) button and press or to change the display. Press **ENTER** to see detailed information.



■ Trip computer

Press the (TRIP) knob to change the display.



Odometer

Shows the total number of miles or kilometers that your vehicle has accumulated.

■ Trip Meter

Shows the total number of miles or kilometers driven since the last reset. Meters A and B can be used to measure two separate trips.

■ Resetting a trip meter

To reset a trip meter, display it, then press and hold the knob. The trip meter is reset to **0.0**.

∑Trip Meter

Switch between trip meter A and trip meter B by pressing the A knob, or by using the customized features on the driver information interface.

Customized Features P. 111

Average Fuel Economy

Shows the estimated average fuel economy of each trip meter in mpg or l/100 km. The display is updated at set intervals. When a trip meter is reset, the average fuel economy is also reset.

Range

Shows the estimated distance you can travel on the remaining fuel. This distance is estimated from the fuel economy of your previous trips.

■ Elapsed Time

Shows the time elapsed since Trip A or Trip B was reset.

Average Speed

Shows the average speed in mph or km/h since Trip A or Trip B was reset.

■ Engine Oil Life

Shows the remaining oil life and Maintenance Minder™.

Maintenance Minder™ P. 479

■ Average Fuel Economy

You can change when to reset the average fuel economy.

Customized Features P. 111

Outside Temperature

Shows the outside temperature in Fahrenheit (U.S.) or Celsius (Canada).

■ Adjusting the outside temperature display

Adjust the temperature reading up to $\pm 5^{\circ} F$ or $\pm 3^{\circ} C$ if the temperature reading seems incorrect.


Use the driver information interface's customized features to correct the temperature.

Customized Features P. 111

Instant Fuel Economy

Shows the instant fuel economy as a bar graph in mpg or I/100 km.

■ Turbo Meter*



When the turbo charger is activated, this meter shows the boost pressure.

≥Outside Temperature

The temperature sensor is in the front bumper. Road heat and exhaust from another vehicle can affect the temperature reading when your vehicle speed is less than 19 mph (30 km/h).

It may take several minutes for the display to be updated after the temperature reading has stabilized.

∑Turn-by-Turn Directions*

You can select whether the turn-by-turn display comes on during the route guidance.

≧ Customized Features P. 111

■ Turn-by-Turn Directions*

Shows you turn-by-turn driving directions to your destination linked with the navigation system.

Refer to the Navigation System Manual

* Not available on all models


Models with color audio system

Customized Features

Use the driver information interface to customize certain features.

■ How to customize

Select the **Vehicle Settings** screen by pressing the $\[\]$ button while the ignition switch is in ON $\[\]$ in $\[\]$ and the vehicle is at a complete stop. Select **Vehicle Settings**, then press the **ENTER** button.





 $[\]star$ 1: Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

○ Customized Features

To customize other features, press the ▲ / ▼ button.

- List of customizable options P. 114
- **Example of customization settings** P. 118





■ List of customizable options

Setup Group	Customizable Features	Description	Selectable Settings
TPMS Calibration*	-	Calibrates the TPMS.	Cancel/Calibrate
Clock Setup	Adjust Clock	Adjusts clock. Discrete Clock P. 122	_
	Clock Display	Selects the digital clock display from 12H to 24H.	24h/12h*1/OFF
	Forward Collision Warning Distance	Changes at which distance the CMBS™ alerts.	Long/Normal*1/Short
Driver Assist	ACC Forward Vehicle Detect Beep	Causes the system to beep when the system detects a vehicle, or when the vehicle goes out of ACC range.	ON/OFF*1
System Setup	Road Departure Mitigation Setting	Changes the setting for the road departure mitigation system.	Normal*1/Wide/Warning Only
	Lane Keeping Assist Suspend Beep	Causes the system to beep when the LKAS is suspended.	ON/OFF*1

^{*1:}Default Setting

Setup Group	Customizable Features	Description	Selectable Settings
	Language Selection	Changes the displayed language.	English*1/French/Spanish
	Adjust Outside Temp. Display	Adjusts the temperature reading by a few degrees.	-5°F ~ ±0°F*1 ~ +5°F (U.S.) -3°C ~ ±0°C*1 ~ +3°C (Canada)
	"Trip A" Reset Timing	Changes the setting of how to reset trip meter A, average fuel economy A, average speed A, and elapsed time A.	When Refueled/IGN Off/ Manually Reset*1
Meter Setup	"Trip B" Reset Timing	Changes the setting of how to reset trip meter B, average fuel economy B, average speed B, and elapsed time B.	When Refueled/IGN Off/ Manually Reset*1
	Adjust Alarm Volume	Changes the alarm volume, such as buzzers, warnings, turn signal sound, and so on.	High/Mid*1/Low
	Fuel Efficiency Backlight	Turns the ambient meter feature on and off.	On*1/Off
	Speed/Distance Units	Selects the trip computer units.	mph·miles*1/km/h·km (U.S.) mph·miles/km/h·km*1 (Canada)
	Tachometer	Selects whether the tachometer come on the driver information interface.	On*1/Off

^{*1:}Default Setting

Setup Group	Customizable Features	Description	Selectable Settings
	Interior Light Dimming Time	Changes the length of time the interior lights stay on after you close the doors.	60sec/30sec*1/15sec
	Headlight Auto OFF Timer	Changes the length of time the exterior lights stay on after you close the driver's door.	60sec/30sec/15sec*1/0sec
Lighting	Auto Light Sensitivity	Changes the timing for the headlights to come on.	Max/High/Mid*1/Low/Min
Setup	Auto Interior Illumination Sensitivity	Changes the sensitivity of the brightness of the instrument panel when the headlight switch is in the AUTO position.	Max/High/Mid* ¹ /Low/Min
	Auto Headlight ON With Wiper ON	Changes the settings for the wiper operation when the headlights automatically come on while the headlight switch is in the AUTO position.	ON/OFF*1


^{*1:} Default Setting

Setup Group	Customizable Features	Description	Selectable Settings
	Auto Door Lock	Changes the setting for when the doors automatically lock.	With Vehicle Speed*1/Shift from P/OFF
	Auto Door Unlock	Changes the setting for when the doors automatically unlock.	When Driver's Door Opens*1/ When Shifting Into Park/ When Ignition Switched OFF/OFF
Door Setup	Key And Remote Unlock Mode	Sets up either the driver's door or all doors to unlock on the first operation of the remote or built-in key.	Driver Door*1/ All Doors
	Keyless Lock Answer Back	LOCK/UNLOCK- The exterior lights flash. LOCK (2nd push)- The beeper sounds.	ON*1/OFF
	Security Relock Timer	Changes the time it takes for the doors to relock and the security system to set after you unlock the vehicle without opening any door.	90sec/60sec/30sec*1
Maintenance Reset	_	Resets/Cancels the engine oil life display when you have performed the maintenance service.	Cancel/Reset
Default All	_	Cancels/Resets all the customized settings as default.	Cancel/Set

^{*1:} Default Setting

■ Example of customization settings

The steps for changing the **"Trip A" Reset Timing** setting to **When Refueled** are shown below. The default setting for **"Trip A" Reset Timing** is **Manually Reset**.



1. Press the button to select Vehicle Settings, then press the ENTER button.



- 2. Press the ▲ / ▼ button until **Meter Setup** appears on the display.
- **3.** Press the **ENTER** button.
 - ► Language Selection appears first in the display.



- **4.** Press the ▲ / ▼ button until **"Trip A" Reset Timing** appears on the display, then press the **ENTER** button.
 - ➤ The display switches to the customization setup screen, where you can select When Refueled, IGN Off, Manually Reset, or Exit.



- **5.** Press the ▲ / ▼ button and select **When Refueled**, then press the **ENTER** button.
 - ➤ The When Refueled Setup screen appears, then the display returns to the customization menu screen.



- **6.** Press the ▲ / ▼ button until **Exit** appears on the display, then press the **ENTER** button.
- **7.** Repeat Step 6 until you return to the normal screen.

Controls

This chapter explains how to operate the various controls necessary for driving.

Clock	122
Locking and Unlocking the Doors	
Key Types and Functions	124
Low Smart Entry Remote Signal Strength*	126
Locking/Unlocking the Doors from t	
Outside	
Locking/Unlocking the Doors from t	
Inside	
Childproof Door Locks	136
Auto Door Locking/Unlocking	13/
Opening and Closing the Trunk	141
Security System	
Immobilizer System	
Security System Alarm	
Opening and Closing the Windows	
Opening and Closing the Moonroof*	150

Operating the Switches Around the Steering Wheel	
Ignition Switch * ENGINE START/STOP Button * Ignition Switch and Power Mode	151 152
Comparison Turn Signals	155 156 156
Fog Lights* Daytime Running Lights	159 159
Brightness Control Rear Defogger/Heated Door Mirror*	
ButtonAdjusting the Steering Wheel	

Adjusting the Mirrors	
Interior Rearview Mirror	165
Power Door Mirrors	
Adjusting the Seats	
nterior Lights/Interior Convenience	•
Items	175
leating System*	
Using Automatic Heating	187
Automatic Heating Sensors	189
Climate Control System*	
Using Automatic Climate Control	190
Synchronized Mode *	195
Automatic Climate Control Sensors	.196

* Not available on all models

Adjusting the Clock

Models without navigation system

You can adjust the time in the clock display with the ignition switch in ON III *1.

Adjusting the Time



Models with color audio system

■ Using the MENU/CLOCK button

- Press and hold the MENU/CLOCK button.
 Adjust Clock is selected.
- **2.** Rotate ♥ to change hour, then press ८.
- **3.** Rotate ♥ to change minute, then press В.
- **4.** To enter the selection, rotate 🗇 and select **Set**, then press 🕹.

■ Adjusting the Clock

Models with Display Audio

The clock is automatically updated through the audio system, so the time does not need to be adjusted.

Models with driver information interface

You can customize the clock display to show the 12 hour clock or 24 hour clock.

Customized Features P. 111

Models with Display Audio

Models with information display

You cannot adjust the time while the vehicle is moving.

≥Using the MENU/CLOCK button

Models with color audio system

These indications are used to show how to operate the **LIST/SELECT** (List/Selector) knob.

Rotate 🗇 to select.

Press 🕹 to enter.

^{*1:} Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.



Models with Display Audio

- Using the Settings menu on the audio/ information screen
- 1. Select Settings.
- 2. Select Clock.
- 3. Select Clock Adjustment.
- **4.** Select **△** or **▼** to change hour.
- **5.** Select **△** or **▼** to change minute, then select **OK**.

■ Using the Settings menu on the audio/information screen

Models with Display Audio

You can customize the clock display to show the 12 hour clock or 24 hour clock.

Customized Features P. 302

The clock display is set to off by factory default. You can turn the clock display on and off.

Customized Features P. 302

The clock is automatically updated when your smartphone is connected to the audio system. You can also adjust the clock by touching the clock displayed on the upper right corner of the display.


- 1. Touch the clock on the display for a few seconds.
- 2. Select Clock Adjustment.
- 3. Select ▲ or ▼ to change hour.
- 4. Select ▲ or ▼ to change minute, then select OK.

Locking and Unlocking the Doors

Key Types and Functions


This vehicle comes with the following keys:

Keys



Use the key to start and stop the engine, to lock and unlock the doors and to open the trunk. You can also use the remote transmitter or smart entry system* to lock and unlock the doors and to open the trunk.

■ Smart entry remote*



The built-in key can be used to lock/unlock the doors when the smart entry remote battery becomes weak and the power door lock/unlock operation is disabled.

To remove the built-in key, pull it out while sliding the release knob. To reinstall the built-in key, push the built-in key into the smart entry remote until it clicks.

■ Key Types and Functions

All the keys have an immobilizer system. The immobilizer system helps to protect against vehicle theft.

Immobilizer System P. 144

The keys contain precision electronics.

Adhere to the following advice to prevent damage to the electronics:

- Do not leave the keys in direct sunlight, or in locations with high temperature or high humidity.
- Do not drop the keys or set heavy objects on them.
- Keep the keys away from liquids.
- Do not take the keys apart except for replacing the battery.

If the circuits in the keys are damaged, the engine may not start, and the remote transmitter may not work.

If the keys do not work properly, have them inspected by a dealer.

Models with remote engine starter

You can remotely start the engine using the one-way smart entry remote.

Remote Engine Start with Vehicle Feedback* P. 400

■ Key Number Tag



Contains a number that you will need if you purchase a replacement key.

Keep the key number tag separate from the key in a safe place outside of your vehicle.

If you wish to purchase an additional key, contact a dealer.

If you lose your key and you cannot start the engine, contact a dealer.

Low Smart Entry Remote Signal Strength*

The vehicle transmits radio waves to locate the smart entry remote when locking/unlocking the doors, opening the trunk, or to start the engine.

In the following cases, locking/unlocking the doors, opening the trunk, or starting the engine may be inhibited or operation may be unstable:

- Strong radio waves are being transmitted by nearby equipment.
- You are carrying the smart entry remote together with telecommunications equipment, laptop computers, cell phones, or wireless devices.
- A metallic object is touching or covering the smart entry remote.

∑Low Smart Entry Remote Signal Strength *


Communication between the smart entry remote and the vehicle consumes the smart entry remote's battery.

Battery life is about two years, but this varies depending on regularity of use.

The battery is consumed whenever the smart entry remote is receiving strong radio waves. Avoid placing it near electrical appliances such as televisions and personal computers.


Locking/Unlocking the Doors from the Outside

Using the Smart Entry with Push Button Start System*



When you carry the smart entry remote, you can lock/unlock the doors and open the trunk. You can lock/unlock the doors within a radius of about 32 inches (80 cm) of the outside door handle. You can open the trunk within about 32 inches (80 cm) radius from the trunk release button.

■ Locking the vehicle



Press the door lock button on the front door.

Some exterior lights flash; the beeper sounds; all the doors lock; and the security system sets. ■Using the Smart Entry with Push Button Start System *

- Do not leave the smart entry remote in the vehicle when you get out. Carry it with you.
- Even if you are not carrying the smart entry remote, you can lock/unlock the doors while someone else with the remote is within range.
- The door may be unlocked if the door handle is covered with water in heavy rain or in a car wash if the smart entry remote is within range.
- If you grip a front door handle wearing gloves, the door sensor may be slow to respond or may not respond by unlocking the doors.
- You cannot unlock the door by gripping the handle after two seconds of locking it.
- The door may not open if you pull it immediately after gripping the door handle. Grip the handle again and confirm that the door is unlocked before pulling the handle.
- Even within the 32 inches (80 cm) radius, you may not be able to lock/unlock the doors with the smart entry remote if it is above or below the outside handle.
- The smart entry remote may not operate if it is too close to the door and door glass.


If the distance at which it works varies, the battery is probably low.


If the LED does not come on when you press a button, the battery is dead.

Replacing the Button Battery P. 527

You can customize the door lock mode and keyless lock acknowledgement setting.

⊇ Customized Features P. 302





■ Locking the vehicle (Walk away auto lock)

When you walk away from the vehicle while carrying the smart entry remote, the doors will automatically lock.

The auto lock function activates when all doors are closed, and the smart entry remote is within about 6 feet (2 m) radius of the outside door handle.

- **1.** Exit vehicle while carrying smart entry remote and close door(s).
- **2.** While within about 6 feet (2 m) radius of the vehicle.
 - ► The beeper sounds; the auto lock function will be activated
- **3.** Carry the smart entry remote beyond about 6 feet (2 m) from the vehicle and remain outside this range for 2 or more seconds.
 - Some exterior lights flash; the beeper sounds; all doors will then lock.

∑Locking the vehicle (Walk away auto lock)

The auto lock function is set to OFF as the factory default setting. The auto lock function can be set to ON using the audio/information screen.

Customized Features P. 302

After the auto lock function has been activated, when you stay within the locking/unlocking operation range, the indicator on the smart entry remote will continue to flash until the doors are locked.

When you stay beside the vehicle within the operation range, the doors will automatically lock approximately 30 seconds after the auto lock function activating beeper sounds.

When you open a door after the auto lock function activating beeper sounds, the auto lock function will be canceled.

When all doors have been closed and the smart entry remote is inside the vehicle, or if the smart entry remote is not detected within about 6 feet (2 m) of the vehicle, auto lock function will not be activated.

To temporarily deactivate the function:

- 1. Set the power mode to OFF.
- 2. Open the driver's door.
- **3.** Using the master door lock switch, operate the lock as follows:

 $\mathsf{Lock} \to \mathsf{Unlock} \to \mathsf{Lock} \to \mathsf{Unlock}.$

► The beeper sounds and the function is deactivated.

To restore the function:

- Set the power mode to ON.
- Lock the vehicle without using the auto lock function
- Walk away at least more than about 6 feet (2 m) away from the vehicle while carrying the smart entry remote.

∑Locking the vehicle (Walk away auto lock)

The auto lock function does not operate when any of the following conditions are met.

- The smart entry remote is inside the vehicle.
- A door or the hood is not closed.
- The power mode is set to any mode other than OFF.
- The smart entry remote is not located within a radius of about 6 feet (2 m) from the vehicle when you get out of the vehicle and close the doors.

The auto lock function will make the warning in the following cases.

The warning buzzer will sound to make sure the walk away auto lock is not activated.


• The auto lock function is deactivated.

Auto lock function operation stop beeper

After the auto lock function has been activated, the auto lock operation stop beeper sounds for approximately two seconds in the following cases.

- The smart entry remote is put inside the vehicle through a window.
- You are located too close to the vehicle.
- The smart entry remote is put inside the trunk. If the warning beeper sounds, check that you are carrying the smart entry remote. Then, open/close a door and confirm the auto lock activation beeper sounds once.

■ Unlocking the vehicle





Grab the driver's door handle:

- ► The driver's door unlocks.
- Some exterior lights flash twice and the beeper sounds twice.

Grab the front passenger's door handle:

- ► All the doors unlock.
- Some exterior lights flash twice and the beeper sounds twice.

Press the trunk release button:

- ► The trunk unlocks and opens.
- Some exterior lights flash and the beeper sounds.
- Using the Trunk Release Button P. 141


■Using the Smart Entry with Push Button Start System*

If you do not open a door within 30 seconds of unlocking the vehicle, the doors will automatically relock.

The light flash, beep, and unlock settings can be customized.

■ Customized Features P. 302

Using the Remote Transmitter



■ Locking the doors

Press the lock button.

Once:

Some exterior lights flash, all the doors lock, and the security system sets.

Twice (within five seconds after the first push):

► The beeper sounds and verifies the security system is set.

If you do not open a door within 30 seconds of unlocking the vehicle with the remote transmitter, the doors will automatically relock.

You can change the relock timer setting.

Customized Features P. 111

If the interior light switch is in the door activated position, the interior lights come on when you press the unlock button.

No doors opened: The lights fade out after 30 seconds.

Doors relocked with the remote: The lights go off immediately.

Interior Lights P. 175

Models without smart entry system

The remote transmitter uses low-power signals, so the operating range may vary depending on the surroundings.

Models with smart entry system

You can lock or unlock doors using the remote transmitter or smart entry system only when the power mode is in VEHICLE OFF.

All models

The remote will not lock the vehicle when a door is open.

■ Unlocking the doors

Press the unlock button.

Once:

► Some exterior lights flash twice, and the driver's door unlocks.

Twice:

► The remaining doors unlock.

■Using the Remote Transmitter

If the distance at which the remote transmitter works varies, the battery is probably low.

If the LED does not come on when you press a button, the battery is dead.

Replacing the Button Battery P. 527

You can customize the door unlock mode setting.

■ Customized Features P. 111

■ Locking/Unlocking the Doors Using a Key



Fully insert the key and turn it.

■ Locking/Unlocking the Doors Using a Key


When you lock the driver's door with a key, all the other doors lock at the same time. When unlocking, the driver's door unlocks first. Turn the key a second time within a few seconds to unlock the remaining doors.

Models with driver information interface

You can customize the door unlock mode setting.

Customized Features P. 111

■ Locking a Door Without Using a Key



■ Locking the driver's door

Push the lock tab forward ① or push the master door lock switch in the lock direction

- 2, and close the door.
 - ➤ The doors cannot be locked when the key is in the ignition switch*1, or the smart entry remote is inside the vehicle.

■ Locking the passenger's doors

Push the lock tab forward and close the door.


∑Locking a Door Without Using a Key

When you lock the driver's door, all the other doors lock at the same time.

Make sure you have the key in your hand before locking the door to prevent it from being locked in the vehicle.

Locking/Unlocking the Doors from the Inside

■ Using the Lock Tab



■ Locking a door

Push the lock tab forward.

■ Unlocking a door


Pull the lock tab rearward.

≥Using the Lock Tab

When you lock the door using the lock tab on the driver's door, all of the other doors lock at the same time.

When you unlock the door using the lock tab on the driver's door, only the driver's door will unlock.

Unlocking Using the Front Door Inner Handle



Pull the front door inner handle.

► The door unlocks and opens in one motion.

Unlocking and opening the driver's door from the inner handle unlocks all the other doors

To avoid all the doors to be unlocked, use the lock tab on the driver's door to unlock, then lock again before opening the door.

This setting works for one time only.

Models with driver information interface

If you do not want all the doors to be unlocked all the time, customize the **Auto Door Unlock** setting to **Off** using the driver information interface.

Customized Features P. 111

Models without driver information interface

If you do not want all the doors to be unlocked all the time, customize the auto door unlocking setting to off using the master door lock switch.

■ Customizing Flow for Auto Door Unlocking Options P. 140


■Unlocking Using the Front Door Inner Handle

The front door inner handles are designed to allow front seat occupants to open the door in one motion. However, this feature requires that front seat occupants never pull a front door inner handle while the vehicle is in motion.

Children should always ride in a rear seat where childproof door locks are provided.

⊇ Childproof Door Locks P. 136

Using the Master Door Lock Switch



Press the master door lock switch in as shown to lock or unlock all doors.


∑Using the Master Door Lock Switch

When you lock/unlock either of the front doors using the master lock switch, all the other doors lock/ unlock at the same time.

Childproof Door Locks

The childproof door locks prevent the rear doors from being opened from the inside regardless of the position of the lock tab.

■ Setting the Childproof Door Locks



Slide the lever in the rear door to the lock position, and close the door.

■ When opening the door

Open the door using the outside door handle.

∑Childproof Door Locks

To open the door from the inside when the childproof door lock is on, put the lock tab in the unlock position, lower the rear window, put your hand out of the window, and pull the outside door handle.

Auto Door Locking/Unlocking

Your vehicle locks and unlocks all doors automatically when a certain condition is met.

Auto Door Locking

■ Drive lock mode

All doors lock when the vehicle's speed reaches about 10 mph (15 km/h).

Auto Door Unlocking

■ Driver's door open mode

All doors unlock when the driver's door is opened.

Models without driver information interface

You can turn off or change to another auto door locking/unlocking setting using the master door lock switch.

■ Customizing the Auto Door Locking/ Unlocking Setting P. 138

Models with driver information interface

You can turn off or change to another auto door locking/unlocking setting using the driver information interface.

Customized Features P. 111

Customizing the Auto Door Locking/Unlocking Setting

You can customize the auto door locking/unlocking setting to your liking using the master door lock switch.

■ List of the Auto Door Locking/Unlocking Customizable Options

■ Auto door locking

Mode	Description
Drive Lock Mode*2	All doors lock when the vehicle's speed reaches about 10 mph (15 km/h).
Off	The auto door locking is deactivated all the time.

■ Auto door unlocking

Mode	Description
Driver's Door Open Mode*2	All doors unlock when the driver's door is opened.
Models with continuously variable transmission Park Unlock Mode	All doors unlock when the shift lever is moved into P with the brake pedal depressed.
Off	The auto door unlocking is deactivated all the time.

^{*1:}Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

^{*2:}Default setting

■ Customizing Flow for Auto Door Locking Options

Steps	Drive Lock Mode*2	Off
	Apply the parking brake.	Apply the parking brake.
1	Models with continuously variable transmission Move the shift lever out of $\boxed{\mathbf{P}}$.	Models with continuously variable transmission Move the shift lever to $\boxed{\mathbf{P}}$.
2	Close the driver's door.	Open the driver's door.
3	Turn the ignition switch to ON \boxed{II}^{*1} .	Turn the ignition switch to ON $\overline{\mathrm{II}}^{*1}$.
4	Press and hold the right side of the master door lock switch on the driver's door for more than five seconds. Release the switch after you hear a click twice.	Press and hold the right side of the master door lock switch on the driver's door for more than five seconds. Release the switch after you hear one click.
	Turn the ignition switch to ACCESSORY 1 *1 within 20 seconds	

Turn the ignition switch to ACCESSORY 1 within 20 seconds.

► Customization is completed.

^{*1:}Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

^{*2:}Default setting

■ Customizing Flow for Auto Door Unlocking Options

Steps	Driver's Door Open Mode*2	Models with continuously variable transmission Park Unlock Mode	Off
1	Apply the parking brake. Models with continuously variable transmission Move the shift lever out of P.	Apply the parking brake. Move the shift lever to $\boxed{\mathbf{P}}$.	Apply the parking brake. Models with continuously variable transmission Move the shift lever to P.
2	Close the driver's door.		Open the driver's door.
3	Turn the ignition switch to ON \boxed{II}^{*1} .		Turn the ignition switch to ON \boxed{II}^{*1} .
4	Press and hold the left side of the master door after you hear a click twice.	lock switch on the driver's door for more than	five seconds. Release the switch

Turn the ignition switch to ACCESSORY | 1 *1 within 20 seconds.

Customization is completed.

^{*1:}Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

^{*2:}Default setting

Opening and Closing the Trunk

Precautions for Opening/Closing the Trunk

■ Opening the trunk

Open the trunk all the way.

▶ If it is not fully opened, the trunk lid may begin to close under its own weight.

■ Closing the trunk

Keep the trunk lid closed while driving to:


- Avoid possible damage.
- ▶ Prevent exhaust gas from leaking into the vehicle.
- Exhaust Gas Hazard P. 70

Using the Trunk Release Button



Pressing the trunk release button on the driver's door

When You Cannot Open the Trunk P. 564



Models with smart entry system


Push up the release button on the trunk lid after the doors are unlocked.

▶ When You Cannot Open the Trunk P. 564

Even if the trunk is locked, you can open the trunk if you carry the smart entry remote.

Some exterior lights flash and the beeper sounds.

Using the Remote Transmitter




Press the trunk release button for approximately one second to unlock and open the trunk

Substitute Street Str

Models with smart entry system

- Do not leave the smart entry remote in the vehicle when you get out. Carry it with you.
- A person who is not carrying the smart entry remote can unlock the trunk if a person who is carrying it is within range.
- Do not leave the smart entry remote inside the trunk and close the lid. The beeper sounds and the trunk cannot be closed.
- Do not carry the smart entry remote near the trunk lid when closing it.
- Do not place the smart entry remote around the rear seat when closing the trunk.

Emergency Trunk Opener



The trunk release lever allows you to open the trunk from inside for your safety.

Slide the release lever in the direction of the arrow.

Parents should decide if their children should be shown how to use this feature.

Security System

Immobilizer System

The immobilizer system prevents a key that has not been pre-registered from starting the engine. Each key contains electronic transmitters that use electronic signals to verify the key.

Pay attention to the following when inserting the key into the ignition switch or pressing the **ENGINE START/STOP** button:

- Do not allow objects that emit strong radio waves near the ignition switch or the ENGINE START/STOP button.
- Make sure the key is not covered by or touching a metal object.
- Do not bring a key from another vehicle's immobilizer system near the ignition switch or the ENGINE START/STOP button.
- Do not put the key near magnetic items. Electronic devices, such as a television set and audio system are strongly magnetic, or a key chain can become magnetic, too.

Security System Alarm

The security system alarm activates when the trunk, hood or doors are forcibly opened. The alarm does not go off if the trunk or doors are opened with the key, remote transmitter or smart entry system.

However, the alarm goes off when a door is opened with the key, then the shift lever is moved out of $\boxed{\mathbf{P}}$ (continuously variable transmission models) or the hood is opened before the ignition switch is turned to ON $\boxed{\mathbf{II}}^{*1}$.

■ When the security system alarm activates

The horn sounds intermittently and all the exterior lights flash.

■ To deactivate the security system alarm

Unlock the vehicle using remote transmitter, or smart entry system. The system, along with the horn and flashing lights, is deactivated.

*1: Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

NOTICE

Leaving the key in the vehicle can result in theft or accidental movement of the vehicle.

Always take the key with you whenever you leave the vehicle unattended.

Do not alter the system or add other devices to it. Doing so may damage the system and make your vehicle inoperable.

Canadian models only: Apply and hold the brake pedal before turning the vehicle on the first time after the battery has been disconnected.

Security System Alarm

The security alarm continues for a maximum of two minutes until the security system deactivates.

■ Setting the security system alarm

The security system alarm automatically sets when the following conditions have been met:

- The ignition switch is in LOCK [0]*1, and the key has been removed from the ignition switch.
- The hood and trunk are closed.
- All doors are locked with the key, the remote transmitter, or smart entry system.

■ When the security system alarm sets

The security system alarm indicator in the instrument panel blinks. When the blinking interval changes after about 15 seconds, the security system alarm is set.

■ To cancel the security system alarm

The security system is canceled when the vehicle is unlocked using the remote transmitter, smart entry system, or the ignition switch is turned to ON \boxed{II}^{*1} . The security system indicator goes off at the same time.

Security System Alarm

Do not set the security system alarm when someone is in the vehicle or a window is open. The system can accidentally activate when:

- Unlocking the door with the lock tab.
- Opening the trunk with the trunk release button on the driver's door or the emergency trunk opener.
- Opening the hood with the hood release.

Continuously variable transmission models

• Moving the shift lever out of P.

If the battery goes dead after you have set the security system alarm, the security alarm may go off once the battery is recharged or replaced.


If this occurs, deactivate the security system alarm by unlocking a door using the remote transmitter.

Do not attempt to alter this system or add another device to it.

Continued 145

^{*1:} Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

Panic Mode



■ The panic button on the remote transmitter

If you press the panic button for approximately one second, the following will occur for about 30 seconds:

- The horn sounds.
- Some exterior lights flash.

■ Canceling panic mode

Press any button on the remote transmitter, or turn the ignition switch to ON II^{*1}.

^{*1:} Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

Opening and Closing the Windows


Opening/Closing the Power Windows

The power windows can be opened and closed when the ignition switch is in ON \boxed{II}^{*1} , using the switches on the doors. The driver's side switches can be used to open and close all of the windows.

The power window lock button on the driver's side must be switched off (indicator off) to open and close the windows from anywhere other than the driver's seat.

When the power window lock button is pressed, the indicator comes on and you can only operate the driver's window. Turn the power window lock button on when children are in the vehicle

■ Opening/Closing Windows with Auto-Open/Close Function



■ Automatic operation

To open: Push the switch down firmly. **To close:** Pull the switch up firmly.

The window opens or closes completely. To stop the window at any time, push or pull the switch briefly.

■ Manual operation

To open: Push the switch down lightly, and hold it until the desired position is reached. **To close:** Pull the switch up lightly, and hold it until the desired position is reached.

*1: Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

∑Opening/Closing the Power Windows

AWARNING

Closing a power window on someone's hands or fingers can cause serious injury.

Make sure your passengers are away from the windows before closing them.

The power windows can be operated for up to 10 minutes after you turn the ignition switch off. Opening either front door cancels this function.

Auto Reverse


If a power window senses resistance when closing automatically, it will stops closing and reverse direction.

The driver's window auto reverse function is disabled when you continuously pull up the switch.

The auto reverse function stops sensing when the window is almost closed to ensure that it fully closes.

Continued 147

Opening/Closing Windows without Auto-Open/Close Function



To open: Push the switch down. **To close:** Pull the switch up.

Release the switch when the window reaches the desired position.

■ Opening Windows and Moonroof* with the Remote



To open: Press the unlock button twice within 10 seconds and hold it down for the second time. If the windows stop midway, repeat the procedure.

■ Opening/Closing the Windows and Moonroof* with the Key



To open: Unlock the driver's door with the key. Within 10 seconds of returning the key to the central position, turn the key in the unlock direction and hold it there.


To close: Lock the driver's door with the key. Within 10 seconds of returning the key to the central position, turn the key in the lock direction and hold it there.

Release the key to stop the windows/ moonroof at the desired position. If you want further adjustment, repeat the same operation.

* Not available on all models

Opening/Closing the Moonroof

You can only operate the moonroof when the ignition switch is in ON \overline{II} ^{*1}. Use the switch in the front of the ceiling to open and close the moonroof.



■ Automatic operation

To open: Pull the switch back firmly. **To close:** Push the switch forward firmly.

The moonroof will automatically open or close all the way. To stop the moonroof midway, touch the switch briefly.

■ Manual operation

To open: Pull the switch back lightly, and hold it until the desired position is reached. **To close:** Push the switch forward lightly, and hold it until the desired position is reached.

■ Tilting the moonroof up

To tilt: Push on the center of the moonroof switch.

To close: Push the switch forward firmly, then release.

∑Opening/Closing the Moonroof

AWARNING

Opening or closing the moonroof on someone's hands or fingers can cause serious injury.

Make sure all hands and fingers are clear of the moonroof before opening or closing it.

NOTICE

Opening the moonroof in below freezing temperature or when it is covered with snow or ice can damage the moonroof panel or motor.

The power moonroof can be operated for up to 10 minutes after you turn the ignition switch off. Opening either front door cancels this function.

When resistance is detected, the auto reverse function causes the moonroof to change directions, then stop. Auto reverse stops sensing when the moonroof is almost closed to ensure that it fully closes. Make sure that all objects, including fingers, are clear of the moonroof.

You can use the remote transmitter or the key to operate the moonroof.


- **②** Opening Windows and Moonroof* with the Remote P. 148
- Opening/Closing the Windows and Moonroof* with the Key P. 149

^{*1:} Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

^{*} Not available on all models

Operating the Switches Around the Steering Wheel

Ignition Switch*



- O LOCK: Insert and remove the key in this position.
- I ACCESSORY: Operate the audio system and other accessories in this position.
- III ON: This is the position when driving.
- [III] START: This position is for starting the engine. The switch returns to ON [II] when you let go of the key.

■ Ignition Switch *

Manual transmission models

AWARNING

Removing the key from the ignition switch while driving locks the steering. This can cause you to lose control of the vehicle.

Remove the key from the ignition switch only when parked.

Continuously variable transmission models

You cannot take the key out unless the shift lever is in \boxed{P} .

All models

If you open the driver's door when the key is in LOCK $\boxed{0}$ or ACCESSORY $\boxed{1}$, a warning buzzer will sound to remind you to take the key out.

When this happens, the following messages appear on the driver information interface*:


- In LOCK 0: Remove Key From Ignition.
- In ACCESSORY : Turn Ignition Switch To Lock (0) Position. The buzzer will stop when you take the key out.

If the key won't turn from LOCK ① to ACCESSORY ①, turn the key while moving the steering wheel left and right. The steering wheel will unlock, allowing the key to turn.

* Not available on all models 151

ENGINE START/STOP Button*

Changing the Power Mode




- *1: Except U.S. models with continuously variable transmission
- *2: U.S. models

* Not available on all models

■ ENGINE START/STOP Button *

ENGINE START/STOP Button Operating Range



You can start the engine when the smart entry remote is inside the vehicle.

The engine may also run if the smart entry remote is close to the door or window, even if it is outside the vehicle.

ON mode:

Indicator in the button is off, if the engine is running.

If the smart entry remote battery is weak, beeper sounds and the **To Start, Hold Remote Near Start Button** message appears on the driver information interface*.

▶ If the Smart Entry Remote Battery is Weak P. 544

Do not leave the power mode in ACCESSORY or ON when you get out.

Automatic Power Off

If you leave the vehicle for 30 to 60 minutes with the shift lever in $[P]^{*1}$ and the power mode in ACCESSORY, the vehicle automatically goes into the mode similar to VEHICLE OFF (LOCK) to avoid draining the battery.

When in this mode:

Except U.S. continuously variable transmission models

The steering wheel does not lock.

All models

You cannot lock or unlock doors with the remote transmitter or the smart entry system.

Press the **ENGINE START/STOP** button twice to switch the mode to VEHICLE OFF (LOCK).

∑Changing the Power Mode


Except U.S. continuously variable transmission models If the power mode does not change from VEHICLE OFF to ACCESSORY, press the **ENGINE START/STOP** button while moving the steering wheel left and right. The steering wheel will unlock, allowing the mode to change.

^{*1:} Continuously variable transmission models

Power Mode Reminder

If you open the driver's door when the power mode is set to ACCESSORY, a warning beep sounds.

Smart Entry Remote Reminder



Warning buzzers may sound from inside and/ or outside the vehicle to remind you that the smart entry remote is out of the vehicle. If the buzzer continues even after the remote is put back inside, place it within the system's operational range.

■ When the power mode is in ON

If the smart entry remote is taken out of the vehicle, and the driver's door is closed, warning buzzers sound from both inside and outside the vehicle. A warning message on the driver information interface notifies the driver inside that the remote is out.

■ When the power mode is in ACCESSORY

If the smart entry remote is taken out of the vehicle, and all the doors are closed, a warning buzzer sounds from outside the vehicle.

Smart Entry Remote Reminder

When the smart entry remote is within the system's operational range, and the driver's door is closed, the warning function cancels.

If the smart entry remote is taken out of the vehicle after the engine has been started, you can no longer change the **ENGINE START/STOP** button mode or restart the engine. Always make sure if the remote is in your vehicle when you operate the **ENGINE START/STOP** button.

Removing the smart entry remote from the vehicle through a window does not activate the warning buzzer.


Do not put the smart entry remote on the dashboard or in the glove box. It may cause the warning buzzer to go off. Under some other conditions that can prevent the vehicle from locating the remote, the warning buzzer may also go off even if the remote is within the system's operational range.

Ignition Switch and Power Mode Comparison

Ignition Switch Position	LOCK (0) (with/without the key)	ACCESSORY (I)	ON (II)	START (III)
Without Smart Entry System	 Engine is turned off and power is shut down. The steering wheel is locked*1. No electrical components can be used. 	 Engine is turned off. Some electrical components such as the audio system and the accessory power socket can be operated. 	 Normal key position while driving. All electrical components can be used. 	 Use this position to start the engine. The ignition switch returns to the ON (II) position when you release the key.
Power Mode	VEHICLE OFF (LOCK)	ACCESSORY	ON Button is: Blinking On	START (BRODE)
With Smart Entry System and ENGINE START/STOP Button	 Button-Off Engine is turned off and power is shut down. The steering wheel is locked*1. No electrical components can be used. 	 Button-Blinking Engine is turned off. Some electrical components such as the audio system and the accessory power socket can be operated. 	Button- Blinking (engine is turned off) On (engine is running) • All electrical components can be used.	Button-On • The mode automatically returns to ON after the engine starts.

^{*1:}Except U.S. models with continuously variable transmission

Turn Signals



The turn signals can be used when the ignition switch is in ON \overline{II} ^{*1}.


■ One-touch turn signal

When you lightly push up or down and release the turn signal lever, the exterior turn signals and turn signal indicator blink three times. This feature can be used when signaling for a lane change.

Light Switches

lights

■ Manual Operation



Rotating the light switch turns the lights on and off, regardless of the power mode setting or position of the ignition switch.

■ High beams

Push the lever forward until you hear a click.

■ Low beams

When in high beams, pull the lever back to return to low beams

■ Flashing the high beams

Pull the lever back, and release it.

≥ Light Switches

Models with smart entry system

If you leave the power mode in VEHICLE OFF (LOCK) while the lights are on, a chime sounds when the driver's door is opened.

Models without smart entry system

If you remove the key from the ignition switch while the lights are on, a chime sounds when the driver's door is opened.

When the lights are on, the lights on indicator in the instrument panel will be on.


Lights On Indicator P. 82

Do not leave the lights on when the engine is off because it will cause the battery to discharge.

If you sense that the level of the headlights is abnormal, have the vehicle inspected by a dealer.

^{*1:} Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

Automatic Operation (automatic lighting control)*



Automatic lighting control can be used when the ignition switch is in ON $[II]^{*1}$.

When you turn the light switch to **AUTO**, the headlights and other exterior lights will switch on and off automatically depending on the ambient brightness.


- ➤ You can change the auto light sensitivity setting.
 - Customized Features P. 111

Matter Automatic Operation (automatic lighting control)*

We recommend that you turn on the lights manually when driving at night, in a dense fog, or in dark areas such as long tunnels or parking facilities.

The light sensor is in the location shown below. Do not cover this light sensor with anything; otherwise, the automatic lighting system may not work properly.





^{*1:} Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

Headlight Integration with Wipers*

The headlights automatically come on when the wipers are used several times within a certain number of intervals with the headlight switch in **AUTO**.

The headlights automatically go off a few minutes later if the wipers are stopped.

Automatic Lighting Off Feature

The headlights, all other exterior lights, and the instrument panel lights turn off 15 seconds after you remove the key or set the power mode to VEHICLE OFF (LOCK), take the remote with you, and close the driver's door.

- ► You can change the headlight auto off timer setting.
 - Customized Features P 111

If you turn the ignition switch to LOCK 0^{*1} with the headlight switch on, but do not open the door, the lights turn off after 10 minutes (3 minutes, if the switch is in the **AUTO** position).

The lights turn on again when you unlock or open the driver's door. If you unlock the door, but do not open it within 15 seconds, the lights go off. If you open the driver's door, you will hear a lights on reminder chime.

■ Automatic Operation (automatic lighting control)*

Adjust the auto light sensitivity as follows:



Customized Features P. 111

This feature activates while the headlights are off in AUTO

The instrument panel brightness does not change when the headlights come on.

At dark ambient light levels, the automatic lighting control feature turns on the headlights, regardless of the number of wiper sweeps.

^{*1:} Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

^{*} Not available on all models

Fog Lights*



When the low beam headlights are on, turn the fog light switch on to use the fog lights.

∑Fog Lights*

When the fog lights are on, the indicator in the instrument panel will be on.

They go off when the headlights turn off, or when the daytime running lights are on.

Fog Light Indicator* P. 82

Daytime Running Lights

The parking/daytime running lights come on when the following conditions have been met:

- The ignition switch is in ON II *1.
- The headlight switch is off.
- The parking brake is released.

The lights remain on even if you set the parking brake. Turning off the ignition switch or setting the power mode to VEHICLE OFF will turn off the daytime running lights.


The daytime running lights are off once the headlight switch is turned on, or when the headlight switch is in **AUTO*** and it is getting darker outside.

* Not available on all models

^{*1:} Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

Wipers and Washers

Windshield Wiper/Washer



MIST

2 OFF

3 INT*: Low speed with intermittent

Auto*: Automatic intermittent operation

4 LO: Low speed wipe

6 HI: High speed wipe

The windshield wipers and washers can be used when the ignition switch is in ON \overline{II}^{*1} .

■ MIST

The wipers run at high speed until you release the lever.

■ Wiper switch (OFF, INT*, LO, HI)

Change the wiper switch setting according to the amount of rain.

■ AUTO*

■ Automatic Intermittent Wipers* P. 161

■ Adjusting wiper operation*

Turn the adjustment ring to adjust the wiper delay.



Lower speed, fewer sweeps

Higher speed, more sweeps

■ Washer

Sprays while you pull the lever toward you. When you release the lever for more than one second, the spray stops, the wipers sweep two or three more times to clear the windshield, then stop.

NOTICE

Do not use the wipers when the windshield is dry. The windshield will get scratched, or the rubber blades will get damaged.

NOTICE

In cold weather, the blades may freeze to the windshield, becoming stuck.

Operating the wipers in this condition may damage the wipers. Use the defroster to warm the windshield, then turn the wipers on.

Models with adjustment ring

If the vehicle speeds up while the wipers are operating intermittently, the length of the wipe interval shortens. When the vehicle starts moving, the wipers make a single sweep.

When the vehicle speeds up, the wiper operation's shortest delay setting () and the **LO** setting become the same.

All models

Turn the washers off if no washer fluid comes out. The pump may get damaged.


The wiper motor may stop motor operation temporarily to prevent an overload. Wiper operation will return to normal within a few minutes, once the circuit has returned to normal.

If the wiper stops operating due to any obstacle such as the build-up of snow, park the vehicle in a safe place.

Rotate the wiper switch to **OFF**, and turn the ignition switch to ACCESSORY $\boxed{1}$ or LOCK $\boxed{0}^{*1}$, then remove the obstacle.

^{*1:} Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

Automatic Intermittent Wipers*



When you push the lever down to **AUTO**, the windshield wipers sweep once, and go into the automatic mode.

The wipers operate intermittently, at low speed, or at high speed and stops in accordance with the amount of rainfall the rainfall sensor detects.

■ AUTO sensitivity adjustment

When in **AUTO**, you can also adjust the rainfall sensor sensitivity using the intermittent time adjustment ring.


Sensor sensitivity



Low sensitivity: Wipers will operate when more rainfall is detected.

High sensitivity: Wipers will operate when less rainfall is detected.


The rainfall sensor is in the location shown below.



Do not put the wiper lever in **AUTO** when cleaning the windshield or driving through a car wash. If the wiper lever is in **AUTO**, and the power mode is in ON, the rainfall sensor may respond to your hand or car wash liquids, and the wipers may operate automatically.

* Not available on all models

Brightness Control



When the parking lights are turned on and the ignition switch is in ON [II]*1, you can use the brightness control knob to adjust instrument panel brightness.

Brighten: Turn the knob to the right. **Dim:** Turn the knob to the left.

You will hear a beep when the brightness reaches minimum or maximum. The display will return to its original state several seconds after you adjust the brightness.

■ Brightness level indicator


The brightness level is shown on the display while you are adjusting it.

Instrument panel brightness varies, depending on whether the exterior lights are on or off. The instrument panel dims to reduce glare when they are on.

Pressing the (TRIP) knob or the (display/information) button* switches the display.

If you turn the knob to the right until the brightness display is up to max, the beeper sounds. This cancels the reduced instrument panel brightness when the exterior lights are on.


The brightness can be set differently for when the exterior lights are on, and when they are off.




*1: Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

Rear Defogger/Heated Door Mirror* Button

Press the rear defogger and heated door mirror button to defog the rear window and mirrors when the ignition switch is in ON $|\overline{II}|^{*1}$.



The rear defogger and heated door mirrors automatically switch off after 10-30 minutes depending on the outside temperature. However, if the outside temperature is 32°F (0°C) or below, they do not automatically switch off.



■ Rear Defogger/Heated Door Mirror * Button

NOTICE

When cleaning the inside of the rear window, be careful not to damage the heating wires. It is critical to wipe the window from side to side along the defogger heating wires.

This system consumes a lot of power, so turn it off when the window has been defogged.


Also, do not use the system for a long period when the engine is idling. This may weaken the battery, making it difficult to start the engine.

^{*1:} Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

^{*} Not available on all models

Adjusting the Steering Wheel

The steering wheel height and distance from your body can be adjusted so that you can comfortably grip the steering wheel in an appropriate driving posture.



- 1. Pull the steering wheel adjustment lever up.
- ► The steering wheel adjustment lever is under the steering column.
- **2.** Move the steering wheel up or down, and in or out.
 - ► Make sure you can see the instrument panel gauges and indicators.
- **3.** Push the steering wheel adjustment lever down to lock the steering wheel in position.
 - ➤ After adjusting the position, make sure you have securely locked the steering wheel in place by trying to move it up, down, in, and out.

∑Adjusting the Steering Wheel

AWARNING

Adjusting the steering wheel position while driving may cause you to lose control of the vehicle and be seriously injured in a crash.

Adjust the steering wheel only when the vehicle is stopped.


Make any steering wheel adjustments before you start driving.

Adjusting the Mirrors

Interior Rearview Mirror

Adjust the angle of the rearview mirror when you are sitting in the correct driving position.

Rearview Mirror with Day and Night Positions*



Flip the tab to switch the position.

The night position will help to reduce the glare from headlights behind you when driving after dark.


■ Adjusting the Mirrors

Keep the inside and outside mirrors clean and adjusted for best visibility.

Adjust the mirrors before you start driving.

Front Seats P. 167

Automatic Dimming Rearview Mirror*




When driving after dark, the automatic dimming rearview mirror reduces the glare from headlights behind you, based in inputs from the mirror sensor. This feature is always active.

■ Automatic Dimming Rearview Mirror*

The auto dimming function cancels when the shift position is in \boxed{R} .

* Not available on all models

Power Door Mirrors




You can adjust the door mirrors when the ignition switch is in ON \boxed{II}^{*1} .

■ Mirror position adjustment

L/R selector switch: Select the left or right mirror. After adjusting the mirror, return the switch to the center position.

Mirror position adjustment switch: Press the switch left, right, up, or down to move the mirror.

■ Expanded View Driver's Mirror



The driver's side door mirror has outer and inner segments.

The outer segment is slightly curved to provide a wider angle view than a standard flat mirror. This wider view may help you check areas that are not visible using a standard door mirror.


Objects visible in the outer segment of the driver's side door mirror appear smaller than objects in the rest of the mirror. But in fact, they are closer than they appear.

Do not rely on your mirrors. Always look to the side and behind your vehicle before changing lanes.

^{*1:} Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

Adjusting the Seats


Front Seats



Adjust the driver's seat as far back as possible while allowing you to maintain full control of the vehicle. You should be able to sit upright, well back in the seat and be able to adequately press the pedals without leaning forward, and grip the steering wheel comfortably. The passenger's seat should be adjusted in a similar manner, so that it is as far back from the front airbag in the dashboard as possible.

Adjusting the Seat Positions

■ Adjusting the front power seat*



■ Adjusting the Seats

AWARNING


Sitting too close to a front airbag can result in serious injury or death if the front airbags inflate.

Always sit as far back from the front airbags as possible while maintaining control of the vehicle.

The National Highway Traffic Safety Administration and Transport Canada recommend that drivers allow at least 10 inches (25 cm) between the center of the steering wheel and the chest.

Always make seat adjustments before driving.

■ Adjusting the front manual seat(s)*



■ Adjusting the front manual seat(s)*

Once a seat is adjusted correctly, rock it back and forth to make sure it is locked in position.

Adjusting the Seat-Backs



Adjust the driver's seat-back to a comfortable, upright position, leaving ample space between your chest and the airbag cover in the center of the steering wheel.

The front seat passenger should also adjust their seat-back to a comfortable, upright position.

Reclining a seat-back so that the shoulder part of the belt no longer rests against the occupant's chest reduces the protective capability of the belt. It also increases the chance of sliding under the belt in a crash and being seriously injured. The farther a seat-back is reclined, the greater the risk of injury.

∑Adjusting the Seat-Backs

AWARNING

Reclining the seat-back too far can result in serious injury or death in a crash.

Adjust the seat-back to an upright position, and sit well back in the seat.


Do not put a cushion, or other object, between the seat-back and your back.

Doing so may interfere with proper seat belt or airbag operation.

If you cannot get far enough away from the steering wheel and still reach the controls, we recommend that you investigate whether some type of adaptive equipment may help.


Head Restraints

Adjusting the Front Head Restraints



Your vehicle is equipped with head restraints in all seating positions.

Front head restraints are most effective for protection against whiplash and other rearimpact crash injuries when the center of the back of the occupant's head rests against the center of the restraint. The tops of the occupant's ears should be level with the center height of the restraint.



To lower the head restraint:

Push it down while pressing the release button.




AWARNING

Improperly positioning head restraints reduces their effectiveness and increases the likelihood of serious injury in a crash.

Make sure head restraints are in place and positioned properly before driving.

In order for the head restraint system to work properly:

- Do not hang any items on the head restraints, or from the restraint legs.
- Do not place any object between an occupant and the seat-back.
- Install each restraint in its proper location.



■ Removing and Reinstalling the Front Head Restraints

Front head restraints can be removed for cleaning or repair.

To remove a head restraint:

Pull the restraint up as far as it will go. Then push the release button, and pull the restraint up and out.

To reinstall a head restraint:

Insert the legs back in place, then adjust the head restraint to an appropriate height while pressing the release button. Pull up on the restraint to make sure it is locked in position.

■ Removing and Reinstalling the Front Head Restraints

AWARNING

Failure to reinstall, or correctly reinstall, the head restraints can result in severe injury during a crash.

Always replace the head restraints before driving.

Maintain a Proper Sitting Position

After all occupants have adjusted their seats and head restraints, and put on their seat belts, it is very important that they continue to sit upright, well back in their seats, with their feet on the floor, until the vehicle is safely parked and the engine is off.

Sitting improperly can increase the chance of injury during a crash. For example, if an occupant slouches, lies down, turns sideways, sits forward, leans forward or sideways, or puts one or both feet up, the chance of injury during a crash is greatly increased.

In addition, an occupant who is out of position in the front seat can be seriously or fatally injured in a crash by striking interior parts of the vehicle or being struck by an inflating front airbag.

Maintain a Proper Sitting Position


AWARNING

Sitting improperly or out of position can result in serious injury or death in a crash.


Always sit upright, well back in the seat, with your feet on the floor.

Rear Seats

■ Folding Down the Rear Seats



1. Pull the release lever in the trunk to release the lock.



2. Fold the seat-back down

∑Folding Down the Rear Seats

The rear seat-back(s*) can be folded down to accommodate bulkier items in the trunk.

Never drive with the seat-back folded down and the trunk lid open.

Exhaust Gas Hazard P. 70

To lock a seat-back upright, push it backwards until it locks.

When returning the seat-back to its original position, push it firmly back. Also, make sure all rear shoulder belts are positioned in front of the seat-back.

Make sure that the folded seat-back does not press against the front passenger seat, as this can cause the weight sensors in the front passenger seat to work improperly.

Passenger Airbag Off Indicator P. 56

Make sure all items in the trunk or items extending through the opening into the rear seats are properly secured. Loose items can fly forward if you have to brake hard.

The front seat(s) must be far enough forward so they do not interfere with the rear seats as they fold down.

Armrest

■ Using the Front Seat Armrest



The console lid can be used as an armrest.

To adjust:

Slide the armrest to desired position.

Using the Rear Seat Armrest*




Pull down the armrest in the center seat-back.

Interior Lights/Interior Convenience Items

Interior Lights

■ Interior Light Switches



ON

The interior lights come on regardless of whether the doors are open or closed.

■ Door activated

The interior lights come on in the following situations:

- When any doors are opened.
- You unlock the driver's door.

Models without smart entry system

 You remove the key from the ignition switch.

Models with smart entry system

 When the power mode is set to VEHICLE OFF (LOCK).

■ OFF

The interior lights remain off regardless of whether the doors are open or closed.

In the door activated position, the interior lights fade out and go off about 30 seconds after the doors are closed. The lights go off after 30 seconds in the following situations:

• When you unlock the driver's door but do not open it.

Models without smart entry system

• When you remove the key from the ignition switch but do not open a door.

Models with smart entry system

• When you set the power mode to VEHICLE OFF (LOCK) but do not open a door.

Models with driver information interface

You can change the interior lights dimming time.

Customized Features P. 111

The interior lights go off immediately in the following situations:

- When you lock the driver's door.
- When you turn the ignition switch to ON III^{*1} .

Models without smart entry system

 When you close the driver's door with the key in the ignition switch.

Models with smart entry system


 When you close the driver's door in ACCESSORY mode.

If you leave any of the doors open in VEHICLE OFF (LOCK) mode, or without the key in the ignition switch, the interior lights go off after about 15 minutes.


*1: Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

Continued 175

■ Map Lights



The map lights can be turned on and off by pressing the lenses.



Map Lights

When the ceiling light switch is in the door activated position and any door is open, the map light will not go off when you press the lens.

Interior Convenience Items

■ Glove Box



Pull the handle to open the glove box.

Solution State State

AWARNING

An open glove box can cause serious injury to your passenger in a crash, even if the passenger is wearing the seat belt.


Always keep the glove box closed while driving.

Continued 177


Console Compartment



Your vehicle has a multi-function center console. It includes a storage compartment, an armrest, and a sliding tray*. Slide the armrest to the rearmost position. Pull the handle to open the console compartment.




You can put small items in the sliding tray* located in the console compartment lid. Slide the sliding tray forward or rearward.



You can create more storage space by removing the removable beverage holder tray and a divider

■ Beverage Holders



■ Front seat beverage holders

Are located in the console between the front seats.


► Move the armrest rearward to use the beverage holders.



To place a short beverage container:

Move the removable beverage holder tray forward.

To place a tall beverage container: Move the removable beverage holder tray rearward.



■ Rear seat beverage holders*


Fold the armrest down to use the rear seat beverage holders.

≥ Beverage Holders

NOTICE

Spilled liquids damage the upholstery, carpeting, and electrical components in the interior.

Be careful when you are using the beverage holders. Hot liquid can scald you.






■ Door beverage holders

■ Accessory Power Socket

The accessory power socket can be used when the ignition switch is in ACCESSORY \boxed{I} or ON \boxed{II}^{*1} .



Open the cover to use it.

NOTICE

Do not insert an automotive type cigarette lighter element.

This can overheat the power socket.

The accessory power socket is designed to supply power for 12 volt DC accessories that are rated 180 watts (15 amps) or less.

To prevent battery drain, only use the power socket with the engine running.

Continued 181


^{*1:} Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

Canadian models

Wireless Charger*

To use the wireless charger, the ignition switch must be in ACCESSORY \boxed{I} or ON \boxed{II}^{*_1} .

Charge a compatible device on the area indicated by the \$\psi\$ mark as follows:



- 1. To turn the system on and off, press and hold the (1) (power) button.
 - ► When the system is activated, the green indicator light comes on.
- **2.** Place the device you want to charge on the charging area.
 - The system will automatically start charging the device, and the amber indicator light will come on.
 - ▶ Make sure that the device is compatible with the system, and placed with the rechargeable side in the center of the charging area.
- **3.** When charging is completed, the green indicator light will come on.
 - ▶ Depending on the device, the amber indicator light will stay on.

Wireless Charger[∗]

ACAUTION

Metal objects between the charge pad and the device to be charged will get hot and can burn you.

- Always remove foreign objects from the charge pad before charging the device.
- Be sure the surface is clear of dust and other debris before charging.
- Do not spill liquids (i. e. water, drinks, etc.) on the charger and the device.
- Do not use oil, grease, alcohol, benzine or thinner for cleaning the charge pad.
- Do not cover the system with towels, clothing, or other objects while charging etc.
- Avoid using spraying hair spray, insecticides, etc, that may contact the charge pad surface.

This system consumes a lot of power, so do not use the system for a long time when the engine is not running. This may weaken the battery, making it difficult to start the engine.

When using the wireless charger, check the user's manual that came with the compatible device you want to charge.

^{*1:}Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

■ When charging does not start

Perform one of the solutions in the following table.

Indicator		Cause	Solution
Green & Amber	Blinking simulta- neously	There is an obstacle(s) between the charging area and the device.	Remove the obstacle(s).
		The device is not within the charging area.	Move the device to the center of the charging area where (1) is located.
Amber	Blinking	The wireless charger is faulty.	Contact a dealer for repairs.

Wireless Charger[∗]

NOTICE

Do not place any magnetic recording media or precision machines within the charging area while charging. The data on your cards such as credit cards can be lost because of the magnetic effect. This magnetic effect can also affect the operation of precision machines such as watches.

"Qi" and 🌗 marks are the registered trademarks owned by Wireless Power Consortium (WPC).

In the following cases, charging may stop or not start:

- The device is already fully charged.
- The temperature of the device is extremely high while charging.
- You are at a place that emits strong electromagnetic wave or noises, such as a TV station, electric power plant, or gas station.

A device may not charge if the size or shape of its rechargeable side is not appropriate for use with the charging area.

Not all devices are compatible with the system.

During the charging phase, it is normal for the charging area and device to heat up.

Changing may be briefly interrupted when:

- All the doors and the trunk are closed

 to avoid interference with the proper functioning of the smart entry system.
- The position of the device is altered.

Do not charge more than one device at a time on a charging area.

■ Coat Hooks



There is a coat hook on the rear left grab handle. Pull it down to use it.



There are coat hooks on the left and right door pillars.


Coat Hooks

The coat hook is not designed for large or heavy items.

■ Front Seat Heaters*



The ignition switch must be in ON [II]*1 to use the seat heaters. The HI setting heats the seats faster than the LO setting.



Press the seat heater button:
Once - The HI setting (three indicators on)
Twice - The MID setting (two indicators on)
Three times - The LO setting
Four times - The OFF setting (no indicators on)

When a comfortable temperature is reached while using the seat heaters in HI, select MID or LO to keep the seat warm.

∑Front Seat Heaters *

AWARNING

Heat induced burns are possible when using seat heaters.

Persons with a diminished ability to sense temperature (e.g., persons with diabetes, lower-limb nerve damage, or paralysis) or with sensitive skin should not use seat heaters.

Do not use the seat heaters even in LO when the engine is off. Under such conditions, the battery may be weakened, making the engine difficult to start.

*1: Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

■ Rear Seat Heaters*



The ignition switch must be in ON \boxed{II}^{*1} to use the seat heaters. The **HI** setting heats the seats faster than the **LO** setting.

There is no heater in the rear center seating position.

While in **HI**, the heater cycles on and off.

➤ The appropriate indicator will be on while the seat heater is on. When a comfortable temperature is reached, select LO to keep the seat warm. ■ Rear Seat Heaters *

AWARNING

Heat induced burns are possible when using seat heaters.

Persons with a diminished ability to sense temperature (e.g., persons with diabetes, lower-limb nerve damage, or paralysis) or with sensitive skin should not use seat heaters.

Do not use the seat heaters even in **LO** when the engine is off. Under such conditions, the battery may be weakened, making the engine difficult to start.

In the **LO** setting, the heater runs continuously and does not automatically turn off.


^{*1:} Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

^{*} Not available on all models

Heating System*

Using Automatic Heating

The automatic heating system maintains the interior temperature you select. The system also selects the proper mix of heated or cooled air that raises or lowers the interior temperature to your preference as quickly as possible.



Use the system when the engine is running.

- 1. Press the AUTO button.
- 2. Adjust the interior temperature using the temperature control dial.
- **3.** Press the solve (on/off) button to cancel.

≥Using Automatic Heating

If any buttons are pressed while using the heating system in auto, the function of the button that was pressed will take priority.

The **AUTO** indicator will go off, but functions unrelated to the button that were pressed will be controlled automatically.

To prevent cold air from blowing in from outside, the fan may not start immediately when the **AUTO** button is pressed.

When you set the temperature to the lower or upper limit. **Lo** or **Hi** is displayed.


■ Switching between the recirculation and fresh air modes

Press the (recirculation) or (fresh air) button to switch the mode depending on environmental conditions.

Recirculation mode (indicator on): Recirculates air from the vehicle's interior through the system.

Fresh air mode (indicator on): Maintains outside ventilation. Keep the system in fresh air mode in normal situations.


Defrosting the Windshield and Windows



Pressing the (windshield defroster) button automatically switches the system to fresh air mode.

Press the button again to turn off, the system returns to the previous settings.

■ To rapidly defrost the windows



- **1.** Press the button.
- 2. Press the button.

Substitute ∑Using Automatic Heating

Pressing the stiff button switches the heating system between on and off. When turned on, the system returns to your last selection.

While in the ECON mode, the heating system has greater temperature fluctuations.

Defrosting the Windshield and Windows

For your safety, make sure you have a clear view through all the windows before driving.

Do not set the temperature near the upper or lower limit.


When cold air hits the windshield, the outside of the windshield may fog up.

If the side windows fog up, adjust the vents so that the air hits the side windows.


∑To rapidly defrost the windows

After defrosting the windows, switch over to fresh air mode. If you keep the system in recirculation mode, the windows may fog up from humidity. This impedes visibility.

Automatic Heating Sensors




The automatic heating system is equipped with sensors. Do not cover or spill any liquid on them.



Climate Control System*

Using Automatic Climate Control

The automatic climate control system maintains the interior temperature you select. The system also selects the proper mix of heated or cooled air that raises or lowers the interior temperature to your preference as quickly as possible.



Use the system when the engine is running.

- 1. Press the AUTO button.
- 2. Adjust the interior temperature using the temperature control dial.
- **3.** Press the solve (on/off) button to cancel.

If any buttons are pressed while using the climate control system in auto, the function of the button that was pressed will take priority.

The **AUTO** indicator will go off, but functions unrelated to the button that were pressed will be controlled automatically.

To prevent cold air from blowing in from outside, the fan may not start immediately when the **AUTO** button is pressed.

If the interior is very warm, you can cool it down more rapidly by partially opening the windows, turning the system on AUTO, and setting the temperature to low. Change the fresh mode to recirculation mode until the temperature cools down.

When you set the temperature to the lower or upper limit, **Lo** or **Hi** is displayed.



Use the system when the engine is running.

- **1.** Press the **AUTO** button.
- **2.** Adjust the interior temperature using the driver's side or passenger's side control dial.
- **3.** Press the ♣ OFF button to cancel.

Pressing the ST button switches the climate control system between on and off. When turned on, the system returns to your last selection.

While in the ECON mode, the climate control system has greater temperature fluctuations.

■ Switching between the recirculation and fresh air modes

U.S. models with color audio system

Models with Display Audio

Models with SYNC button

Press the (recirculation) button and switch the mode depending on environmental conditions.

Recirculation mode (indicator on): Recirculates air from the vehicle's interior through the system.

Fresh air mode (indicator off): Maintains outside ventilation. Keep the system in fresh air mode in normal situations

Models with Display Audio


Models without SYNC button

Press the (recirculation) or (fresh air) button to switch the mode depending on environmental conditions.

Recirculation mode (indicator on): Recirculates air from the vehicle's interior through the system.


Fresh air mode (indicator on): Maintains outside ventilation. Keep the system in fresh air mode in normal situations.

Defrosting the Windshield and Windows



Pressing the (windshield defroster) button turns the air conditioning system on and automatically switches the system to fresh air mode.

Press the button again to turn off, the system returns to the previous settings.




For your safety, make sure you have a clear view through all the windows before driving.

Do not set the temperature near the upper or lower limit.

When cold air hits the windshield, the outside of the windshield may fog up.

If the side windows fog up, adjust the vents so that the air hits the side windows.








Continued 193

2. Press the button.

■ To rapidly defrost the windows 1. Press the | windows |








∑To rapidly defrost the windows

After defrosting the windows, switch over to fresh air mode. If you keep the system in recirculation mode, the windows may fog up from humidity. This impedes visibility.

Synchronized Mode*



You can set the temperature synchronously for the driver's side and the passenger's side in synchronized mode.


- 1. Press the **SYNC** button.
 - ▶ The system switches to synchronized mode.
- **2.** Adjust the temperature using the driver's side temperature control dial.

Press the **SYNC** button to return to dual mode.


Synchronized Mode *

When the system is in dual mode, the driver's side temperature and the passenger's side temperature can be set separately.

Automatic Climate Control Sensors



The automatic climate control system is equipped with sensors. Do not cover or spill any liquid on them.





Audio System	
About Your Audio System	198
USB Port(s)	
Audio System Theft Protection	200
Audio Remote Controls	201
Models with color audio system	
Audio System Basic Operation	205
Audio/Information Screen	206
Adjusting the Sound	210
Display Setup	211
Playing the AM/FM Radio	
Playing an iPod	214

Playing Bluetooth® Audio	220
Models with Display Audio	
Audio System Basic Operation	223
Audio/Information Screen	224
Adjusting the Sound	245
Display Setup	
Voice Control Operation	
Playing AM/FM Radio	
Playing SiriusXM® Radio*	
Playing an iPod	
Song By Voice™ (SBV)	
Playing Pandora®*	
Playing Aha TM	
,	2, 2

Playing a USB Flash Drive	273		
Playing Bluetooth® Audio	276		
HondaLink®	278		
Wi-Fi Connection	283		
Siri Eyes Free	285		
Apple CarPlay	286		
Android Auto	289		
audio Error Messages	293		
ieneral Information on the Audio			
System	296		
ustomized Features			
luetooth® HandsFreeLink®* 333,	356		


* Not available on all models

Audio System

About Your Audio System

The audio system features AM/FM radio and SiriusXM® Radio service*. It can also play USB flash drives, and iPod, iPhone and *Bluetooth*® devices.

You can operate the audio system from the buttons and switches on the panel, the remote controls on the steering wheel, or the icons on the touchscreen interface*.



■ About Your Audio System

SiriusXM® Radio is available on a subscription basis only. For more information on SiriusXM® Radio*, contact a dealer.

B General Information on the Audio System P. 296


SiriusXM® Radio is available in the United States and Canada, except Hawaii, Alaska, and Puerto Rico.

SiriusXM® is a registered trademark of SiriusXM Radio, Inc.

iPod, iPhone and iTunes are trademarks of Apple Inc.

State or local laws may prohibit the operation of handheld electronic devices while operating a vehicle

USB Port(s)



Install the iPod USB connector or the USB flash drive to the USB port.

Models with color audio system

► The USB port (1.0 A) is for playing audio files on a USB flash drive and connecting a cellular phone and charging device.

Models with Display Audio

▶ The USB port (1.5 A) is for charging devices, playing audio files and connecting compatible phones with Apple CarPlay or Android Auto.

■ In the console compartment*

The USB port (1.0 A) is for playing audio files on the USB flash drive and connecting a cellular phone and charging device.

- Do not leave the iPod or USB flash drive in the vehicle. Direct sunlight and high temperatures may damage it.
- We recommend using an extension cable with the USB port.
- Do not connect the iPod or USB flash drive using a hub.
- Do not use a device such as a card reader or hard disk drive, as the device or your files may be damaged.
- We recommend keeping your data backed up before using the device in your vehicle.
- Displayed messages may vary depending on the device model and software version.


If the audio system does not recognize the iPod, try reconnecting it a few times or reboot the device. To reboot, follow the manufacturer's instructions provided with the iPod or visit www.apple.com/ipod.

USB charge (1.5 A)

The USB port can supply up to 1.5 A of power. It does not output 1.5 A unless requested by the device. For amperage details, read the operating manual of the device that needs to be charged.

Turn the ignition switch to ACCESSORY \boxed{I} or ON \boxed{II}^{*1} first.

Under certain conditions, a device connected to the port may generate noise in the radio you are listening to.



- *1: Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.
- * Not available on all models

Audio System Theft Protection

The audio system is disabled when it is disconnected from the power source, such as when the battery is disconnected or goes dead. In certain conditions, the system may display **ENTER CODE***1/**Enter Code***2. If this occurs, reactivate the audio system.

■ Reactivating the audio system

- **1.** Turn the ignition switch to ON III*3.
- 2. Turn on the audio system.
- **3.** Press and hold the audio system power button for more than two seconds.
 - ➤ The audio system is reactivated when the audio control unit establishes a connection with the vehicle control unit. If the control unit fails to recognize the audio unit, you must go to a dealer and have the audio unit checked.

^{*1:} Models with color audio system


^{*2:} Models with the Display Audio

^{*3:} Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

Audio Remote Controls

Models with information display

Allow you to operate the audio system while driving.



SOURCE Button

Cycles through the audio modes as follows: FM—>AM—>USB—>iPod—>Bluetooth® Audio

+ 🗕 (Volume) Buttons

Press +: To increase the volume.

Press —: To decrease the volume.

Buttons

• When listening to the radio

Press To select the next preset radio station.

Press To select the previous preset radio station.

Press and hold To select the next station with strong reception.

Press and hold To select the previous station with strong reception.

• When listening to an iPod, USB flash drive, or *Bluetooth*® Audio

Press To skip to the next song.

Press To go back to the beginning of the current or previous song.

• When listening to a USB flash drive

Press and hold To skip to the next folder.

Press and hold To go back to the previous folder.

■ Audio Remote Controls


Some modes appear only when an appropriate device or medium is used.

Depending on the *Bluetooth*® device you connect, some functions may not be available.

Continued 201

Models with driver information interface

Allow you to operate the audio system while driving. The information is shown on the driver information interface.



▲ ▼ Buttons

Press ▲ or ▼ to cycle through the audio mode as follows:

FM→AM→SiriusXM®*→USB→iPod →Bluetooth® Audio→Pandora®*→Apps* →Audio Apps*

- \bullet When listening to the radio and SiriusXM $\!\!^{^{\tiny{\textcircled{\scriptsize 8}}}}$
- **1.** Press **ENTER** to switch the display to a preset list you stored in the preset buttons.
- 2. Press ▲ or ▼ to select a preset, then press ENTER.
- When listening to a USB flash drive
- **1.** Press **ENTER** to display the folder list.
- **2.** Press ▲ or ▼ to select a folder.
- **3.** Press **ENTER** to display a list of tracks in that folder
- **4.** Press ▲ or ▼ to select a track, then press **ENTER**.

You can also swipe up or down to scroll through the list of tracks alphabetically.

Some modes appear only when an appropriate device or medium is used.

Depending on the *Bluetooth*® device you connect, some functions may not be available.

Press the (Amg-up/back) button to go back to the previous command or cancel a command.

Press the **button** to switch display. **Switching the Display** P. 206

- When listening to an iPod
- **1.** Press **ENTER** to display the iPod music list.
- **2.** Press ▲ or ▼ to select a category.
- **3.** Press **ENTER** to display a list of items in the category.
- **4.** Press ▲ or ▼ to select an item, then press ENTER
 - ▶ Press ENTER and press ▲ or ▼ repeatedly until the desired mode you want to listen to is displayed.

You can also swipe up or down to scroll through the list of tracks alphabetically.

- When listening to Internet Radio*
- 1. Press ENTER to display the station list.
- 2. Press ▲ or ▼ to select an item, then press ENTER.
- When listening to Bluetooth® Audio
- 1. Press ENTER to display the track list.
- 2. Press ▲ or ▼ to select a track, then press ENTER.

+ - (Volume) Bar

Press +: To increase the volume.

Press —: To decrease the volume.

Models with Display Audio

Slide your finger up or down to increase or decrease the volume, respectively. Swipe down quickly to mute the volume and swipe up to cancel the mute.

■ Buttons

• When listening to the radio

Press To select the next preset radio station.

Press To select the previous preset radio station.

Press and hold To select the next strong station.

Press and hold To select the previous strong station.

• When listening to an iPod, USB flash drive, or Bluetooth® Audio

Press To skip to the next song.

Press To go back to the beginning of the current or previous song.

• When listening to a USB flash drive

Press and hold To skip to the next folder.

Press and hold To go back to the previous folder.

• When listening to Internet radio*

Press To skip to the next song.


Press and hold To select the next station.

Press and hold To select the previous station.

Audio System Basic Operation


Models with color audio system

To use the audio system, the ignition switch must be in ACCESSORY I or ON III.



Use the selector knob or **MENU/CLOCK** button to access some audio functions.

Press 🖔 to switch between the normal and extended display for some functions.



MENU/CLOCK button: Press to select any mode.

The available mode includes the wallpaper, display, clock, language setup, and play modes. Play modes can be also selected from scan, random, repeat, and so on.

- **(Back) button:** Press to go back to the previous display.
- **)/|| button:** Press to select the sound setting mode.
- *) button: Press to change the audio/information screen brightness.

Press *), then adjust the brightness using 😙.

► Each time you press (*), the mode switches between the daytime mode, nighttime mode and **OFF** mode.

These indications are used to show how to operate the selector knob.

Rotate 😙 to select.

Press 🕹 to enter.

Menu Items

- Adjust Clock P. 122
- **Wallpaper Setup** P. 208
- Display Setup P. 211
- Scan P. 213, 219
- **▶ Play Mode** P. 216, 219
- RDS Settings P. 213
- **Bluetooth** P. 220, 276


Press the **SOURCE**, \longrightarrow , \longrightarrow button on the steering wheel to change any audio setting.

Audio Remote Controls P. 201

Audio/Information Screen

Displays the audio status and wallpaper. From this screen, you can go to various setup options.

■ Switching the Display



207

Audio

Shows the current audio information.

■ Clock/Wallpaper

Shows a clock screen or an image you import.

■ Change display

- 1. Press the MENU/CLOCK button.
- **2.** Rotate ♥ to select **Settings**, then press ८.
- **3.** Rotate ♥ to select **Display Change**, then press ८.
- **4.** Rotate 🗇 to select **Wallpaper**, then press 🕹.
 - ▶ If you want to return to the audio display, select **Audio**.

Continued

Wallpaper Setup

You can change, store, and delete the wallpaper on the audio/information screen.

■ Import wallpaper

You can import up to three images, one at a time, for wallpaper from a USB flash drive



- **1.** Connect the USB flash drive to the USB port.
 - **USB Port(s)** P. 199
- 2. Press the MENU/CLOCK button.
- **3.** Rotate ♂ to select **Settings**, then press <a>⊗.
- **4.** Rotate ♂ to select **Wallpaper**, then press ∠
- **5.** Rotate ⑦ to select **Import**, then press ፩. ► The picture name is displayed on the list.
- **6.** Rotate ♥ to select a desired picture, then press ℧.
 - ► The selected picture is displayed.
- **7.** Press 🕹 to save the picture.
- 8. Press ♂ to select OK.
- **9.** Rotate ♥ to select a location to save the picture, then press ८.
 - ► The display will return to the wallpaper setting screen.

≫Wallpaper Setup

- When importing wallpaper files, the image must be in the USB flash drive's root directory. Images in a folder cannot be imported.
- The file name must be fewer than 64 characters.
- The file format of the image that can be imported is BMP (bmp) or JPEG (jpg).
- The individual file size limit is 2 MB.
- The maximum image size is 1,920 x 936 pixels. If the image size is less than 480 x 234 pixels, the image is displayed in the middle of the screen with the extra area appearing in black.
- Up to 255 files can be selected.
- If the USB flash drive does not have any pictures, the **No files detected** message appears.

■ Select wallpaper

- 1. Press the MENU/CLOCK button.
- **2.** Rotate ♥ to select **Settings**, then press ८.
- **3.** Rotate ♥ to select **Wallpaper**, then press ८.
- **4.** Rotate ♥ to select **Select**, then press ८.
 - ► The screen changes to the wallpaper list.
- **5.** Rotate ♥ to select a desired wallpaper, then press ८.

■ To view wallpaper once it is set

- 1. Press the MENU/CLOCK button
- **2.** Rotate ♥ to select **Settings**, then press ८.
- **3.** Rotate ♥ to select **Display Change**, then press ८.
- **4.** Rotate ⑦ to select **Wallpaper**, then press ♂.
 - ► The screen changes to the wallpaper list.
- **5.** Rotate ¹ to select a wallpaper that you want to set, then press ∠3.

■ Delete wallpaper

- 1. Press the MENU/CLOCK button.
- **2.** Rotate ♥ to select **Settings**, then press ८.
- **3.** Rotate region to select **Wallpaper**, then press ...
- **4.** Rotate [♠] to select **Delete**, then press [♠].
 - ► The screen changes to the wallpaper list.
- **5.** Rotate ♥ to select a wallpaper that you want to delete, then press ८.
- **6.** Rotate ♥ to select **Yes**, then press ८.
 - ► The display will return to the wallpaper setting screen.


≫Wallpaper Setup

To go back to the previous screen, press the (Back) button.





When the file size is large, it takes a while to be previewed.

Adjusting the Sound



Press the (sound) button, and rotate or to scroll through the following choices:





■ Adjusting the Sound

The SVC has four modes: **Off, Low, Mid,** and **High**. SVC adjusts the volume level based on the vehicle speed. As you go faster, audio volume increases. As you slow down, audio volume decreases.

Display Setup

You can change the brightness or color theme of the audio/information screen.

■ Changing the Screen Brightness



- 1. Press the **MENU/CLOCK** button.
- **2.** Rotate ♂ to select **Settings**, then press ૱.
- **3.** Rotate '♥ to select **Display Adjustment**, then press ♥.
- **4.** Rotate '♥' to select **Brightness**, then press ♥.
- **5.** Rotate ♥ to adjust the setting, then press ♣.

■ Changing the Screen's Color Theme




- 1. Press the MENU/CLOCK button.
- **2.** Rotate [♠] to select **Settings**, then press [♠].
- **3.** Rotate ♥ to select **Color Theme**, then press ♥.
- **4.** Rotate ♥ to select the setting you want, then press ८.

○ ○ ○ Changing the Screen Brightness

You can change the **Contrast** and **Black level** settings in the same manner.

Playing the AM/FM Radio



Radio Data System (RDS)

Provides text data information related to your selected RDS capable FM station.

■ To find an RDS station from Station List

- **1.** Press 💍 while listening to an FM station.
- **2.** Rotate to select the station, then press .

■ Update List

Updates your available station list at any time.

- **1.** Press 🛎 while listening to an FM station.
- **2.** Rotate ♥ to select **Update List**, then press ८.

■ Radio text

Displays the radio text information of the selected RDS station.

- 1. Press the MENU/CLOCK button.
- **2.** Rotate $^{\mbox{\tiny{1}}}$ to select **Settings**, then press $^{\mbox{\tiny{2}}}$.
- **3.** Rotate $^{\mbox{\tiny{1}}}$ to select **RDS Settings**, then press $^{\mbox{\tiny{2}}}$.
- **4.** Rotate $^{\mbox{\tiny{?}}}$ to select **Radio Text**, then press $^{\mbox{\tiny{$\&$}}}$.

Scan

Samples each of the strongest stations on the selected band for 10 seconds.

- 1. Press the **MENU/CLOCK** button.
- **2.** Rotate ♥ to select **Scan**, then press ८.

To turn off scan, press ᇫ.

Playing the AM/FM Radio Playing the AM/

The **ST** indicator appears on the display indicating stereo FM broadcasts.

Stereo reproduction in AM is not available.

You can store 6 AM stations and 12 FM stations into the preset memory.

Switching the Audio Mode

Press the **SOURCE** button on the steering wheel.


Audio Remote Controls P. 201

When you select an RDS-capable FM station, the RDS automatically turns on, and the frequency display changes to the station name. However, when the signals of that station become weak, the display changes from the station name to the frequency.


Playing an iPod

Connect the iPod using your dock connector to the USB port, then press the **MEDIA** button.

■ USB Port(s) P. 199



How to Select a Song from the iPod Music List with the Selector Knob



1. Press 💍 to display the iPod music list.

2. Rotate 😙 to select a category.

- **3.** Press ⊗ to display a list of items in the category.
- **4.** Rotate to select an item, then press .
 - ▶ Press ☑ and rotate ⑤ repeatedly until a desired item you want to listen is displayed.

Available operating functions vary on models or versions. Some functions may not be available on the vehicle's audio system.

If there is a problem, you may see an error message on the audio/information screen.

iPod/USB Flash Drive P. 293

Continued 215

■ How to Select a Play Mode

You can select repeat and shuffle modes when playing a song.



Available mode icons appear above the play mode buttons.

Press the button corresponding to the mode you want to select.

■ To turn off a play mode

Press the selected button

Play Mode Menu Items

Shuffle Album: Plays all available albums in a selected category (playlists, artists, albums, songs, genres, or composers) in random order.

Shuffle All: Plays all available songs in a selected category (playlists, artists, albums, songs, genres, or composers) in random order.

Repeat One Track: Repeats the current song.

You can also select a play mode by pressing the MENU/CLOCK button.

Rotate of to select **Play Mode**, then press &. To turn it off, rotate or to select **Normal Play**, then

press 💍.


216

Playing a USB Flash Drive

Your audio system reads and plays sound files on a USB flash drive in either MP3, WMA or AAC*1 format.


Connect your USB flash drive to the USB port, then press the **MEDIA** button.

■ USB Port(s) P. 199



^{*1:}Only AAC format files recorded with iTunes are playable on this unit.

■ How to Select a File from a Folder with the Selector Knob



1. Press 💍 to display a folder list.

2. Rotate 😙 to select a folder.

- **3.** Press ⊗ to display a list of files in that folder.
- **4.** Rotate '♥ to select a file, then press ८.

Use the recommended USB flash drives.

Seneral Information on the Audio System P. 296

Files in WMA format protected by digital rights management (DRM) cannot be played. The audio system displays **UNPLAYABLE FILE**, and then skips to the next file.

If there is a problem, you may see an error message on the audio/information screen.

▶ iPod/USB Flash Drive P. 293

■ How to Select a Play Mode

You can select repeat, random, and scan modes when playing a file.



Available mode icons appear above the play mode buttons.

Press the button corresponding to the mode you want to select.

■ To turn off a play mode

Press the selected button.

∑How to Select a Play Mode

Play Mode Menu Items

Repeat

Repeat One Folder: Repeats all files in the current folder.

Repeat One Track: Repeats the current file.

Random

Random in Folder: Plays all files in the current folder in random order.

Random All: Plays all files in random order.

Scan

Scan Folders: Provides 10-second sampling of the first file in each of the main folders.

Scan Tracks: Provides 10-second sampling of all files in the current folder.

You can also select a play mode by pressing the **MENU/CLOCK** button.

Rotate to select **Play Mode**, then press . Rotate to select a mode, then press . To turn it off, rotate to select **Normal Play**, then


press &.

Playing Bluetooth® Audio

Your audio system allows you to listen to music from your *Bluetooth*-compatible phone.

This function is available when the phone is paired and connected to the vehicle's *Bluetooth*® HandsFreeLink® (HFL) system.

Phone Setup P. 339



Not all *Bluetooth*-enabled phones with streaming audio capabilities are compatible with the system. For a list of compatible phones:

- U.S.: Visit www.handsfreelink.honda.com, or call 1-888-528-7876.
- Canada: Visit www.handsfreelink.ca, or call 1-888-528-7876.

In some states, it may be illegal to perform some data device functions while driving.


Only one phone can be used with HFL at a time. When there are more than two paired phones in the vehicle, the first paired phone the system finds is automatically connected.

If more than one phone is paired to the HFL system, there will be a delay before the system begins to play.

In some cases, the name of the artist, album, or track may not appear correctly.

Some functions may not be available on some devices.

■ To Play *Bluetooth*® Audio Files



- **1.** Make sure that your phone is paired and connected to HFL.
- **2.** Press the **MEDIA** button until the *Bluetooth* Audio Source is selected.

If the phone is not recognized, another HFL-compatible phone, which is not compatible for *Bluetooth*® Audio, may already be connected.

■ To pause or resume a file

Press a **Play** or **Pause** button to select a mode.

∑To Play Bluetooth® Audio Files


To play the audio files, you may need to operate your phone. If so, follow the phone maker's operating instructions.

The pause function may not be available on some phones.

If any audio device is connected to the auxiliary input jack or USB port, you may need to press the **MEDIA** button repeatedly to select the *Bluetooth*® Audio system.

Switching to another mode pauses the music playing from your phone.

How to Select a Song from the Music Search List with the Selector Knob



1. Press 🕹 to display the music search list.

2. Rotate 😙 to select a category.

- **3.** Press 🖔 to display a list of items in the category.
- 4. Rotate ♂ to select an item, then press ♂.

 ▶ Press ♂ and rotate ♂ repeatedly until a
 - desired item you want to listen is displayed.

▶ How to Select a Song from the Music Search List with the Selector Knob

Depending on the *Bluetooth*® device you connect, some or all of the categories may not be displayed.

Audio System Basic Operation

Models with Display Audio

To use the audio system function, the ignition switch must be in ACCESSORY \blacksquare or ON \blacksquare ^{*1}.




Select to go to the home screen.

Switching the Display P. 224

Select to display available options including **Sound**, **View Radio Text**, **Music Search**, and playback modes.

Select to go back to the previous screen when the icon is illuminated.



***** Select to change the audio/information screen brightness.

Select nonce and select nor to make an adjustment.

► Each time you select ※), the mode switches among the daytime mode, nighttime mode and off mode.

Audio Menu Items

Station List P. 253, 254

Music Search List P. 264, 274

Scan P. 254, 255, 262, 275

▶ Play Mode P. 265, 275

^{*1:} Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.


Audio/Information Screen

Displays the audio status and wallpaper. From this display, you can go to various setup options.

Switching the Display

■ Using the 🕝 button

Press the (display) button to change the display.




■ Using the button

You can edit, add, and delete the contents shown on the driver information interface.

Customizing the Meter P. 229

■ Using the audio/information screen



Select to go to the home screen.

Select Phone, Info, Audio, Settings, Navigation*, HondaLink, Aha, Smartphone Connection (Apple CarPlay, Android Auto), App List, or Instrument Panel.

■ Phone

Displays the HFL information.

Bluetooth® HandsFreeLink®* P. 356

■ Info

Displays **Trip Computer** or **Clock/Wallpaper**. Select on the **Info Menu** screen to see all available options: **Trip Computer**, **Voice Info**, **Clock/Wallpaper** and **System/Device Information**.

Trip Computer:

- **Current Drive** tab: Displays the current trip information.
- **History of Trip A** tab: Displays information for the three previous drives. The information is stored every time you reset Trip A.

To delete the history manually, select **Delete History** on the **History of Trip A** tab. The confirmation message appears on the screen, then select **Yes**.

Voice Info: Displays the all commands list.

Clock/Wallpaper:

Displays the clock and wallpaper.

System/Device Information:

- **System Info**: Displays the software version of the audio system.
- **USB Info**: Displays the memory usage of the USB device.

Audio

Displays the current audio information.

■ Settings

Enters the customizing menu screen.

■ Customized Features P. 302

■ Navigation*

Displays the navigation screen.

Refer to the Navigation System Manual

* Not available on all models

■ HondaLink

Connects with your smartphone*1 to play personalized music, information, and social media streams.

HondaLink® P 278

■ Aha

Displays the Aha[™] screen.

Playing Aha™ P. 272

■ Smartphone Connection

Connects with your smartphone*1 and allows some apps on your smartphone to be used on the audio system.

▶ Apple CarPlay P. 286

Android Auto P. 289

■ App List

Adds or removes apps or widgets on the Home screen.

Home Screen P. 235

■ Instrument Panel

Selects from three customizable settings for the driver information interface.

^{*1:} Available on specific phones only. Check *handsfreelink.honda.com* for U.S. and *www.handsfreelink.ca* for Canada for compatible phones and *hondalink.com* for U.S. and *honda.ca/hondalink* for Canada for feature details.

■ Changing the Home Screen Icon Layout



- 1. Select .
- 2. Select and hold an icon.
 - ► The screen switches to the customization screen.
- **3.** Drag and drop the icon to where you want it to be.
- 4. Select OK.
 - ► The screen will return to the home screen.

■ Customizing the Meter

You can edit, add, or delete the meter contents on the driver information interface.



- 1. HOME
- 2. Settings
- 3. System
- 4. Configuration of Instrument Panel

■ Customizing the Meter

You can store up to three customized configurations. To select or customize a configuration, press **Swap Config.**.

When you select **Swap Config.** during customization, the settings you changed will be saved.

When you select during customization, the settings you changed will not be saved and you will be returned to the **Configuration of Instrument Panel** screen.

■ Editing order

To change the order of the icons on the driver information interface, first select:



1. Edit Order

- 2. Select the icon you want to move.
 - ➤ You will see arrows on both sides of the selected icon.

- **3.** Select the left or right arrow repeatedly to move the icon to your desired position.
- 4. Select OK.
 - ➤ The screen will return to the Configuration of Instrument Panel screen.


Editing order

You can use an alternative method to change the order of the icons. First select:

- 1. Edit Order
- 2. Select and hold the icon you want to move.
- 3. Drag and drop the icon to where you want it to be.
- 4 Select **OK**
- The screen will return to the Configuration of Instrument Panel screen.

■ Adding contents

You can add up to 10 contents on the driver information interface. To add contents, first select:



1. Add

- 2. Select an icon you want to add.
 - You will see a plus mark on the upper right hand corner of the selected icon.

- 3. Select OK.
 - ► The screen will return to the Configuration of Instrument Panel screen.


■ Adding contents

Icons that are grayed out cannot be selected.

If an icon has a plus mark in the upper-right corner, it means that the icon has already been added.

■ Deleting contents

To delete contents on the driver information interface, first select:



1. Delete

- 2. Select an icon you want to delete.
 - ► The icon with an X on the upper right hand corner can be deleted.

- 3. Select OK.
 - ➤ The screen will return to the Configuration of Instrument Panel screen.

Deleting contents

You can also delete contents by selecting:

- 1. Delete or Edit Order
- 2. Select and hold an icon you want to delete.
- 3. Drag and drop the icon to the trash icon.
- 4. Select **OK**.
- The screen will return to the Configuration of Instrument Panel screen.

Wallpaper Setup

You can change, store, and delete the wallpaper on the audio/information screen.

■ Import wallpaper

You can import up to five images, one at a time, for wallpaper from a USB flash drive.



CCC.jog
DD0.jpg
EEE.jog
AAA.jpg
BBR.jpg

- **1.** Connect the USB flash drive to the USB port.
 - **USB Port(s)** P. 199
- 2. Select Settings.
- 3. Select Clock.
- **4.** Select **Clock/Wallpaper Type**, then open the **Wallpaper** tab.
- 5. Select Add New.
 - ► The picture name is displayed on the list.
- **6.** Select a desired picture.
 - ➤ The preview is displayed on the left side on the screen.
- **7.** Select **Start Import** to save the data.
 - ► The display will return to the wallpaper list.

Wallpaper Setup

The wallpaper you set up on **Clock Wallpaper/Type** cannot be displayed on the driver information interface.

- When importing wallpaper files, the image must be in the USB flash drive's root directory.
 Images in a folder cannot be imported.
- The file name must be fewer than 64 characters.
- The file format of the image that can be imported is BMP (bmp) or JPEG (jpg).
- The individual file size limit is 5 MB.
- The maximum image size is 4,096 × 4,096 pixels. If the image size is less than 800 × 480 pixels, the image is displayed in the middle of the screen with the extra area appearing in black.
- If the USB flash drive does not have any pictures, the **No files detected** message appears.

After changing the screen interface design, you can change the wallpaper by following procedure.

- 1. Select HOME.
- 2. Select and hold empty space on the home screen. The pop-up menu appears on the screen.
- 3. Select **Change Wallpaper**.
- 4. Select Gallery, Live wallpapers, or Wallpapers.

■ Select wallpaper

- 1. Select Settings.
- 2. Select Clock.
- **3.** Select **Clock/Wallpaper Type**, then open the **Wallpaper** tab.
 - ► The screen changes to the wallpaper list.
- **4.** Select a desired wallpaper.
 - ► The preview is displayed on the left side on the screen.
 - ► The pop-up menu appears on the screen.
- 5. Select Set.
 - ► The display will return to the wallpaper list.

■ To view wallpaper once it is set


- 1. Select
- 2. Select Info.
- 3. Select 🖳
- 4. Select Clock/Wallpaper.

■ Delete wallpaper

- 1. Select **Settings**.
- 2. Select Clock.
- **3.** Select **Clock/Wallpaper Type**, then open the **Wallpaper** tab.
 - ► The screen changes to the wallpaper list.
- 4. Select a wallpaper that you want to delete.
 - ▶ The preview is displayed on the left side on the screen.
 - ► The pop-up menu appears on the screen.
- 5. Select **Delete**.
 - A confirmation message appears on the screen.
- **6.** Select **Yes** to delete completely.
 - ► The display will return to the wallpaper list.

≫Wallpaper Setup

From the pop-up menu, select **Preview** to see a preview at full-size screen.




To go back to the previous screen, select **OK**, or select **OK**.

When the file size is large, it takes a while to be previewed.

To delete all wallpapers you add, select **Delete All**, then **Yes**

■ Home Screen

■ To change to a next screen



Selecting ((or)), or swiping the screen left or right changes to the next screen.

The home screen has 5 pages (fixed). You cannot add any more pages.

Select to go directly back to the first page of the home screen from any page.

■ To use apps or widgets



- 1. Select
- 2. Select «.
- 3. Select App List.
 - ► The **Apps** screen appears.
- 4. Select the app or widget you want to use.

Preinstall app list:

- **Browser**: Displays the web browser utilized by smartphone and Wi-Fi connection.
- Calculator: Displays Calculator.
- **Gallery**: Displays images.
- **Downloads**: Displays the data downloaded from the web browser and so on.
- **App Installer**: Allows you to install apps.
- **Search**: Displays various retrieval screen.

■ To use apps or widgets

Select and hold a selected app or widget to add that app's or widget's shortcut on the home screen.

Pre-installed apps may not start up normally. If this occurs, you need to reset the system.

Defaulting All the Settings P. 332

If you perform **Factory Data Reset**, it may reset all the settings to their factory default.

Defaulting All the Settings P. 332

In case those apps still do not startup normally even after **Factory Data Reset**, contact your dealer.

There is a possibility that a browser is shut down in the situation of the use. In that situation, the screen will return to before the browser startup.


You can delete user installed apps by the following procedure.

- 1. Select
- 2. Select Settings.
- 3. Select **System**.
- 4. Select the Others tab.
- Select **Detail Information**.
- 6. Select an App that you want to delete.
- 7. Select **Delete**.

Pre-installed apps cannot be deleted.

■ To add app or widget icons on the home screen

App or widget icons can be added on the home screen.




- 1. Select .
- 2. Select «.
- **3.** Select and hold empty space on the home screen.
 - ► The pop-up menu appears on the screen.
- 4. Select Add App or Add Widget.
 - ► The **Apps** screen appears.



- **5.** Select and hold an app or widget icon you want to add.
 - ► The screen switches to the customization screen.
- **6.** Drag and drop the icon to where you want it to be.
- 7. Select OK.
 - ► The screen will return to the home screen.

■ To move icons on the home screen

You can change location on the home screen.



- 1. Select and hold an icon.
 - ► The screen switches to the customization screen.
- **2.** Drag and drop the icon to where you want it to be.
- 3. Select OK.
 - ► The screen will return to the home screen.

∑To move icons on the home screen

You can also move the Phone, Info, Audio, Settings, Navigation*, HondaLink, Aha, Smartphone Connection, App List, and Instrument Panel icons in the same manner.

■ To remove icons on the home screen

You can delete the icons on the home screen.



- 1. Select and hold an icon.
 - ► The screen switches to the customization screen.
- **2.** Drag and drop the icon you want to remove to the trash icon.
 - ► The icon is removed from the home screen.
- 3. Select OK.
 - ► The screen will return to the home screen.

∑To remove icons on the home screen

You cannot delete the Phone, Info, Audio, Settings, and Navigation*, HondaLink, Aha, Smartphone Connection, App List, and Instrument Panel icons.

Apps or widgets will not be deleted by deleting the icon on the home screen.

Status Area



- **1.** Swipe the upper area of the screen.
 - ► The status area appears.
- 2. Select an item to see the details.
- **3.** Select or swipe up the bottom bar to close the area.

■ Changing the Screen Interface

You can change the screen interface design.



- 1. Select .
- 2. Select Settings.
- 3. Select System.
- **4.** Select the **Others** tab.
- 5. Select Change Skin.
- **6.** A confirmation message appears on the screen. Select **Yes**.

∑Changing the Screen Interface

After changing the screen interface design, you can change the wallpaper by following procedure.

- 1. Select
- 2. Select and hold empty space on the home screen. The pop-up menu appears on the screen.
- 3. Select **Change Wallpaper**.
- 4. Select Gallery, Live wallpapers, or Wallpapers.

If you change the screen interface, some of the setting items will change.

Customized Features P. 302

Menu Customize

You can change menu icons on the right side of **Audio**, **Phone**, and **Info** screen.

- Menu Icons 12:34 Select and hold To change Menu Icon 12:34 Menu Customize Drag and drop To add 12:34 Drag and drop
- 1. Select and hold menu icon.

- 2. Select or icon, then Audio, Phone, or Info from Menu Customize.
- **3.** Select and hold the menu icon you want to change, then drag and drop the icon to the bottom.

- **4.** Select and hold the menu icon you want to add, then drag and drop the icon to above.
- **5.** Select **OK**.

Menu Customize

You can also use the method below to change menu icon:

Select Settings→System→Home tab→Menu icon position

■ Closing Apps

You can close specific apps running in the background on the system.



- 1. Select and hold
- **2.** Select an app you want to close.
- 3. Select Clear.
 - ► The display will return to the app list.


○ Closing Apps

If you have a number of apps running in the background and something goes wrong with the audio system, some of those apps may not work properly. If this happens, close all the apps and relaunch the app/apps that you want to use.

To close all apps on the system, select $\mbox{\bf Clear All},$ then $\mbox{\bf Yes}.$

You cannot close the HondaLink®, AhaTM and Garmin* apps.

Adjusting the Sound



- 1. Select
- 2. Select Audio.
- 3. Select 🖺.
- 4. Select Sound.

Select a tab from the following choices:

- BAS-MID-TRE: Bass, Middle, Treble
- **FAD-BAL-SUBW:** Fader, Balance, Subwoofer
- **SVC·Neural:** Speed Volume Compensation, DTS Neural Surround™



■ Adjusting the Sound

The SVC has four modes: **Off**, **Low**, **Mid**, and **High**. SVC adjusts the volume level based on the vehicle speed. As you go faster, audio volume increases. As you slow down, audio volume decreases.

Display Setup

You can change the brightness or color theme of the audio/information screen.

Changing the Screen Brightness



- 1. Select
- 2. Select Settings.
- 3. Select System.
- **4.** Select the **Display** tab.
- 5. Select Display Settings.
- **6.** Select the setting you want.
- 7. Select OK.

■ Changing the Screen's Color Theme




- 1. Select
- 2. Select Settings.
- 3. Select System.
- **4.** Select the **Display** tab.
- 5. Select Background Color.
- **6.** Select the setting you want.
- 7. Select OK.

∑Changing the Screen Brightness

You can change the **Contrast** and **Black Level** settings in the same manner.

Selecting an Audio Source



Select the current source icon, then select an icon on the source list to switch the audio source

■ Limitations for Manual Operation

Certain manual functions are disabled or inoperable while the vehicle is in motion. You cannot select a grayed-out option until the vehicle is stopped.

Selecting an Audio Source

If you startup preinstalled audio apps, Apps is displayed on the lower right of the screen.

These preinstalled apps cannot be displayed on the source select screen.

You can startup those audio apps from ADDS.



When you are using the Aha™ screen and you want to select another source, select **AUDIO** on the upper left of the screen. The source select screen will appear. Select the source you want.

Voice Control Operation

Your vehicle has a voice control system that allows hands-free operation. The voice control system uses the (Talk) and (hang-up/back) buttons on the steering wheel and a microphone near the map lights on the ceiling.

■ Voice Recognition

To achieve optimum voice recognition when using the voice control system:

- Make sure the correct screen is displayed for the voice command that you are using.
- Close the windows and moonroof*.
- Adjust the dashboard and side vents so air does not blow onto the microphone on the ceiling.
- Speak clearly in a natural speaking voice without pausing between words.
- Reduce any background noise if possible. The system may misinterpret your command if more than one person is speaking at the same time.

≥Voice Control Operation

When you press the £ button, a helpful prompt asks what you would like to do. Press and release the £ button again to bypass this prompt and give a command.

≥ Voice Recognition

The voice control system can only be used from the driver's seat because the microphone unit removes noises from the front passenger's side.

■ Voice Portal Screen



When the [6] (Talk) button is pressed, available voice commands appear on the screen.

For a complete list of commands, say "Voice Help" after the beep or select **Voice Help**.

You can see the list of commands in **Voice Info** on the **Info menu** screen. Select **Info**, then select **Info**.

■ Phone Call

This can be only used when the phone is connected. When the system recognizes the *Phone call* command, the screen will change to the voice recognition screen for phone commands.

- Dial by number
- Call history
- Redial
- Call <Your Contact Name>
- Call <Phone Number>
- Call Police
- Call 911

Phone Call commands are not available if using Apple CarPlay or Android Auto.

■ Music Search

This can be only used when the iPod or USB device is connected.

■ Climate Control*¹

When the system recognizes the *Climate Control* command, the screen will change the dedicated screen to the climate control voice recognition screen.

Climate Control Commands*1 P. 251

■ Audio*1

When the system recognizes the *Audio* command, the screen will change to the audio voice recognition screen.

- Audio On
- Audio Off
- Radio FM
- Radio AM
- Radio SXM*
- Pandora*
- iPod
- USB
- Other Sources

Pandora* cannot be used with Android Auto.

■ Navigation*1

The screen changes to the navigation screen.

Refer to the Navigation System Manual

■ HondaLink

This can be only used when the phone is connected.

■ Voice Setting

The screen changes to the **Voice Recog** tab on the **System settings** screen.

^{*1:} Models with navigation system

^{*} Not available on all models

■ Voice Help

You can see a list of the available commands on the screen.

- Useful Commands
- Phone Commands
- Audio Commands
- On Screen Commands
- Music Search Commands
- General Commands
- Climate Control Commands

Useful Commands

The system accepts these commands on the voice portal top screen.

- Call <Phone Number>
- Call <Your Contact Name>
- What time is it?
- What is today's date?

Phone Commands

The system accepts these commands on the dedicated screen for the voice recognition of the phone.

- Call by Number
- · Call by Name
- Call <Phone Number>
- Call <Your Contact Name>

Audio Commands*1

The system accepts these commands on the dedicated screen for the voice recognition of the audio.

■ Radio FM Commands

- Radio tune to <87.7-107.9> FM
- Radio tune to <87.7 -107.9> HD <1-8> FM
- Radio FM preset <1-12>

■ Radio AM Commands

- Radio tune to <530-1710> AM
- Radio AM preset <1-6>

■ Radio SXM Commands*

• SXM channel <1-255>

- SXM channel <channel name, category name, traffic and weather city name, sports team name>
- Radio SXM preset <1-12>

■ Pandora Commands*

Pandora play

■ iPod Commands

- iPod play
- iPod play track <1-30>
- Music Search
- What album is this?
- What am I listening to?

■ USB Commands

- USB play
- USB play track <1-30>
- Music Search
- What album is this?
- What am I listening to?

■ Bluetooth® audio Commands

• Bluetooth® audio play

NOTE:

Bluetooth® Audio commands may not work on some phones or Bluetooth® Audio devices.

^{*1:} Models with navigation system

On Screen Commands

When **On Screen Commands** is selected, the explanation screen is displayed.

■ Music Search Commands

The system accepts these commands on the **Music Search** screen.

■ Using Song By Voice

Song By VoiceTM is a feature that allows you to select music from your iPod or USB device using Voice Commands. To activate this mode, you must push the talk switch and say: "Music search".

■ Song By Voice Commands

- What am I listening to?
- Who am I listening to?
- Who is this?
- What's playing?
- Who's playing?
- What album is this?

■ Play Commands

- Play artist <Name>
- Play track/song <Name>
- Play album <Name>
- Play genre/category <Name>
- Play playlist <Name>
- Play composer <Name>

■ List Commands

- List artist <Name>
- List album <Name>
- List genre/category <Name>
- List playlist <Name>
- List composer <Name>

■ General Commands


- What time is it?
- What is today's date?

■ Climate Control Commands*1

- Climate Control on
- Climate Control off
- Fan Speed <1-7>
- Temperature max heat
- Temperature max cool
- Temperature <57-87> degrees
- Defrost on
- Defrost off
- Air conditioner on
- Air conditioner off
- More
- Climate control automatic
- Vent
- Dash and floor
- Fan speed up
- Fan speed down
- Floor vents
- Floor and defrost
- Temperature up
- Temperature down

^{*1:} Models with navigation system

Playing AM/FM Radio



^{*1:}Some or all of the lists may not be displayed.

Preset Memory

To store a station:

- 1. Tune to the selected station.
- **2.** Select and hold the preset number for the station you want to store.

You can also store a preset station by the following procedure.

- **1.** Tune to the selected station.
- 2. Select the open/close icon to display a list.
- **3.** Select the **Preset** tab.
- **4.** Select and hold the preset number for the station you want to store.

■ Station List

Lists the strongest stations on the selected band.

- 1. Select the open/close icon to display a list.
- 2. Select the Station List tab.
- **3.** Select the station.

■ Manual update

Updates your available station list at any time.

- **1.** Select the open/close icon to display a list.
- 2. Select the **Station List** tab.
- 3. Select Refresh.

The **ST** indicator appears on the display indicating stereo FM broadcasts.

Stereo reproduction in AM is not available.

Switching the Audio Mode

Press the or button on the steering wheel or select **SOURCE** on the screen.

Audio Remote Controls P. 201

You can store 6 AM stations and 12 FM stations into preset memory.

HD Radio Technology manufactured under license from iBiquity Digital Corporation. U.S. and Foreign Patents. HD Radio™ and the HD, HD Radio, and "Arc" logos are proprietary trademarks of iBiquity Digital Corp.



Scan

Samples each of the strongest stations on the selected band for 10 seconds. To turn off scan, select **Cancel** or seconds.

Models with HD Radio™

■ HD Subchannel

Displays the subchannel list when an HD Radio™ station is selected while listening to an FM station.

- 1. Select 🖳
- 2. Select HD Subchannel.
- 3. Select the channel number.

■ Radio Data System (RDS)

Provides text data information related to your selected RDS-capable FM station.

■ To find an RDS station from Station List

- **1.** Select the open/close icon to display a list while listening to an FM station.
- 2. Select the **Station List** tab.
- 3. Select the station.

■ Manual update

Updates your available station list at any time.

- **1.** Select the open/close icon to display a list while listening to an FM station.
- 2. Select the **Station List** tab.
- 3. Select Refresh.

When you select an RDS-capable FM station, the RDS automatically turns on, and the frequency display changes to the station name. However, when the signals of that station become weak, the display changes from the station name to the frequency.

■ Radio text

Displays the radio text information of the selected RDS station.


- 1. Select 🖳
- 2. Select View Radio Text.

■ Scan

Samples each of the strongest stations on the selected band for 10 seconds.

To turn off scan, select **Cancel** or BACK.

Playing SiriusXM® Radio*



^{*1:}Some or all of the lists may not be displayed.

■ To Change the Tune Mode

- 1. Select
- 2. Select Tune Mode.
- 3. Select Channel Mode or Category Mode.

▶ Playing SiriusXM® Radio *

In the channel mode, all available channels are selectable. In the category mode, you can select a channel within a category (Jazz, Rock, Classical, etc.).

There may be instances when SiriusXM® Radio does not broadcast all the data fields (artist name, title). This does not indicate a problem with your audio system.

SiriusXM® Radio stations load in ascending order, which can take about a minute. Once they have loaded you will be able to scroll up or down to make your selections.

Switching the Audio Mode

Press the **SOURCE** button on the steering wheel or select **SOURCE** on the screen.

Audio Remote Controls P. 201

Tune Start:

When you change to a preset channel, a song being played on that channel restarts from the beginning with this function. This can be turned on or off from the **Audio settings** screen.

⊇ Customized Features P. 302

Preset Memory

To store a channel:


- 1. Tune to the selected channel.
- 2. Press and hold the preset number for the station you want to store.
- 3. Select OK.

You can also store a channel by the following procedure.

- 1. Tune to the selected channel.
- 2. Select the open/close icon to display a list.
- 3. Select the **Preset** tab.
- **4.** Select and hold the preset number for the station you want to store.

■ Multi-channel preset (for music channels only)

You can store up to four of your preferred music channels per preset.



- **1.** Tune a station.
- 2. Select the open/close icon to display a list.
- **3.** Select the **Preset** tab.
- **4.** Select and hold the preset number you want to add a music channel.
 - A message appears if there are no available presets.
- 5. Select Combine.

You can store 12 SiriusXM® channels into the preset memory.

■ Listening to Featured Channels

Suggested channel listing received from SiriusXM® can be displayed and selected.

- **1.** Select the open/close icon to display a channel list.
- 2. Select the Channel tab.
- **3.** Select the featured channel list title you want to listen to.
 - ▶ The selected channel list of the title is displayed.
- **4.** Select the channel.

∑Listening to Featured Channels

Up to three featured channels by SiriusXM® can be displayed.

Featured channel lists are at the top of the channel list.

Replay Function

The system can record up to the last 60 minutes of your currently tuned channel's broadcast, as well as the last 30 minutes of your preset channel's broadcast, starting from the moment you turn the vehicle on. If you tuned to a preset channel, the system records up to 60 minutes of a broadcast instead of up to 30 minutes. You can rewind and replay the last 30 or 60 minutes of a broadcast.

- 1. Select 🖳
- 2. Select Playback.
- **3.** Move the time marker to the position you want to replay.

To play or pause on playback mode:

- 1. Select 🖳.
- 2. Select Play/Pause.

■ Returning to real-time broadcast


- 1. Select 🖳
- 2. Select Go to Live

■ Replay Function

The system starts storing broadcast in memory when the power mode is turned ON. You can go back to the program from that point.

You can no longer replay any program once the power mode is turned off as it erases memory. You can check how long the program has been stored in memory from the audio/information screen.

After 30 or 60 minutes of recording the system will automatically start deleting the oldest data.



(A): Shows how much time the replayed segment is behind the real-time broadcast

- (B): Replayed segment
- (C): Length stored in memory

■ Live Sports Alert

While listening to other channels, you can receive sports alerts such as scores from the games of your favorite teams.

■ To set up a favorite team



- 1. Select
- **2.** Select **Settings**.
- 3. Select Audio.
- 4. Select Sports Flash Setup.
- 5. Select Favorite Team.
- 6. Select a team.

■ To set up an alert message

- 1. Select .
- 2. Select Settings.
- 3. Select Audio.
- 4. Select Sports Flash Setup.
- **5.** Select **Interrupt**.
- 6. Select On(one time) or On(continue).

∑Live Sports Alert

The sports alert function is available in SiriusXM® mode only.

∑To set up a favorite team

Sports alerts cut in only when SiriusXM® mode is on. Selecting **On(one time)** from the customize settings disables the alert feature next time you turn the power mode to ON.

Customized Features P. 302

You can also set up a favorite team by the following procedure.

- 1. Select Audio.
- 2. Select
- 3. Select **Setting**.
- 4. Select **Sports Flash Setup**.

■ To set up an alert beep

- 1. Select
- 2. Select Settings.
- 3. Select Audio.
- 4. Select Sports Flash Setup.
- **5.** Select **Interrupt Beep**.
- 6. Select On.

■ Traffic and Weather Information

You can receive traffic and weather information.

- 1. Select
- 2. Select Settings.
- 3. Select Audio.
- 4. Select Traffic & Weather Setup.
- **5.** Select the region.
 - ▶ When you do not want to receive the information, select **Unregistered**.

Scan

Sample each channel on the selected mode for 10 seconds.

- 1. Select Scan.
- 2. Select Scan Channels.
 - ▶ You can select the desired channel by songs using **Scan Songs in Preset**.

To turn off scan, select **Cancel Scan**.

■To set up an alert beep

You can also set up a alert beep by the following procedure.

- 1. Select Audio.
- 2. Select 🖳.
- 3. Select **Setting**.
- 4. Select Sports Flash Setup.

▼Traffic and Weather Information

The traffic and weather information function at SiriusXM® mode only.

You can also set up the traffic and weather information by the following procedure.

- Select Audio.
- 2. Select 🖳.
- 3. Select **Setting**.
- 4. Select Traffic & Weather Setup.

≫Scan

The "Scan Songs in Preset" function is based on TuneScan™ technology of SiriusXM®.


The "Featured Channels" function is based on Featured Favorites™ technology of SiriusXM®.

TuneScan[™] and Featured Favorites[™] are registered trademarks of SiriusXM® Radio. Inc.

Playing an iPod

Connect the iPod using your dock connector to the USB port, then select the iPod mode

■ USB Port(s) P. 199



^{*1:}Some or all of the lists may not be displayed.

263

■ How to Select a Song from the Music Search List



1. Select and select **Music Search**.

2. Select the items on that menu.

▶ Playing an iPod

Available operating functions vary on models or versions. Some functions may not be available on the vehicle's audio system.

If there is a problem, you may see an error message on the audio/information screen.

iPod/USB Flash Drive P. 293

If you operate any music app on your iPhone/iPod while the phone is connected to the audio system, you may no longer be able to operate the same app on the audio/information screen.

Reconnect the device if necessary.

If an iPhone is connected via Apple CarPlay, the iPod/ USB source is unavailable and audio files on the phone can only be played within Apple CarPlay.

■ How to Select a Play Mode

You can select shuffle and repeat modes when playing a file.

Select a play mode.



■ To turn off a play mode

Select the mode you want to turn off.

Play Mode Menu Items

Shuffle All Songs: Plays all available files in a selected list (playlists, artists, albums, songs, podcasts, genres, composers, or audiobooks) in random order.

Shuffle Albums: Plays all available albums in a selected list (playlists, artists, albums, songs, podcasts, genres, composers, or audiobooks) in random order.


Repeat Song: Repeats the current track.

Models with navigation system

Song By Voice™ (SBV)

Use SBV to search for and play music from your USB flash drive or iPod using voice commands.

■ To enable SBV




- 1. Select
- 2. Select Settings.
- 3. Select System.
- **4.** Select the **Voice Recog.** tab.
- **5.** Select **Song by Voice**.
- **6.** Select **On** or **Off**.

Song By Voice™ (SBV)

Setting options:

- On (factory default): Song By Voice™ commands are available.
- Off: Disable the feature.

■ Searching for music using SBV



- **1.** Set the **Song by Voice** setting to **On**.
- 2. Press the (Talk) button and say "Music Search" to activate the SBV feature for the USB flash drive and iPod.
- **3.** Then, say a next command.
 - Example 1: Say "(List) 'Artist A'" to view a list of songs by that artist. Select the desired song to start playing.
 - Example 2: Say "Play 'Artist A'" to start playing songs by that artist.
- **4.** To cancel SBV, press the (hang-up/back) button on the steering wheel. The selected song continues playing.

Once you have canceled this mode, you need to press the 🔊 button and say "Music Search" again to re-activate this mode.

Searching for music using SBV

Song By Voice™ Commands List

Song By Voice Commands P. 251

NOTF:

Song By Voice™ commands are available for tracks stored on the USB flash drive or iPod.

You can add phonetic modifications of difficult words so that it is easier for SBV to recognize artists, songs, albums, and composers in voice commands.

▶ Phonetic Modification P. 268

SBV is not available when using Apple CarPlay. Use Siri Eyes Free instead.

■ Phonetic Modification

Add phonetic modifications of difficult or foreign words so that it is easier for SBV to recognize artists, songs, albums, and composers in voice commands when searching for music on the USB flash drive or iPod.




- 1. Select
- 2. Select Settings.
- 3. Select System.
- **4.** Select the **Voice Recog.** tab.
- 5. Select Song by Voice Phonetic Modification.
- 6. Select New Modification.
- 7. Select **USB** or **iPod**.

>> Phonetic Modification

Phonetic Modification is grayed out when Song By Voice is set to Off.

You can store up to 2,000 phonetic modification items.



- 8. Select the item to modify (e.g., Artist).
 - ► The list of the selected item appears on the screen.
- **9.** Select an entry to modify.
 - ► The pop-up menu appears on the screen.
 - ➤ The listen to the current phonetic modification, select Play.
 - To delete the current phonetic modification, select **Delete**.

10.Select **Modify**.

11. Select the phonetic spelling you want to use (e.g., "Artist A") when prompted.

12.Select OK.

► The artist "No Name" is phonetically modified to "Artist A." When in the SBV mode, you can press the [©] (Talk) button and use the voice command "Play 'Artist A'" to play songs by the artist "No Name"


U.S. models

Playing Pandora®*

Your audio system allows you to listen to music from the Pandora® app on a compatible smartphone.

This function is available when the phone is paired and connected to the vehicle's *Bluetooth*[®] HandsFreeLink[®] (HFL) system, or with an iPhone, you can connect using your USB cable to the USB port.

- Phone Setup P. 364
- **USB Port(s)** P. 199



- *1:Some or all of the lists may not be displayed.
- * Not available on all models

≫Playing Pandora® *

Pandora®, the Pandora logo, and the Pandora trade dress are trademarks or registered trademarks of Pandora Media, Inc., used with permission. Pandora is only available in certain countries. Visit the Pandora website for more information.

To find out if your phone is compatible with this feature, visit www.handsfreelink.honda.com, or call 1-888-528-7876.

To use this service in your vehicle, the Pandora® app must first be installed on your phone. Visit www.pandora.com. for more information.

Pandora® is free, personalized radio that plays music and comedy you'll love. Just start with the name of one of your favorite artists, songs, comedians or composers and Pandora® will create a custom station that plays similar tracks. Pandora® also features hundreds of genre stations ranging from Dubstep to Smooth Jazz to Power Workout.

If you cannot operate Pandora® through the audio system, it may be streaming through *Bluetooth*® Audio. Make sure Pandora® mode on your audio system is selected.


If your phone is connected to Android Auto, Pandora is only available through the Android Auto interface. Visit the Android Auto website to check compatibility.

■ Pandora® Menu

You can operate some of the Pandora® menu items from your vehicle's audio system. The available items are:

- Bookmark
- Station List
- New Station
- Switch USB device
- Sound
- Setting

■ Operating a menu item



- 1. Select 里.
- 2. Select an item.

≫Pandora® Menu

Available operating functions vary on software versions. Some functions may not be available on the vehicle's audio system.

If there is a problem, you may see an error message on the audio/information screen.

Pandora®* P. 294

Pandora® may limit the total number of skips allowed on the service. If you dislike a track after the skip limit has been reached, your feedback will be saved but the current track will continue to play.


To change stations, activate the Pandora® menu, select **Station List**, and then select a new station. It also changes stations on the main Pandora® screen.

* Not available on all models

Playing Aha™

AhaTM can be displayed and operated on the audio/information screen when your smartphone is connected to the audio system by Wi-Fi or through Bluetooth[®] with the HondaLink[®] app downloaded to your smartphone.

- **₩i-Fi Connection** P. 283
- HondaLink® P. 278



Playing Aha[™]

AhaTM by Harman is a cloud-based service that organizes your favorite web content into live radio stations. You can access podcasts, internet radio, location-based services, and audio updates from social media sites.

Available operating functions vary on software versions. Some functions may not be available on the vehicle's audio system.

The menu items vary depending on the station you selected.

You must have a previously set up Aha^{TM} account prior to using the service in your vehicle. Visit www.aharadio.com for more information.

You want to select another source, select **AUDIO** on the upper left of the screen. The source select screen will appear. Select the source you want.


When Apple CarPlay or Android Auto is connected to the audio system, Aha[™] can be accessed even without a Wi-Fi connection.

Playing a USB Flash Drive

Your audio system reads and plays sound files on a USB flash drive in either MP3, WMA, or AAC*1 format.

Connect your USB flash drive to the USB port, then select the USB mode.

■ USB Port(s) P. 199



- *1:Only AAC format files recorded with iTunes are playable on this unit.
- *2:Some or all of the lists may not be displayed.

■ How to Select a File from the Music Search List



1. Select and select **Music Search**.

2. Select Music.

3. Select a folder

4. Select a track.

▶ Playing a USB Flash Drive

Use the recommended USB flash drives.

■ General Information on the Audio System P. 296

WMA files protected by digital rights management (DRM) cannot be played.

The audio system displays **Unplayable File**, then skips to the next file.

If there is a problem, you may see an error message on the audio/information screen.

iPod/USB Flash Drive P. 293


■ How to Select a Play Mode

You can select scan, repeat, and random modes when playing a file.



■ Scan

- 1. Select 🖭
- 2. Select Scan.
- **3.** Select a play mode.



■ Random/Repeat

Select a play mode.

■ To turn off a play mode

To turn off Scan, select are or **Cancel**.

To turn off **Random/Repeat**, select the mode again.

Play Mode Menu Items

Scan

Scan Folders: Provides 10-second sampling of the

first file in each of the main folders.

Scan Tracks: Provides 10-second sampling of all files in the current folder.

Random/Repeat

Random in Folder: Plays all files in the current

folder in random order.

Random All Tracks: Plays all files in random order. **Repeat Folder**: Repeats all files in the current folder.


Repeat Track: Repeats the current file.

Playing Bluetooth® Audio

Your audio system allows you to listen to music from your *Bluetooth*-compatible phone.

This function is available when the phone is paired and connected to the vehicle's *Bluetooth*® HandsFreeLink® (HFL) system.

Phone Setup P. 364



*1:Depending on the *Bluetooth*® device you connect, some or all of the lists may not be displayed.

Not all *Bluetooth*-enabled phones with streaming audio capabilities are compatible.
To check if your phone is compatible, visit http://www.handsfreelink.com/Honda/.

It may be illegal to perform some data device functions while driving.

Only one phone can be used with HFL at a time. When there are more than two paired phones in the vehicle, the first paired phone the system finds is automatically connected.

The connected phone for *Bluetooth*® Audio can be different

If more than one phone is paired to the HFL system, there may be a delay before the system begins to play.

In some cases, the name of the artist, album, or track may not appear correctly.

Some functions may not be available on some devices.

If a phone is currently connected via Apple CarPlay or Android Auto, *Bluetooth*® Audio from that phone is unavailable. However, a second previously paired phone can stream *Bluetooth*® Audio by selecting **Connect** from the **Bluetooth Device List**.

■ To Play Bluetooth® Audio Files



1. Make sure that your phone is paired and connected to the system.


Phone Setup P. 364

2. Select the *Bluetooth®* Audio mode.

If the phone is not recognized, another HFL-compatible phone, which is not compatible for *Bluetooth*® Audio, may already be connected.

■ To pause or resume a file Select the play icon or pause icon.

■ Searching for Music



- 1. Select 🖳
- 2. Select Music Search.
- **3.** Select a search category (e.g., Albums).
- 4. Select an item.
 - ► The selection begins playing.

∑To Play Bluetooth® Audio Files

To play the audio files, you may need to operate your phone. If so, follow the phone maker's operating instructions.

Switching to another mode pauses the music playing from your phone.

You can change the connected phone in the *Bluetooth®* settings on the **Audio menu** screen by the following procedure.

- 1. Select 🖭.
- 2. Select **Setting**.

Searching for Music

Depending on the *Bluetooth*® device you connect, some or all of the lists may not be displayed.

HondaLink®

HondaLink® connects you to the latest information from Honda. You can connect your phone wirelessly through Wi-Fi or *Bluetooth*®.

₩i-Fi Connection P. 283

Phone Setup P. 364

■ HondaLink® Menu



■ Places*

Displays restaurants, gas stations, Honda dealer, and so on. You can also navigate to the found locations via the navigation.

■ Vehicle

Displays instruction messages when the vehicle needs service.

■ Help & Support

Displays tips for vehicle usage, and get support via road side or customer service center.

>> HondaLink®

The HondaLink® connect app is compatible with most iPhone and Android phones.

Some cell phone carriers charge for tethering and smartphone data use. Check your phone's data subscription package.

When Apple CarPlay or Android Auto is connected to the audio system, HondaLink® can be accessed even without a Wi-Fi connection

■ Messages from Honda

Displays helpful and important information from Honda.

■ Weather

Displays a weekly five-day weather forecast for any location you want. You can change the ZIP Code at any time.

■ To Set Up to Connect HondaLink® Service

Use the following procedure to connect to HondaLink® service.

■ To enable the HondaLink® service



- 1. Select
- 2. Select Settings.
- 3. Select Info
- **4.** Select the **HondaLink** tab.
- 5. Select Diagnostics & Location Data.
- **6.** Select **On**.

You need to allow the consent of the location service to enable the HondaLink® service.



Enable once: Allows only one time. (Prompt shows again next time.)

Always Enable: Allows anytime. (Prompt

does not show again.)

Cancel: Does not allow this consent.

■ To link with HondaLink®



You can see the **Connection Guide** screen after launching HondaLink®. If you do not need this guide, select check-box and select **OK**.

■ Vehicle Information and Message from Honda Tips

You can check the messages that are received guickly in the shortcut operation.



- **1.** A message appears and notifies you of a new message on the header area.
 - ► When the message is received, a notification ring can be heard.

2. A message icon is continuously displayed in the header area until the new message is read.



3. From the top of the screen, swipe down to see the messages.

4. Select a new message to open.

283

Wi-Fi Connection

You can connect the Display Audio to the Internet using Wi-Fi and browse websites or use online services on the audio/information screen. If your phone has wireless hotspot capabilities, the system can be tethered to the phone. Use the following steps to setup.

■ Wi-Fi mode (setting for the first time)



- 1. Select
- 2. Select Settings.
- 3. Select Bluetooth/Wi-Fi.
- 4. Select the Wi-Fi tab.
- **5.** Select **Wi-Fi On/Off Status**, then **On**.
- 6. Select Wi-Fi Device List.
 - ► Make sure your phone's Wi-Fi setting is in access point (tethering) mode.
 - Select the phone you want to connect to the system.
 - ► If you do not find the phone you want to connect in the list, select **Scan**.

7. Select Connect.

- ► If needed, enter a password for your phone and select **OK**.
- When the connection is successful, the icon is displayed on the top of the screen.
- **8.** Select to go back to the home screen.

You cannot go through the setting procedure while a vehicle is moving. Park in a safe place to setup the Wi-Fi connection.

Some cell phone carriers charge for tethering and smartphone data use. Check your phone's data subscription package.

Check your phone manual to find out if the phone has Wi-Fi connectivity.

You can confirm whether Wi-Fi connection is on or off with the picon on **Wi-Fi Device List**. Network speed will not be displayed on this screen.



■ Wi-Fi mode (after the initial setting has been made)

Make sure your phone's Wi-Fi setting is in access point (tethering) mode.

Wi-Fi mode (after the initial setting has been made)

iPhone users


You may need to go through an initial setup for Wi-Fi connection again after you boot your phone.

Siri Eyes Free

You can talk to Siri using the [6] (Talk) button on the steering wheel when your iPhone is paired to the *Bluetooth*® HandsFreeLink® (HFL) system.

▶ Phone Setup P. 364

■ Using Siri Eyes Free



Siri Eyes Free

Siri is a trademark of Apple Inc.

Check Apple Inc. website for features available for Siri.

We recommend against using Siri other than in Siri Eyes Free while operating a vehicle.

≥ Using Siri Eyes Free


Some commands work only on specific phone features or apps.

Apple CarPlay

If you connect an Apple CarPlay-compatible iPhone to the system via USB, you can use the audio/information touch screen, instead of the iPhone display, to make a phone call, listen to music, view maps (navigation), and access messages.

■ USB Port(s) P. 199

■ Apple CarPlay Menu



■ Phone

Access the contact list, make phone calls, or listen to voice mail.

■ Messages

Check and reply to text messages, or have messages read to you.

■ Music

Play music stored on your iPhone.

■ Apple CarPlay

Only iPhone5 or newer versions with iOS 8.4 or later are compatible with Apple CarPlay.

Park in a safe place before connecting your iPhone to Apple CarPlay and when launching any compatible apps.

To use Apple CarPlay, connect the USB cable to the front USB port. The USB port located in the center console storage will not enable Apple CarPlay operation.

USB Port(s) P. 199

To directly access the Apple CarPlay phone function, press **Phone** on the home screen. While connected to Apple CarPlay, calls are only made through Apple CarPlay. If you want to make a call with HandsFreeLink, turn Apple CarPlay OFF or detach the USB cable from your iPhone.

Setting Up Apple CarPlay P. 287

When your iPhone is connected to Apple CarPlay, it is not possible to use the *Bluetooth*® Audio or *Bluetooth*® HandsFreeLink®. However, other previously paired phones can stream audio via *Bluetooth*® while Apple CarPlay is connected.

Phone Setup P. 364

For details on countries and regions where Apple CarPlay is available, as well as information pertaining to function, refer to the Apple homepage.

■ Maps

Display Apple CarPlay map and use the navigation function just as you would on your iPhone.


Models with navigation system

Only one navigation system (pre-installed navigation or Apple CarPlay) can give directions at a time. When you are using one system, directions to any prior destination set on the other system will be canceled, and the system you are currently using will direct you to your destination.

Setting Up Apple CarPlay

After you have connected your iPhone to the system via USB, use the following procedure to set up Apple CarPlay. Use of Apple CarPlay will result in the transmission of certain user and vehicle information (such as vehicle location, speed, and status) to your iPhone to enhance the Apple CarPlay experience. You will need to consent to the sharing of this information on the Display Audio Screen.

■ Enabling Apple CarPlay



Enable Once: Allows only once. (Prompt shows again next time.)

Always Enable: Allows anytime. (Prompt

does not show again.)

Cancel: Does not allow this consent.

You may change the consent settings under the **Smartphone** settings menu.

■ Apple CarPlay

Apple CarPlay Operating Requirements & Limitations

Apple CarPlay requires a compatible iPhone with an active cellular connection and data plan. Your carrier's rate plans will apply.

Changes in operating systems, hardware, software, and other technology integral to providing Apple CarPlay functionality, as well as new or revised governmental regulations, may result in a decrease or cessation of Apple CarPlay functionality and services. Honda cannot and does not provide any warranty or guarantee of future Apple CarPlay performance or functionality.

It is possible to use 3rd party apps if they are compatible with Apple CarPlay. Refer to the Apple homepage for information on compatible apps.

Setting Up Apple CarPlay

You can also use the method below to set up Apple CarPlay:


Select HOME—Settings—Smartphone—Apple CarPlay

Use of user and vehicle information

The use and handling of user and vehicle information transmitted to /from your iPhone by Apple CarPlay is governed by the Apple iOS terms and conditions and Apple's Privacy Policy.

■ Operating Apple CarPlay with Siri Eyes Free

Press and hold the talk button to activate Siri Eyes Free.



■ Operating Apple CarPlay with Siri Eyes Free

Below are examples of questions and commands for Siri Eyes Free.

- What movies are playing today?
- Call dad at work.
- What song is this?
- How's the weather tomorrow?
- Read my latest email.
- Find a table for four tonight in Chicago.

For more information, please visit www.apple.com/ios/siri.

Android Auto

When you connect an Android phone to the Display Audio system via USB, Android Auto is automatically initiated. When connected via Android Auto, you can use the audio/information touch screen to access the Phone, Google Maps (Navigation), Google Play Music, and Google Now functions. When you first use Android Auto, a tutorial will appear on the screen.

We recommend that you complete this tutorial while safely parked before using Android Auto.

■ USB Port(s) P. 199

▶ Auto Pairing Connection P. 291

To use Android Auto, you need to download the Android Auto app from Google Play to your smartphone.

Only Android 5.0 (Lollipop) or later versions are compatible with Android Auto.

Bluetooth A2DP cannot be used with Android Auto phone.

Park in a safe place before connecting your Android phone to Android Auto and when launching any compatible apps.

To use Android Auto, connect the USB cable to the front USB port. The USB port in the center console storage will not enable Android Auto operation.

■ USB Port(s) P. 199


To directly access the Android Auto phone function, press **Phone** on the home screen. While connected to Android Auto, calls are only made through Android Auto. If you want to make a call with HandsFreeLink, turn Android Auto OFF or detach the USB cable from your Android phone.

■ Auto Pairing Connection P. 291

When your Android phone is connected to Android Auto, it is not possible to use the *Bluetooth*® Audio or *Bluetooth*® HandsFreeLink®. However, other previously paired phones can stream audio via *Bluetooth*® while Android Auto is connected.

▶ Phone Setup P. 364

Android Auto Menu



Maps (Navigation)

Display Google Maps and use the navigation function just as you would with your Android phone. When the vehicle is in motion, it is not possible to make keyboard entries. Stop the vehicle in a safe location to undertake a search or provide other inputs.

Models with navigation system

Only one navigation system (pre-installed navigation or Android Auto) can give directions at a time. When you are using one system, directions to any prior destination set on the other system will be canceled, and the system you are currently using will direct you to your destination.

The audio/Information screen shows you turn-by turn driving directions to your destination.

2 Phone (Communication)

Make and receive phone calls as well as listen to voicemail.

3 Google Now (Home screen)

Display useful information organized by Android Auto into simple cards that appear just when they're needed.

>> Android Auto

For details on countries and regions where Android Auto is available, as well as information pertaining to function, refer to the Android Auto homepage.

Android Auto Operating Requirements & Limitations

Android Auto requires a compatible Android phone with an active cellular connection and data plan. Your carrier's rate plans will apply.

Changes in operating systems, hardware, software, and other technology integral to providing Android Auto functionality, as well as new or revised governmental regulations, may result in a decrease or cessation of Android Auto functionality and services. Honda cannot and does not provide any warranty or guarantee of future Android Auto performance or functionality.

It is possible to use 3rd party apps if they are compatible with Android Auto. Refer to the Android Auto homepage for information on compatible apps.

4 Music and audio

Play Google Play Music and music apps that are compatible with Android Auto. To switch between music apps, press this icon.


- **6** Go back to the Home Screen.
- **6** Voice

Operate Android Auto with your voice.

Auto Pairing Connection

When you connect an Android phone to the unit via USB, Android Auto is automatically initiated.

■ Enabling Android Auto



 $\textbf{Enable Once} : \textbf{Allows only once}. \ (\textbf{Prompt}$

shows again next time.)

Always Enable: Allows anytime. (Prompt

does not show again.)

Cancel: Does not allow this consent.

You may change the consent settings under the **Smartphone** settings menu.

Enabling Android Auto

Only initialize Android Auto when you safely parked. When Android Auto first detects your phone, you will need to set up your phone so that auto pairing is possible. Refer to the instruction manual that came with your phone.

You can use the method below to change Android Auto settings after you have completed the initial setup:

Select HOME→Settings→Smartphone→Android Auto

Use of user and vehicle information

The use and handling of user and vehicle information transmitted to /from your phone by Android Auto is governed by the Google's Privacy Policy.

Continued 291

Operating Android Auto with Voice Recognition

Press and hold the talk button to operate Android Auto with your voice.



■ Operating Android Auto with Voice Recognition

Below are examples of commands you can give with voice recognition:

- Reply to text.
- Call my wife.
- Navigate to Honda.
- Play my music.
- Send a text message to my wife.
- Call flower shop.

For more information, please refer to the Android Auto homepage.

You can also activate the voice recognition function by pressing the 4 icon in the upper-right corner of the screen.

Audio Error Messages

iPod/USB Flash Drive

If an error occurs while playing an iPod or USB flash drive, you may see the following error messages. If you cannot clear the error message, contact a dealer.

Error Message	Solution
USB Error*1, *2	Appears when there is a problem with the audio system. Check if the device is compatible with the audio system.
Bad USB Device Please Check Owners Manual* ¹ The connected USB device has a problem. See Owner's Manual* ²	Appears when an incompatible device is connected. Disconnect the device. Then turn the audio system off, and turn it on again. Do not reconnect the device that caused the error.
Unsupported Ver*1 Unsupported Version*2	Appears when an unsupported iPod is connected. If it appears when a supported iPod is connected, update the iPod software to the newer version.
Retry Connection*1 Connect Retry*2	Appears when the system does not acknowledge the iPod. Reconnect the iPod.
Unplayable File*1, *2	Appears when the files in the USB flash drive are copyright protected or an unsupported format. This error message appears for about three seconds, then plays the next song.
USB No Song*1 iPod No Song*1 No Data*2	Appears when the iPod is empty. USB flash drive Appears when the USB flash drive is empty or there are no MP3, WMA, or AAC files in the USB flash drive. iPod and USB flash drive Check that compatible files are stored on the device.
Unsupported*1,*2	Appears when an unsupported device is connected. If it appears when a supported device is connected, reconnect the device.

^{*1:}Models with color audio system *2:Models with Display Audio

Pandora®*

If an error occurs while playing Pandora®, you may see the following error messages. If you cannot clear the error message, contact a dealer.

Error Message	Solution
To begin listening, select a station from the Stations list.	Appears when there is no station list on the device. Use the device to create a station.
Unable to rate track. Please try again. Skip limit reached.	Appears when you try to skip a song or select Like/Dislike over the predetermined number of times in an hour.
Unable to play Pandora. Please try again later. Unable to retrieve a track explanation. Please try again later. Unable to create bookmark. Please try again later.	Appears when the commanded operation fails. Try again later.
No Data	Appears when no data is available with Pandora® activated. Reboot the app and reconnect the device.
Pandora App version is not supported	Appears when Pandora® version is not supported. Update Pandora® to the latest version.
Unable to complete the operation. Please try again later.	Appears when the Pandora® server is in maintenance. Try again later.
Unable to connect Pandora. When stopped, check your mobile phone	Appears when Pandora® is unable to play music. Check your device.
Unable to connect Pandora. When stopped, check your mobile phone	Appears when Pandora® app is not installed on your device. Install Pandora® app to your device.

Android/Apps

If an error occurs while using the audio system or apps, you may see the following error messages. If you cannot clear the error message, contact a dealer.

Error Message*1	Solution
Unfortunately, **** has stopped.	Error has occurred within app, select OK on the screen to close the app.
**** is not responding. Would you like to close it?	App is not responding. Select Wait if you can wait for a response from app a little longer. If it does not respond even if you keep waiting, select OK to close the app and start it up. If the error message continues, perform Factory Data Reset . Defaulting All the Settings P. 332

^{*1:****}part is variable characters, and will change depending upon where an error occurs.

General Information on the Audio System

SiriusXM® Radio Service*

Subscribing to SiriusXM® Radio

- **1.** You need your radio ID ready before registering for subscription. To see the ID on the screen, select **Channel** 0.
- 2. Have your radio ID ready, and either call SiriusXM® or visit the SiriusXM® website to subscribe.

Receiving SiriusXM® Radio

Switch to the SiriusXM® mode by using the **SOURCE** button on the steering wheel, or through the audio/information screen, and stay in this mode for about 30 minutes until the service is activated. Make sure your vehicle is in an open area with good reception.

SiriusXM® Radio Display Messages

Channel Not Subscribed:

You are not subscribed to the channel selected.

Subscription Update:

SiriusXM® radio is receiving information update from the network.

Channel Not Available:

No such channel exists, or the artist or title information is unavailable.

No Signal:

The signal is too weak in the current location.

Antenna Disconnected:

The SiriusXM® antenna is disconnected. Contact a dealer.

Subscribing to SiriusXM® Radio

Contact Information for SiriusXM® Radio:

- U.S.: SiriusXM® Radio at www.siriusxm.com or 1-800-852-9696
- Canada: SiriusXM® Canada at www.xmradio.ca, or 1-877-209-0079

■ Receiving SiriusXM® Radio

The SiriusXM® satellites are in orbit over the equator; therefore, objects south of the vehicle may cause satellite reception interruptions. Satellite signals are more likely to be blocked by tall buildings and mountains the farther north you travel from the equator.

You may experience reception problems under the following circumstances:

- In a location with an obstruction to the south of your vehicle.
- In tunnels
- On the lower level of a multi-tiered road
- Large items carried on the roof rack

Compatible iPod, iPhone, and USB Flash Drives

■ iPod and iPhone Model Compatibility

Model

iPod (5th generation)

iPod classic 80GB/160GB (launch in 2007)

iPod classic 120GB (launch in 2008)

iPod classic 160GB (launch in 2009)

iPod nano (1st to 7th generation) released between 2005 and 2012 iPod touch (1st to 5th generation) released between 2007 and 2012

iPhone 3G/iPhone 3GS/iPhone 4/iPhone 4S/iPhone 5c*1/iPhone 5s*1/iPhone 6*1/iPhone 6 Plus*1

USB Flash Drives

- A USB flash drive of 256 MB or higher is recommended.
- Some digital audio players may not be compatible.
- Some USB flash drives (e.g., a device with security lockout) may not work.
- Some software files may not allow for audio play or text data display.
- Some versions of MP3, WMA, or AAC formats may be unsupported.

This system may not work with all software versions of these devices.

™USB Flash Drives

Files on the USB flash drive are played in their stored order. This order may be different from the order displayed on your PC or device.

^{*1:}Models with Display Audio

Legal Information on Apple CarPlay/Android Auto

OWNER'S MANUAL LICENSE/LIABILITY STATEMENTS

USE OF APPLE CARPLAY IS SUBJECT TO YOUR AGREEMENT TO THE CARPLAY TERMS OF USE, WHICH ARE INCLUDED AS PART OF THE APPLE IOS TERMS OF USE. IN SUMMARY, THE CARPLAY TERMS OF USE DISCLAIM APPLE AND ITS SERVICE PROVIDERS' LIABILITY IF THE SERVICES FAIL TO PERFORM CORRECTLY OR ARE DISCONTINUED, STRICTLY LIMIT APPLE AND ITS SERVICE PROVIDERS' OTHER LIABILITIES, DESCRIBE THE KINDS OF USER INFORMATION (INCLUDING, FOR EXAMPLE, VEHICLE LOCATION, VEHICLE SPEED, AND VEHICLE STATUS) BEING GATHERED AND STORED BY APPLE AND ITS SERVICE PROVIDERS, AND DISCLOSE CERTAIN POSSIBLE RISKS ASSOCIATED WITH THE USE OF CARPLAY, INCLUDING THE POTENTIAL FOR DRIVER DISTRACTION. SEE APPLE'S PRIVACY POLICY FOR DETAILS REGARDING APPLE'S USE AND HANDLING OF DATA UPLOADED BY CARPLAY.

USE OF ANDROID AUTO IS SUBJECT TO YOUR AGREEMENT TO THE ANDROID AUTO TERMS OF USE WHICH MUST BE AGREED TO WHEN THE ANDROID AUTO APPLICATION IS DOWNLOADED TO YOUR ANDROID PHONE. IN SUMMARY, THE ANDROID AUTO TERMS OF USE DISCLAIM GOOGLE AND ITS SERVICE PROVIDERS' LIABILITY IF THE SERVICES FAIL TO PERFORM CORRECTLY OR ARE DISCONTINUED, STRICTLY LIMIT GOOGLE AND ITS SERVICE PROVIDERS' OTHER LIABILITIES, DESCRIBE THE KINDS OF USER INFORMATION (INCLUDING, FOR EXAMPLE, VEHICLE LOCATION, VEHICLE SPEED, AND VEHICLE STATUS) BEING GATHERED AND STORED BY GOOGLE AND ITS SERVICE PROVIDERS, AND DISCLOSE CERTAIN POSSIBLE RISKS ASSOCIATED WITH THE USE OF ANDROID AUTO, INCLUDING THE POTENTIAL FOR DRIVER DISTRACTION. SEE GOOGLE'S PRIVACY POLICY FOR DETAILS REGARDING GOOGLE'S USE AND HANDLING OF DATA UPLOADED BY ANDROID AUTO.

■ DISCLAIMER OF WARRANTIES; LIMITATION ON LIABILITY

YOU EXPRESSLY ACKNOWLEDGE AND AGREE THAT USE OF APPLE CARPLAY OR ANDROID AUTO ("THE APPLICATIONS") IS AT YOUR SOLE RISK AND THAT THE ENTIRE RISK AS TO SATISFACTORY QUALITY, PERFORMANCE, ACCURACY AND EFFORT IS WITH YOU TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, AND THAT THE APPLICATIONS AND INFORMATION ON THE APPLICATIONS IS PROVIDED "AS IS" AND "AS AVAILABLE." WITH ALL FAULTS AND WITHOUT WARRANTY OF ANY KIND. AND HONDA HEREBY DISCLAIMS ALL WARRANTIES AND CONDITIONS WITH RESPECT TO THE APPLICATIONS AND INFORMATION ON THE APPLICATIONS, EITHER EXPRESS, IMPLIED OR STATUTORY, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES AND/OR CONDITIONS OF MERCHANTABILITY. SATISFACTORY OUALITY. FITNESS FOR A PARTICULAR PURPOSE. ACCURACY. OUIET ENJOYMENT, AND NON-INFRINGEMENT OF THIRD PARTY RIGHTS. NO ORAL OR WRITTEN INFORMATION OR ADVICE GIVEN BY HONDA OR AN AUTHORIZED. REPRESENTATIVE SHALL CREATE A WARRANTY, AS EXAMPLES, AND WITHOUT LIMITATION, HONDA DISCLAIMS ANY WARRANTY REGARDING THE ACCURACY OF DATA PROVIDED BY THE APPLICATIONS. SUCH AS THE ACCURACY OF DIRECTIONS. ESTIMATED TRAVEL TIME, SPEED LIMITS, ROAD CONDITIONS, NEWS, WEATHER, TRAFFIC, OR OTHER CONTENT PROVIDED BY APPLE, GOOGLE, THEIR AFFILIATES, OR THIRD PARTY PROVIDERS; HONDA DOES NOT GUARANTEE AGAINST LOSS OF APPLICATION DATA, WHICH MAY BE LOST AT ANY TIME: HONDA DOES NOT GUARANTEE THAT THE APPLICATIONS OR ANY SERVICES PROVIDED THROUGH THEM WILL BE PROVIDED AT ALL TIMES OR THAT ANY OR ALL SERVICES WILL BE AVAILABLE AT ANY PARTICULAR TIME OR LOCATION. FOR EXAMPLE. SERVICES MAY BE SUSPENDED OR INTERRUPTED WITHOUT NOTICE FOR REPAIR, MAINTENANCE, SECURITY FIXES, UPDATES, ETC., SERVICES MAY BE UNAVAILABLE IN YOUR AREA OR LOCATION. ETC. IN ADDITION. YOU UNDERSTAND THAT CHANGES IN THIRD PARTY TECHNOLOGY OR GOVERNMENT REGULATION MAY RENDER THE SERVICES AND/OR APPLICATIONS OBSOLETE AND/OR UNUSABLE.

TO THE EXTENT NOT PROHIBITED BY LAW, IN NO EVENT SHALL HONDA OR ITS AFFILIATES BE LIABLE FOR PERSONAL INJURY, OR ANY INCIDENTAL, SPECIAL, INDIRECT OR CONSEQUENTIAL DAMAGES WHATSOEVER, INCLUDING, WITHOUT LIMITATION, DAMAGES FOR LOSS OF PROFITS, CORRUPTION OR LOSS OF DATA, FAILURE TO TRANSMIT OR RECEIVE ANY DATA, BUSINESS INTERRUPTION OR ANY OTHER COMMERCIAL DAMAGES OR LOSSES, ARISING OUT OF OR RELATED TO THE APPLICATIONS OR YOUR USE OF OR INABILITY TO USE THE APPLICATIONS OR INFORMATION ON THE APPLICATIONS, HOWEVER CAUSED, REGARDLESS OF THE THEORY OF LIABILITY (CONTRACT, TORT OR OTHERWISE) AND EVEN IF HONDA WERE ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. SOME STATES AND JURISDICTIONS DISALLOW THE EXCLUSION OR LIMITATION OF LIABILITY FOR DAMAGES, SO THESE LIMITATIONS AND EXCLUSIONS MAY NOT APPLY TO YOU. IN NO EVENT SHALL HONDA'S TOTAL LIABILITY TO YOU FOR ALL DAMAGES (OTHER THAN AS MAY BE REQUIRED BY APPLICABLE LAW IN CASES INVOLVING PERSONAL INJURY) EXCEED THE AMOUNT OF FIVE DOLLARS (\$5.00). THE FOREGOING LIMITATIONS WILL APPLY EVEN IF THE ABOVE STATED REMEDY FAILS OF ITS ESSENTIAL PURPOSE.

About Open Source Licenses

To see the open source license information, follow these steps.

Models with color audio system

- 1. Press the MENU/CLOCK button.
- **2.** Rotate $^{\mbox{\tiny{1}}}$ to select **Settings**, then press $^{\mbox{\tiny{2}}}$.
- **3.** Rotate ♥ to select **OSS Licenses**, then press ८.

Models with Display Audio

- 1. Select
- 2. Select Settings.
- 3. Select System.
- 4. Select the Others tab.
- 5. Select **Detail Info**
- 6. Select About device.
- **7.** Select **Legal information**.
- 8. Select Open source licenses.

LICENCE: Copyright © 2001 Bob Trower, Trantor Standard Systems Inc.

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

License information

■ DOLBY DIGITAL

Manufactured under license from Dolby Laboratories. Dolby and the double-D symbol are registered trademarks of Dolby Laboratories.



DTS

For DTS patents, see http://patents.dts.com. Manufactured under license from DTS Licensing Limited. DTS, the Symbol, & DTS and the Symbol together are registered trademarks, and DTS Digital Surround and Neural Surround are trademarks of DTS, Inc. © DTS, Inc. All Rights Reserved.






Customized Features

Use the audio/information screen to customize certain features.

Models with color audio system

■ How to customize

While the vehicle is at a complete stop with the ignition switch in ON III, press the **MENU/CLOCK** button, then select **Settings**. To customize the phone settings, press the button, then select **Phone Setup**.



○ Customized Features

When you customize settings:

• Make sure that the vehicle is at a complete stop.

Continuously variable transmission models

• Shift to P.

Manual transmission models

• Set the parking brake.

➤ How to customize

These indications are used to show how to operate the selector knob.

Rotate 🔯 to select.


Press 🕹 to enter.


To customize other features, select **Settings**, rotate $^{\circ}_{\circ}$, then press $^{\circ}_{\circ}$.


List of customizable options P. 306

■ Customization Flow

Press the MENU/CLOCK button.







■ List of customizable options

Setup Group	Custo	omizable Features	Description	Selectable Settings
Clock Adjustment			Adjust Clock. D Clock P. 122	_
	Bluetooth	Add New Device	Pairs a new phone to HFL, edits and deletes a paired phone, and create a code for a paired phone. Phone Setup P. 339	_
		Connect an Audio Device	Connects, disconnects or pairs a <i>Bluetooth</i> ® Audio device to HFL.	_
Settings	Display Adjustment	Brightness	Changes the brightness of the audio/ information screen.	_
		Contrast	Changes the contrast of the audio/ information screen.	_
		Black Level	Changes the black level of the audio/ information screen.	_
	Rear Camera	Camera Guideline	Selects whether the guidelines come on the audio/information screen.	On*1/Off

^{*1:}Default Setting

Setup Group	Cust	comizable Features	Description	Selectable Settings
	Display Cha	nge	Changes the display type.	Audio*1/Wallpaper
	Wallpaper	Select	Changes the wallpaper type.	Clock*1/Image1/Image2/ Image3
		Import	Imports an image file for a new wallpaper. ☑ Wallpaper Setup P. 208	_
C - 44!		Delete	Deletes an image file for a wallpaper.	lmage1*1/lmage2/lmage3
Settings	Color Theme		Changes the background color of the audio/information screen.	Blue*1/Red/Amber/Gray
	Language		Changes the display language.	English*1/French/Spanish
	Clock Format		Selects the digital clock display from 12H to 24H.	12H*1/24H
	OSS License	S	Shows the legal information.	


^{*1:}Default Setting

Setup Group	Customizable Features		Description	Selectable Settings
		Add New Device	Pairs a new phone to HFL. → Phone Setup P. 339	_
	Bluetooth	Connect a Phone	Pairs a new phone or connects a paired phone to HFL. ▶ Phone Setup P. 339	-
	Setup	Connect an Audio Device	Connects a <i>Bluetooth</i> ® Audio device to HFL.	_
Diama		Disconnect All Devices	Disconnects a paired phone from HFL.	_
Phone		Delete Device	Deletes a paired phone.	_
Setup		Pass-Key	Inputs and changes a code for a paired phone.	_
	Speed Dial		Edits, adds or deletes a speed dial entry. ▶ Speed Dial P. 346	_
	Ringtone		Selects the ring tone.	Fixed*1/Mobile Phone
	Caller ID Info	0	Prioritizes the caller's name or phone number as the caller ID.	Name Priority*1/Number Priority
	System Clea	r	Cancels/Resets all customized items in the Phone Setup group as default.	_

^{*1:}Default Setting

■ How to customize

While the vehicle is at a complete stop with the ignition switch in ON III^{*1} , select IIII, and **Settings**, then select a setting item.



○ Customized Features

When you customize settings:

• Make sure that the vehicle is at a complete stop.

Continuously variable transmission models

• Shift to P.

Manual transmission models

• Set the parking brake.


To customize other features, select **Settings**.

List of customizable options P. 317


Continued


^{*1:} Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

■ Customization flow




- *1: Does not appear when you change the screen interface design.
- *2: Appears only when you change the screen interface design.
- * Not available on all models






- *1: Does not appear when you change the screen interface design. *2: Appears only when you change the screen interface design.




* Not available on all models




^{*1:} Does not appear when you change the screen interface design.

^{*2:} Appears only when you change the screen interface design.



* Not available on all models

315



■ List of customizable options

Setup Group	Cu	stomizable Fe	eatures	Description	Selectable Settings
		Clock/ Wallpaper	Clock		
		Type*1/ Clock Type*2	Wallpaper		
		Clock Adjus	tment		
		Auto Time 2	o Time Zone*		
	Clock	Manual Tim	e Zone*		
Clock		Auto Daylig	ht Saving Time	See Info on P. 318	
		Clock Forma	at	_ _	
		Clock Displa	ay		
		Overlay Clo	ck Location		
		Clock Reset			
	HondaLink	Diagnostic 8	& Location Data		
	Others	Info Screen	Preference		

^{*1:}Does not appear when you change the screen interface design. *2:Appears only when you change the screen interface design.

* Not available on all models

Setup Group		Customizable Features		Description	Selectable Settings
		Clock/ Wallpaper Type* ² / Clock Type* ³	Clock	Changes the clock display type.	Analog/Digital*1/ Small Digital/Off
			Wallpaper	Changes the wallpaper type.Imports an image file for a new wallpaper.Deletes an image file for a wallpaper.	Blank/Galaxy* ¹ / Metallic/Time Zone
		Clock Adjus	tment	Adjusts Clock.	_
		Auto Time Zone	Automatically adjusts the clock when driving through different time zones.	On*1/Off	
Info	Clock	Manual Tim	ne Zone*	Changes the time zone manually.	_
Info	CIOCK		ght Saving Time	Select On to have the GPS automatically adjust the clock to daylight savings time. Select Off to cancel this function.	On*1/Off
		Clock Forma	at	Selects the digital clock display from 12H to 24H.	12H*1/24H
		Clock Displa	ау	Selects whether the clock display comes on.	On*1/Off
		Overlay Clock Location	ck Location	Changes the clock display layout.	Upper Right*1/Upper Left/Lower Right/ Lower Left/Off
		Clock Reset		Resets the clock settings to the factory default.	Yes/No

^{*1:}Default Setting

^{*2:}Does not appear when you change the screen interface design. *3:Appears only when you change the screen interface design.

^{*} Not available on all models

Setup Group	Cus	tomizable Features	Description	Selectable Settings	
	HondaLink	Diagnostic & Location Data	Turns HondaLink® on and off.	On*1/Off	
Info	Others	Info Screen Preference	Selects the top menu when the button is pressed. Info Top- A brief menu pops up. Info Menu- A full menu pops up. Off- A menu does not pop up.	Info Top/Info Menu*¹/Off	
	Rear Camera	Fixed Guideline	Selects whether the fixed guidelines come on the rear camera monitor. Multi-View Rear Camera P. 468	On*1/Off	
		Dynamic Guideline	Selects whether the guidelines adjust to the movement of the steering wheel. Multi-View Rear Camera P. 468	On*1/Off	
Camera				Default	Cancels/Resets all customized items in the Rear Camera setting group as default.
	LaneWatch*	Show with Turn Signal	Selects whether the LaneWatch display comes on when you move the turn signal lever to indicate a right turn.	On*1/Off	
		Display Time after Turn Signal Off	Changes the length of time the LaneWatch display stays on after the turn signal lever returns to the center.	0 second*1/2 seconds	

^{*1:}Default Setting

* Not available on all models

Setup Group	Cust	tomizable Features	Description	Selectable Settings
Camera	LaneWatch*	Reference Line	Selects whether the reference lines come on the LaneWatch monitor.	On*1/Off
Camera		Default	Cancels/Resets all customized items in the LaneWatch group as default.	Yes/No
		Bluetooth On/Off Status	Changes the <i>Bluetooth</i> ® status.	On*1/Off
	Bluetooth	Bluetooth Device List	Pairs a new phone to HFL, edits or deletes a paired phone. ▶ Phone Setup P. 364	_
Bluetooth		Edit Pairing Code	Edits a pairing code. To change the pairing code setting P. 365	Random/Fixed*1
/Wi-Fi	Wi-Fi	Wi-Fi On/Off Status	Changes the Wi-Fi mode.	On/Off*1
		Wi-Fi Device List	Connects, disconnects, or deletes the Wi-Fi device.	_
		Wi-Fi Information	Shows the Wi-Fi information of the head unit.	_
	Default		Cancels/Resets all customized items in the Bluetooth/Wi-Fi group as default.	Yes/No
Smart-	Apple CarPla	у	Sets up the Apple CarPlay connection.	_
phone	Android Auto	0	Sets up the Android Auto connection.	_

^{*1:}Default Setting

Setup Group	Cu	stomizable Features	Description	Selectable Settings
		Bluetooth Device List	Pairs a new phone to HFL, connects or disconnects a paired phone. ▶ Phone Setup P. 364	_
		Edit Speed Dial	Edits, adds or deletes a speed dial entry. Speed Dial P. 370	_
	Phone	none Ring Tone	Selects the ring tone.	Fixed/Mobile Phone*1
		Automatic Phone Sync	Sets a phonebook and call history data to be automatically imported when a phone is paired to HFL.	On*1/Off
Phone		HondaLink Assist	Turns HondaLink Assist on and off.	On/Off*1
		Enable Text/Email	Turns the text/e-mail message function on and off.	On*1/Off
	Text/Email	Select Account	Selects a text or e-mail message account.	
		New Message Notification	Selects whether a pop-up alert comes on the screen when HFL receives a new text/e-mail message.	On/Off
	Default		Cancels/Resets all customized items in the Phone settings group as default.	Yes/No

^{*1:}Default Setting

Setup Group	Customizable Features			Description	Selectable Settings
	FM/AM mode FM/AM	HD Radi	o Mode*	Selects whether the audio system automatically switches to the digital radio waves or receives the analog waves only.	Auto*1/Analog
		RDS INF	0	Turns on and off the RDS information.	On*1/Off
	SiriusXM® mode SXM *	Tune Sta	art	Turns on and off, starts the song from the beginning as you change preset stations.	On*1/Off
Audio		Jetup .	Interrupt	Turns on and off the sports alert function.	Off/On(one time)/ On(continue)*1
Audio			Favorite Team	Selects your favorite sports teams. D Live Sports Alert P. 261	_
			Interrupt Beep	Causes the system to beep when the sports alert is notified.	On*1/Off
		Traffic 8	Weather Setup	Selects the region you want to receive the information.	_
		Multiple Preset	e Channel Mix	Turns multiple channel mix preset on and off.	On/Off*1

^{*1:}Default Setting

Setup Group	Customizable Features		Description	Selectable Settings
Audio	Bluetooth® mode	Bluetooth Device List	Pairs a new phone to HFL, edits or deletes a paired phone. Phone Setup P. 364	-
	Other	iPod or USB mode [Your selected media] Cover Art	Turns the cover art display on and off.	On*¹/Off
		Audio Source Pop-Up	Selects whether the list of selectable audio source comes on when Audio is selected on the home screen.	On/Off*1
	Default		Cancels/Resets all customized items in the Audio settings group as default.	Yes/No
System	Home	Home Screen Edit Order	Changes the HOME screen icon layout.	_
		Menu icon position*2	Changes the position of the menu icons on the Audio , Phone , and Info screen.	_
		Configuration of Instrument Panel	Changes the Instrument Panel screen icon layout.	_
		Tachometer Setting	Turns on and off the tachometer display.	On*1/Off

^{*1:}Default Setting
*2:Appears only when you change the screen interface design.

Setup Group	Customizable Features			Description	Selectable Settings
	Display	Display Settings ay	Brightness	Changes the brightness of the audio/information screen.	_
			Contrast	Changes the contrast of the audio/information screen.	_
			Black Level	Changes the black level of the audio/information screen.	_
System		Backgroun	d Color*2	Changes the background color of the audio/ information screen.	Blue/Amber/Red/ Violet/BlueGreen*1
	Touch		el Sensitivity	Sets the sensitivity of the touch panel screen.	High/Low*1
	Sound/ Beep ——	Guidance \	/olume*	Changes the sound volume. Adjusts the guidance volume of the navigation system.	1~6*1~11
		Text Messa	age Volume	Changes the text/e-mail message reading volume.	1~6*1~11

^{*1:}Default Setting
*2:Does not appear when you change the screen interface design.

Setup Group	Customizable Features		Description	Selectable Settings
		Voice Recog. Volume	Changes the volume of the voice prompt.	1~6*1~11
	Sound /Beep	Meter Volume - List Reading	Changes the list reading volume.	1~6*1~11
		Meter Volume - Alphabetic Reading	Changes the alphabetic reading volume.	1~6*1~11
		Verbal Reminder	Turns the verbal reminders on and off.	On*1/Off
		Beep Volume	Changes the beep volume.	Off/1/2*1/3
	Voice Recog.	One Press Voice Operation	Changes the setting of the 🖟 (Talk) button operation when using the voice operation.	On*1/Off
System		Voice Prompt	Turns the voice prompt on and off.	On*1/Off
		Voice Recog. Volume	Changes the volume of the voice prompt.	1~6*1~11
		Song by Voice*	Turns the Song By Voice™ on and off.	On*1/Off
		Song by Voice Phonetic Modification	Modifies a voice command for music stored in the system or an iPod/iPhone. Phonetic Modification P. 268	_
		Phonebook Phonetic Modification	Modifies a voice command for the phonebook. ▶ Phonetic Modification P. 268	
		Automatic Phone Sync	Sets phonebook and call history data to be automatically imported when a phone is paired to HFL.	On/Off

^{*1:}Default Setting

^{*} Not available on all models

Setup Group		Customizable Fe	atures	Description	Selectable Settings
		Clock/	Clock	See Info on P. 318	
		Wallpaper ⁻ Type ^{*2} / Clock Type ^{*3}	Wallpaper		
		Clock Adjust	tment		
		Auto Time Z	one*		
C	Clock	Manual Time	e Zone*		
System		Auto Daylig	ht Saving Time		
		Clock Forma	t		
	Clock Display				
		Overlay Clo	ck Location	_	
		Clock Reset		-	
	Others	Language		Change the display language.	English*¹/Français/ Español

^{*1:}Default Setting

^{*2:}Does not appear when you change the screen interface design. *3:Appears only when you change the screen interface design.

Setup Group	Customizable Features	Description	Selectable Settings
	Voice Command Tips	Alerts you when manual control of the system is disabled to prevent distraction while driving. Only voice commands are available.	On*¹/Off
	Remember Last Screen*3	Selects whether the device remembers the last screen.	On/Off*1
	Memory Refresh	Turns on the audio system automatically and restores the fragmentation of a memory when the ignition switch is LOCK $\boxed{0}^{*2}$.	On*¹/Off
	Refresh Time Adjustment	Sets the time for Memory Refresh .	
System Other	Swipe Direction	Sets the vertical swipe direction on the audio remote controls.	Normal*1/Invert
	4way Switch Gesture	Turns the vertical swipe direction on the audio remote controls on or off.	On*1/Off
	Volume Gestures Turns the volume swipe dir remote controls on or off.	Turns the volume swipe direction on the audio remote controls on or off.	On*1/Off
	Change Skin	Changes the screen interface design.	Yes/No
	Factory Data Reset	Resets all the settings to their factory default. Defaulting All the Settings P. 332	Yes/No

327

^{*1:}Default Setting
*2:Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.
*3:Does not appear when you change the screen interface design.

Setup Group	Customizable Features		Description	Selectable Settings
	Others	Climate screen timeout	Changes the length of time the climate control display stays on when you press the CLIMATE button.	Never/5 Seconds/10 Seconds*1/20 Seconds
System		Detail Information	Displays the details of the head unit and operating system information.	
	Default		Cancels /Resets all customized items in the System group as default.	Yes/No
	TPMS Calibration*		Cancels/Calibrates the TPMS.	Cancel/Calibrate
	Driver Assist System Setup*	Forward Collision Warning Distance	Changes CMBS™ alert distance.	Long/Normal*1/Short
Vehicle		ACC Forward Vehicle Detect Beep	Causes the system to beep when the system detects a vehicle, or when the vehicle goes out of the ACC range.	On/Off*1
		Lane Keeping Assist Suspend Beep	Causes the system to beep when LKAS is suspended.	On/Off*1
		Road Departure Mitigation Setting	Changes the setting for the road departure mitigation system.	Normal*1/Wide/ Warning Only

^{*1:}Default Setting

Setup Group		Customizable Features	Description	Selectable Settings
	"Trip A" Reset T "Trip B" Reset Ti Adjust Alarm Vo Meter Fuel Efficiency B Setup Turn By Turn Au	Adjust Outside Temp. Display	Adjusts the temperature reading by a few degrees.	-5°F ~ ±0°F*1 ~ +5°F (U.S.) -3°C ~ ±0°C*1 ~ +3°C (Canada)
		"Trip A" Reset Timing	Changes the setting of how to reset trip meter A and average fuel economy A.	When Refueled/IGN Off/Manually Reset*1
		rue: Erneleney Buckinghie	Changes the setting of how to reset trip meter B and average fuel economy B.	When Refueled/IGN Off/Manually Reset*1
			Changes the alarm volume, such as buzzers, warnings, turn signal sound, and so on.	High/Mid*1/Low
Vehicle			Turns the ambient meter feature on and off.	On*1/Off
			Selects whether the turn-by-turn display comes on during the route guidance.	On*1/Off
		New Message Notification	Used to select whether a pop-up alert comes on the screen when HFL receives a new text/e-mail message.	On*1/Off
		Speed/Distance Units	Selects the trip computer units.	mph*1/km/h (U.S.) mph/km/h*1 (Canada)
		Tachometer	Selects whether the tachometer come on the driver information interface.	On*1/Off

^{*1:}Default Setting

^{*} Not available on all models

Setup Group	Customizable Features		Description	Selectable Settings
	Keyless Access Setup*	Remote Start System ON/ OFF*	Turns the remote engine start feature on and off.	On*1/Off
		Door Unlock Mode	Changes which doors unlock when you grab the driver's door handle.	Driver Door Only*1/ All Doors
		Keyless Access Light Flash	Causes some exterior lights to flash when you unlock/lock the doors.	On*1/Off
		Keyless Access Beep	Causes the beeper to sound when you unlock/lock the doors.	On*1/Off
Vehicle	Lighting Setup	Interior Light Dimming Time	Changes the length of time the interior lights stay on after you close the doors.	15seconds/ 30seconds*1/ 60seconds
		Headlight Auto Off Timer	Changes the length of time the exterior lights stay on after you close the driver's door.	0seconds/ 15seconds*1/ 30seconds/ 60seconds
		Auto Light Sensitivity	Changes the timing for the headlights to come on.	Max/High/Mid*1/ Low/Min
		Auto Interior Illumination Sensitivity*	Changes the sensitivity of the brightness of the instrument panel when the headlight switch is in the AUTO position.	Max/High/Mid*1/ Low/Min

^{*1:}Default Setting

^{*} Not available on all models


Setup Group	Cı	ustomizable Features	Description	Selectable Settings
	Lighting Setup	Auto Headlight ON With Wiper ON	Changes the settings for the wiper operation when the headlights automatically come on while the headlight switch is in the AUTO position.	On*1/Off
	Door/ Window Setup	Auto Door Lock	Used to change the setting for when the doors automatically lock.	With Vehicle Speed*1/Shift from P*2/Off
		Auto Door Unlock	Changes the setting for when the doors unlock automatically.	All Doors When Driver's Door Opens' / All Doors When Shifted to Park* 2/ All Doors When Ignitions Switched Off/Off
Vehicle		Key And Remote Unlock Mode	Sets up the driver's door or all the doors to unlock on the first push of the remote.	Driver Door*1/All Doors
		Keyless Lock Answer Back	LOCK/UNLOCK- The exterior lights flash. LOCK (2nd push)- The beeper sounds.	On*1/Off
		Security Relock Timer	Changes the time it takes for the doors to relock and the security system to set after you unlock the vehicle without opening any door.	90seconds/ 60seconds/ 30seconds*1
		Walk Away Auto Lock	Changes the settings for the auto lock function when you walk away from the vehicle.	On/Off*1
	Maintenan	ce Info.	Used to reset the engine oil life display when the maintenance service has been performed.	_

^{*1:}Default Setting *2:Continuously variable transmission models

Models with Display Audio

Defaulting All the Settings

Reset all the menu and customized settings as the factory defaults.



- 1. Select .
- 2. Select Settings.
- 3. Select System.
- **4.** Select the **Others** tab.
- 5. Select Factory Data Reset.
 - A confirmation message appears on the screen.
- **6.** Select **Yes** to reset the settings.
- 7. Select Yes again to reset the settings.
 - ► A confirmation message appears on the screen. Select **OK**.
 - After selecting **OK**, the system will reboot.

Defaulting All the Settings

When you transfer the vehicle to a third party, reset all settings to default and delete all personal data.

If you perform **Factory Data Reset**, it will reset the preinstalled apps to their factory default.

If you perform **Factory Data Reset**, you cannot use the HondaLink® because it becomes off line.


HondaLink® P. 278

Bluetooth® HandsFreeLink® (HFL) allows you to place and receive phone calls using your vehicle's audio system, without handling your cell phone.

Models with color audio system

Using HFL

■ HFL Buttons



(Pick-up) button: Press to go directly to the Phone screen or to answer an incoming call.

(Hang-up/back) button: Press to end a call or to cancel a command.

(Talk) button: Press to call a number with a stored voice tag.

(Phone) button: Press to go directly to the Phone screen.

>> Bluetooth® HandsFreeLink®*

Place your phone where you can get good reception.

To use HFL, you need a *Bluetooth*-compatible cell phone. For a list of compatible phones, pairing procedures, and special feature capabilities:

- U.S.: Visit www.handsfreelink.honda.com, or call 1-888-528 -7876.
- Canada: Visit www.handsfreelink.ca, or call 1-888-528 -7876.

Voice control tips

- Aim the vents away from the ceiling and close the windows, as noise coming from them may interfere with the microphone.
- Press and release the 🖟 button when you want to call a number using a stored voice tag. Speak clearly and naturally after a beep.
- If the microphone picks up voices other than yours, the command may be misinterpreted.
- To change the volume level, use the audio system's volume knob or the remote audio controls* on the steering wheel.

State or local laws may prohibit the operation of handheld electronic devices while operating a vehicle.


If you receive a call while using the audio system, the system resumes its operation after ending the call.

Up to 20 speed dial entries can be stored. If there is no entry in the system, Speed Dial is disabled.

Speed Dial P. 346

Up to 20 call histories can be stored. If there is no call history, Call History is disabled.

■ HFL Status Display



The audio/information screen notifies you when there is an incoming call.

■ Limitations for Manual Operation

Certain manual functions are disabled or inoperable while the vehicle is in motion. You cannot select a grayed-out option until the vehicle is stopped.

Only previously stored speed dial entries can be called using voice commands while the vehicle is in motion.

Speed Dial P. 346

>> Bluetooth® HandsFreeLink®*

Bluetooth® Wireless Technology

The *Bluetooth*® word mark and logos are registered trademarks owned by *Bluetooth* SIG, Inc., and any use of such marks by Honda Motor Co., Ltd., is under license. Other trademarks and trade names are those of their respective owners.

HFL Limitations

An incoming call on HFL will interrupt the audio system when it is playing. It will resume when the call is ended.

The information that appears on the audio/information screen varies between phone models.


You can change the system language to English, French, or Spanish.

Customized Features P. 111

HFL Menus

The ignition switch must be in ACCESSORY ${
m II}$ or ON ${
m III}^{*1}$ to use HFL.

cor Z



>> HFL Menus

To use HFL, you must first pair your *Bluetooth*-compatible cell phone to the system while the vehicle is parked.

Some functions are limited while driving. A message appears on the screen when the vehicle is moving and the operation is canceled.

Select a phone number from the call history to store as a speed dial number.

Select a phone number from the phonebook to store as a speed dial number.

Enter a phone number to store as a speed dial number.

Phonebook*

Dialed Calls

Display the last 20 outgoing calls.

Received Calls

Display the last 20 incoming calls.


Display the last 20 missed calls.

Phonebook*


Display the paired phones's phonebook.

Dial*1 Enter a phone number to dial.


^{*1:} Appears only when a phone is connected to HFL.




*1: Appears only when a phone is connected to HFL.



^{*1:} Appears only when a phone is connected to HFL.



■ Phone Setup



- To pair a cell phone (No phone has been paired to the system)
- **1.** Press the **\(\)** button or the **\(\)** button.
- **2.** Rotate ♥ to select **Yes**, then press ८.
- **3.** Make sure your phone is in search or discoverable mode, then press ፩.
 - ► HFL automatically searches for a Bluetooth® device.
- **4.** When your phone appears on the list, select it by pressing *᠖*.
 - ▶ If your phone doesn't appear, select Phone Not Found? and search for Bluetooth® devices using your phone. From your phone, select HandsFreeLink.

- **5.** The system gives you a pairing code on the audio/information screen.
 - Confirm if the pairing code on the screen and your phone match.
 This may vary by phone.
- **6.** A notification appears on the screen if pairing is successful.

Your *Bluetooth*-compatible phone must be paired to HFL before you can make and receive hands-free calls.

Phone Pairing Tips:


- You cannot pair your phone while the vehicle is moving.
- Up to six phones can be paired.
- Your phone's battery may drain faster when it is paired to HFL.
- If your phone is not ready for pairing or not found by the system within three minutes, the system will time out and return to idle.

Once you have paired a phone, you can see it displayed on the screen with one or two icons on the right side.

These icons indicate the following:

: The phone can be used with HFL.


: The phone is compatible with *Bluetooth®* Audio.



■ To Change the currently paired phone

- **1.** Press the **\(\)** button or the **\(\)** button.
- **2.** Rotate [♠] to select **Phone Setup**, then press [♠].
- **3.** Rotate � to select **Bluetooth Setup**, then press ❷.
- **4.** Rotate ♥ to select **Connect a Phone**, then press ८.
 - ► The screen changes to a device list.

- **5.** Rotate 'ô' to select a desired device name, then press ⊗.
 - ► HFL disconnects the connected phone and starts searching for another paired phone.




■ To change the pairing code setting

- **1.** Press the button or the button.
- 2. Rotate [♠] to select **Phone Setup**, then press [♠].
- **3.** Rotate [♠] to select **Bluetooth Setup**, then press [♠].

4. Rotate ♂ to select **Pass-Key**, then press ⑤.

5. Input a new pairing code, then press 🕹 .




■ To delete a paired phone

- **1.** Press the **\(\)** button or the **\(\)** button.
- 2. Rotate ro to select **Phone Setup**, then press 3.
- **3.** Rotate � to select **Bluetooth Setup**, then press ❷.
- **4.** Rotate 🎅 to select **Delete Device**, then press ℧.
 - ▶ The screen changes to a device list.
- **5.** Rotate ⊘ to select a phone you want to delete, then press ∠.

6. A confirmation message appears on the screen. Rotate [™] to select **Yes**, then press [™] .

Ring Tone


You can change the ring tone setting.



- **1.** Press the **\(\)** button or the **\(\)** button.
- **2.** Rotate [♠] to select **Phone Setup**, then press [♠].
- **3.** Rotate [♠] to select **Ringtone**, then press [♠].
- **4.** Rotate '⑦ to select **Fixed** or **Mobile Phone**, then press ℧.

Caller's ID Information

You can select a caller's information to be displayed when you have an incoming call.



- 1. Press the button or the button.
- **2.** Rotate 🎅 to select **Phone Setup**, then press 🍣.
- **3.** Rotate ♥ to select **Caller ID Info**, then press ♥.
- **4.** Rotate $^{\circ}$ to select a mode you want, then press $^{\circ}$.

■ Ring Tone

Fixed: The fixed ring tone sounds from the speakers. **Mobile Phone:** For certain connected phones, the ring tone stored in the phone sounds from the speakers.

∑Caller's ID Information

Name Priority: A caller's name is displayed if it is stored in the phonebook.

Number Priority: A caller's phone number is displayed.

■ To Clear the System

Pairing codes, paired phones, all stored voice tags, all speed dial entries, all call history data, and all imported phonebook data are erased.



- **1.** Press the button or the button.
- **2.** Rotate ♥ to select **Phone Setup**, then press ♥.
- **3.** Rotate ♥ to select **System Clear**, then press ♥.
- **4.** Rotate ⑦ to select **Yes**, then press ♂.
- **5.** A confirmation message appears on the screen. Rotate ^{*} to select **Yes**, then press ^{*} . ^{*}

6. A notification appears on the screen. Press <a>⊗.

■ Automatic Import of Cellular Phonebook and Call History

When your phone is paired, the contents of its phonebook and call history are automatically imported to HFL.



Matter Automatic Import of Cellular Phonebook and Call History

When you select a person from the list in the cellular phonebook, you can see up to three category icons. The icons indicate what types of numbers are stored for that name.




If a name has four or more numbers, ... appears instead of category icons.


On some phones, it may not be possible to import the category icons to HFL.

The phonebook is updated after every connection. Call history is updated after every connection or call.

Speed Dial

Up to 20 speed dial numbers can be stored per phone.





To store a speed dial number:

- **1.** Press the button or the button.
- 2. Rotate ♥ to select **Speed Dial**, then press ⑤.
- **3.** Rotate ♥ to select **Add New**, then press ♥.
- **4.** Rotate ♥ to select a place to choose a number from, then press ♥.

From **Call History**:

► Select a number from the call history.

From **Phonebook**:

➤ Select a number from the connected cell phone's imported phonebook.

From **Phone Number**:


- Input the number manually.
- 5. When the speed dial is successfully stored, you are asked to create a voice tag for the number. Rotate ♂ to select **Yes** or **No**, then press ♂.
- **6.** Using the button, follow the prompts to say the name for the speed dial entry.

Speed Dial

You can use the audio preset buttons during a call to store a speed dial number:

- 1. Press and hold the desired audio preset button during a call.
- 2. The contact information for the active call will be stored for the corresponding speed dial.

When a voice tag is stored, you can press the <u>6</u> button and call the number using voice commands.



■ To edit a speed dial

- **1.** Press the button or the button.
- 2. Rotate [♠] to select **Phone Setup**, then press [♠].
- **3.** Rotate [♠] to select **Speed Dial**, then press [♠].
- **4.** Select an existing speed dial entry.
- **5.** Rotate ۞ to select **Change Speed Dial**, then press ॆ⊗.
- **6.** Select a new speed dial number, then press 💍 .



■ To add a voice tag to a stored speed dial number

- **1.** Press the **\(\)** button or the **\(\)** button.
- **2.** Rotate ♥ to select **Phone Setup**, then press ♥.
- **3.** Rotate ۞ to select **Speed Dial**, then press 丞.
- **4.** Select an existing speed dial entry.
- **5.** Rotate ⊘ to select **Store Voice Tag**, then press ⊗.
- **6.** Using the 😰 button, follow the prompts to complete the voice tag.

■ To change a voice tag

- 1. Press the button or the button.
- **2.** Rotate ♥ to select **Phone Setup**, then press ♥.
- **3.** Rotate ♥ to select **Speed Dial**, then press ⑤.
- **4.** Select an existing speed dial entry.
- **5.** Rotate ♥ to select **Change Voice Tag**, then press ♥.
- **6.** Using the <u>©</u> button, follow the prompts to complete the voice tag.

Speed Dial

Avoid using duplicate voice tags. Avoid using "home" as a voice tag. It is easier for HFL to recognize a longer name. For example, use "John Smith" instead of "John."







■ To delete a voice tag


- 1. Press the button or the button.
- **2.** Rotate ♥ to select **Phone Setup**, then press ♥.
- **3.** Rotate ♥ to select **Speed Dial**, then press ♥.
- **4.** Select an existing speed dial entry.
- **5.** Rotate ♥ to select **Delete Voice Tag**, then press ८.
 - ▶ A confirmation message appears on the screen. Rotate 😙 to select **Yes**, then press 🕹.

■ To delete a speed dial number

- 1. Press the button or the button.
- 2. Rotate ⊘ to select **Phone Setup**, then press ⊗.
- **3.** Rotate ♥ to select **Speed Dial**, then press ♥.
- **4.** Select an existing speed dial entry.
- **5.** Rotate ^{*}⑦ to select **Delete Speed Dial**, then press ③.
 - ► A confirmation message appears on the screen. Rotate 😙 to select **Yes**, then press 🕹.

■ Making a Call

You can make calls by inputting any phone number, or by using the imported phonebook, call history, speed dial entries, or redial.




Any voice-tagged speed dial entry can be dialed by voice from any screen.

Press the button and follow the prompts.

The maximum range between your phone and vehicles is 30 feet (10 meters).

Once a call is connected, you can hear the voice of the person you are calling through the audio speakers.





■ To make a call using the imported phonebook

When your phone is paired, the contents of its phonebook are automatically imported to HFI

- **1.** Press the **\(\)** button or the **\(\)** button.
- **2.** Rotate 🌣 to select **Phonebook**, then press 🍣.
- **3.** The phonebook is stored alphabetically. Rotate ^{*}⑦ to select the initial, then press [™]⊗.
- **4.** Rotate ♂ to select a name, then press ♂.
- **5.** Rotate ♂ to select a number, then press ⑤.
 - ▶ Dialing starts automatically.

■ To make a call using a phone number

- **1.** Press the **\(\)** button or the **\(\)** button.
- 2. Rotate roto select **Dial**, then press &.
- **3.** Rotate ♥ to select a number, then press ♣.
- **4.** Rotate ۞ to select **∠**, then press ⊗. **▶** Dialing starts automatically.

■To make a call using the imported phonebook

This function is disabled while the vehicle is moving. However, you can call a stored voice-tagged speed dial number using voice commands.


- Limitations for Manual Operation P. 334
- Speed Dial P. 346

∑To make a call using a phone number

This function is disabled while the vehicle is moving. However, you can call a stored voice-tagged speed dial number using voice commands.

- **▶ Limitations for Manual Operation** P. 334
- Speed Dial P. 346





■ To make a call using redial

- **1.** Press the **\(\)** button or the **\(\)** button.
- 2. Rotate ७ to select **Redial**, then press ७.

 ▶ Dialing starts automatically.

■ To make a call using the call history Call history is stored by Dialed Calls, Received Calls, and Missed Calls.

- **1.** Press the **\(\)** button or the **\(\)** button.
- 2. Rotate ۞ to select **Call History**, then press ፩.
- **3.** Rotate ♥ to select **Dialed Calls**, **Received Calls**, or **Missed Calls**, then press ८.
- **4.** Rotate ♥ to select a number, then press ⑤.
 - ▶ Dialing starts automatically.

∑To make a call using redial

Press and hold the **button** to redial the last number dialed in your phone's call history.

∑To make a call using the call history

The call history appears only when a phone is connected to HFL, and displays the last 20 dialed, received, or missed calls.



■ To make a call using a speed dial entry

- **1.** Press the button or the button.
- 2. Rotate to select **Speed Dial**, then press &.
- **3.** Rotate ♂ to select a number, then press ⑤.
 - ▶ Dialing starts automatically.

∑To make a call using a speed dial entry

On the **Phone** screen, the first six speed dials on the list can be directly selected by pressing the corresponding audio preset buttons (1-6).


Select **Others** to view another paired phone's speed dial list.

When a voice tag is stored, press the <u>©</u> button and call the number using voice commands.

Speed Dial P. 346

Any voice-tagged speed dial entry can be dialed by voice from any screen. Press the $\fbox{\cite{minimize}}$ button and follow the prompts.

Receiving a Call



When there is an incoming call, an audible notification sounds and the **Incoming Call** screen appears.

Press the button to answer the call.

Press the button to decline or end the call.

■ Receiving a Call

Call Waiting

Press the button to put the current call on hold to answer the incoming call.

Press the <u>L</u> button again to return to the current call.

Select **Ignore** to ignore the incoming call if you do not want to answer it.

Press the button if you want to hang up the current call.

You can select the icons on the audio/information screen instead of the and buttons. Rotate to select the icon, then press .

■ Options During a Call

The following options are available during a call.


Swap Call: Put the current call on hold to answer the incoming call.

Mute: Mute your voice.

Transfer Call: Transfer a call from HFL to your phone.

Dial Tones: Send numbers during a call. This is useful when you call a menu-driven

phone system.



- **1.** To view the available options, press the button.
- 2. Rotate ♂ to select the option, then press ૱.
 - ► The check box is checked when **Mute** is selected. Select **Mute** again to turn it off.

■Options During a Call


Dial Tones: Available on some phones.

Models with Display Audio

Bluetooth® HandsFreeLink® (HFL) allows you to place and receive phone calls using your vehicle's audio system, without handling your cell phone.

Using HFL

■ HFL Buttons



≫Bluetooth® HandsFreeLink®*

Place your phone where you can get good reception.

To use HFL, you need a *Bluetooth*-compatible cell phone. For a list of compatible phones, pairing procedures, and special feature capabilities:

- U.S.: Visit www.handsfreelink.honda.com, or call 1-888-528 -7876.
- Canada: Visit www.handsfreelink.ca, or call 1-888-528 -7876.

To use the system, the **Bluetooth On/Off** setting must be **On**. If there is an active connection to Apple CarPlay or Android Auto, HFL is unavailable.

How to customize P. 309

Voice control tips

- Aim the vents away from the ceiling and close the windows, as noise coming from them may interfere with the microphones.
- Press the 🛍 button when you want to call a number using a stored voice tag. Speak clearly and naturally after a beep.
- If the microphones pick up voices other than yours, the command may be misinterpreted.
- To change the volume level, select the audio system's **VOL** (Volume) or use the remote audio controls on the steering wheel.

Up to five speed dial entries can be displayed among a total of 20 that can be entered.

Speed Dial P. 370

Up to five previous calls can be displayed at a time among a total of 20 that can be entered. If there is no call history, Call History is disabled.

(Pick-up) button: Press to go directly to the phone menu on the driver information interface, or to answer an incoming call.

(Hang-up/back) button: Press to end a call, go back to the previous command, or cancel a command.

(Talk) button: Press to access Voice Portal.

buttons: Press to select an item displayed on the phone menu in the driver information interface.

ENTER button: Press to call a number listed in the selected item on the phone menu in the driver information interface.

button: Select and press **ENTER** to display **Speed Dial**, **Call History**, or **Phonebook** on the phone menu in the driver information interface.

To go to the **Phone menu** screen:

- 1. Select .
- **2.** Select **Phone** to switch the display to the phone screen.
- 3. Select 🖳 .

Bluetooth® Wireless Technology


The *Bluetooth®* word mark and logos are registered trademarks owned by *Bluetooth* SIG, Inc., and any use of such marks by Honda Motor Co., Ltd., is under license. Other trademarks and trade names are those of their respective owners.

HFL Limitations

An incoming call on HFL will interrupt the audio system when it is playing. It will resume when the call is ended.

■ HFL Status Display

The audio/information screen notifies you when there is an incoming call.



■ Limitations for Manual Operation

Certain manual functions are disabled or inoperable while the vehicle is in motion. You cannot select a grayed-out option until the vehicle is stopped.

Only previously stored speed dial entries with voice tags, phonebook names, or numbers can be called using voice commands while the vehicle is in motion.

Speed Dial P. 370

► MFL Status Display

The information that appears on the audio/information screen varies between phone models.

You can change the system language.

How to customize P. 309

HFL Menus

The power mode must be in ACCESSORY or ON to use the system.

■ Phone settings screen





- 1. Select .
- 2. Select Settings.
- 3. Select Phone.

>> HFL Menus

To use HFL, you must first pair your *Bluetooth*-compatible cell phone to the system while the vehicle is parked.


Some functions are limited while driving.









■ Phone menu screen



- 1. Select
- 2. Select Phone
- 3. Select 🖳





■ Phone Setup



- To pair a cell phone (when there is no phone paired to the system)
- 1. Select Phone.
- 2. Select Yes
- **3.** Make sure your phone is in search or discoverable mode, then select **Continue**.
 - ► HFL automatically searches for a Bluetooth® device.
- **4.** Select your phone when it appears on the list.
 - ► If your phone does not appear, you can select **Refresh** to search again.
 - ▶ If your phone still does not appear, select Phone Not Found and search for Bluetooth® devices using your phone. From your phone, search for HandsFreeLink.
- **5.** The system gives you a pairing code on the audio/information screen.
 - ➤ Confirm if the pairing code on the screen and your phone match.

 This may vary by phone.

▶ Phone Setup

Your *Bluetooth*-compatible phone must be paired to the system before you can make and receive hands-free calls

Phone Pairing Tips:

- You cannot pair your phone while the vehicle is moving.
- Up to six phones can be paired.
- Your phone's battery may drain faster when it is paired to the system.
- If your phone is not ready for pairing or not found by the system within three minutes, the system will time out and return to idle.


Once you have paired a phone, you can see it displayed on the screen with one or two icons on the right side.

These icons indicate the following:

: The phone can be used with HFL.

The phone is compatible with *Bluetooth*® Audio.

If there is an active connection to Apple CarPlay or Android Auto, pairing of additional *Bluetooth*compatible devices is unavailable and **Add Bluetooth Device** is grayed out from the **Bluetooth Device List** screen.





■ To change the currently paired phone

- **1.** Go to the phone settings screen.
 - **▶ Phone settings screen** P. 359
- Select Bluetooth Device List.
 Select a phone to connect.
 - ► HFL disconnects the connected phone and starts searching for another paired
- phone.

 4. Select Connect , Connect , or Connect .

■ To change the pairing code setting

- 1. Select .
- 2. Select Settings.
- 3. Select Bluetooth/Wi-Fi.
- **4.** Select the **Bluetooth** tab.
- 5. Select Edit Pairing Code.

6. Select Random or Fixed.

∑To change the currently paired phone

If no other phones are found or paired when trying to switch to another phone, HFL will inform you that the original phone is connected again.

To pair other phones, select **Add Bluetooth Device** from the **Bluetooth device list** screen.

≥ To change the pairing code setting

The default pairing code is **0000** until you change the setting.

To create your own, select **Fixed**, and delete the current code, then enter a new one.

For a randomly generated pairing code each time you pair a phone, select **Random**.




■ To delete a paired phone


- **1.** Go to the phone settings screen. **▶ Phone settings screen** P. 359
- 2. Select Bluetooth Device List.
- 3. Select a phone you want to delete.

- 4. Select **Delete**.
- **5.** A confirmation message appears on the screen. Select **Yes**.

367

■ To Set Up Text Message/E-mail Options





- To turn on or off the text/e-mail function
- 1. Go to the **Phone settings** screen.

 ▶ **Phone settings screen** P. 359
- 2. Select the **Text/Email** tab, then **Enable Text/Email**.
 - A pop-up menu appears on the screen.
- 3. Select On or Off.
- To turn on or off the text/e-mail notice
- **1.** Go to the **Phone settings** screen. **▶ Phone settings screen** P. 359
- 2. Select the **Text/Email** tab, then **New Message Notification**.
 - ► A pop-up menu appears on the screen.
- 3. Select On or Off.

∑To Set Up Text Message/E-mail Options

To use the text message/e-mail function, it may be necessary to set up on your phone.


∑To turn on or off the text/e-mail notice

On: A pop-up notification comes on every time you receive a new message.

Off: The message you receive is stored in the system without notification.

■ Ring Tone

You can change the ring tone setting.



- **1.** Go to the phone settings screen. **▶ Phone settings screen** P. 359
- 2. Select Ring Tone.
- 3. Select Fixed or Mobile Phone.

Ring Tone

Fixed: The fixed ring tone sounds from the speakers. **Mobile Phone**: For certain connected phones, the ring tone stored in the phone sounds from the speakers.

Automatic Import of Cellular Phonebook and Call History



luetooth Device List

Automatic Phone Sync HondaLink Assist

Automatic phone sync

Edit Speed Dial

12:34

12:34

■ When Automatic Phone Sync is set to On:

When your phone is paired, the contents of its phonebook and call history are automatically imported to the system.

■ Changing the Automatic Phone Sync setting

- **1.** Go to the phone settings screen. **▶ Phone settings screen** P. 359
- 2. Select Automatic Phone Sync.

3. Select On or Off.

Matter Automatic Import of Cellular Phonebook and Call History

When you select a name from the list in the cellular phonebook, you can see up to three category icons. The icons indicate what types of numbers are stored for that name.



On some phones, it may not be possible to import the category icons to the system.

The phonebook is updated after every connection. Call history is updated after every connection or call.

Speed Dial

Up to 20 speed dial numbers can be stored per phone.

₩ Speed Dial 12:34 <New Entry> 12:34 New entry Manual Input 12:34 Store Voice Tag To store a voice tag. Record

To store a speed dial number:

- 1. Go to the **Phone menu** screen.

 ▶ **Phone menu screen** P 362
- 2. Select Speed Dial.
- **3.** Select **New Entry**.

From Import from Call History:

► Select a number from the call history.

From **Manual Input**:

▶ Input the number manually.

From **Import from Phonebook**:

- Select a number from the connected cell phone's imported phonebook.
- **4.** When the speed dial is successfully stored, you are asked to create a voice tag for the number. Select **Yes** or **No**.

5. Select **Record**, or use the <u>№</u> button and follow the prompts to complete the voice tag.

Speed Dial

When a voice tag is stored, press the £ button to call the number using the voice tag. Say the voice tag name.



■ To add a voice tag to a stored speed dial number

- **1.** Go to the phone settings screen.
 - **▶ Phone settings screen** P. 359
- 2. Select Edit Speed Dial.
- **3.** Select an existing speed dial entry.
 - From the pop-up menu, select **Edit**.
- 4. Select Voice Tag.
 - From the pop-up menu, select **Record**.
- **5.** Select **Record**, or use the <u>№</u> button and follow the prompts to complete the voice tag.

≥Speed Dial

Avoid using duplicate voice tags. Avoid using "home" as a voice tag. It is easier for the system to recognize a longer name. For example, use "John Smith" instead of "John."



■ To delete a voice tag

- **1.** Go to the phone settings screen. **▶ Phone settings screen** P. 359
- 2. Select Edit Speed Dial.
- **3.** Select an existing speed dial entry.
 - From the pop-up menu, select **Edit**.
- **4.** Select **Voice Tag**.
 - From the pop-up menu, select **Clear**.
- **5.** A confirmation message appears on the screen. Select **Yes**.



■ To edit a speed dial

- **1.** Go to the phone settings screen. **▶ Phone settings screen** P. 359
- 2. Select Edit Speed Dial.
- **3.** Select an existing speed dial entry.
 - From the pop-up menu, select **Edit**.
- **4.** Select a setting you want.

■ To delete a speed dial

- **1.** Go to the phone settings screen.
 - **▶ Phone settings screen** P. 359
- 2. Select Edit Speed Dial.
- **3.** Select an existing speed dial entry.
 - From the pop-up menu, select **Delete**.
- **4.** A confirmation message appears on the screen. Select **Yes**

■ Phonebook Phonetic Modification

Add phonetic modifications or a new voice tag to the phone's contact name so that it is easier for HFL to recognize voice commands.



- To add a new voice tag
- 1. Select
- 2. Select Settings.
- 3. Select System.
- **4.** Select the **Voice Recog** tab.
- 5. Select Phonebook Phonetic Modification.
- **6.** Select the phone you want to add phonetic modification to.

You can store up to 20 phonetic modification items.



- 7. Select New Voice Tag.
- **8.** Select a contact name you want to add to.
 - ► The pop-up menu appears on the screen.
- 9. Select Modify.
- **10.** Using **Record** or the <u>©</u> button, follow the prompts to complete the voice tag.
- **11.** You will receive a confirmation message on the screen, then select **OK**.



■ To modify a voice tag

- 1. Select
- 2. Select Settings.
- 3. Select System.
- **4.** Select the **Voice Recog** tab.
- 5. Select Phonebook Phonetic Modification
- **6.** Select the phone you want to modify phonetic modification.
- **7.** Select a contact name you want to modify.
 - ► The pop-up menu appears on the screen.
- 8. Select Modify.
- **9.** Using **Record** or the <u>©</u> button, follow the prompts to complete the voice tag.
- **10.** You will receive a confirmation message on the screen, then select **OK**.

∑Phonebook Phonetic Modification

You can only modify or delete contact names for the currently connected phone.



■ To delete a modified voice tag

- 1. Select
- 2. Select Settings.
- 3. Select System.
- **4.** Select the **Voice Recog** tab.
- 5. Select Phonebook Phonetic Modification
- **6.** Select the phone you want to delete phonetic modification.
- **7.** Select a contact name you want to delete.
 - ► The pop-up menu appears on the screen.
- 8. Select **Delete**.
 - ► The selected contact name has been selected.
- 9. Select OK.

377



■ To delete all modified voice tags

- 1. Select
- 2. Select Settings.
- 3. Select System.
- **4.** Select the **Voice Recog** tab.
- 5. Select Phonebook Phonetic Modification
- **6.** Select the phone you want to delete phonetic modification.
 - ▶ The contact name list appears.
- 7. Select Delete All.
- **8.** You will receive a confirmation message on the screen, then select **Yes**.

■ Making a Call



You can make calls by inputting any phone number, or by using the imported phonebook, call history, speed dial entries, or redial.

Making a Call

Any voice-tagged speed dial entry can be dialed by voice from most screens.

Press the <u>s</u> button and say the voice tag name.

Once a call is connected, you can hear the voice of the person you are calling through the audio speakers.

While there is an active connection with Apple CarPlay or Android Auto, phone calls cannot be made with HandsFreeLink® and are only made from Apple CarPlay or Android Auto.






■ To make a call using the imported phonebook

- **1.** Go to the **Phone menu** screen.
 - Phone menu screen P. 362
- 2. Select Phonebook
- 3. Select a name.
 - You can also search by letter. Select **Search**.
 - ► Use the keyboard on the touch screen for entering name, if multiple numbers exist select a number.
 - ➤ You can also swipe up or down to scroll through the list of contacts alphabetically on the steering wheel.
 - **Audio Remote Controls** P. 202
- **4.** Select a number.
 - ▶ Dialing starts automatically.

■ To make a call using a phone number

- **1.** Go to the **Phone menu** screen.
 - **▶ Phone menu screen** P. 362
- 2. Select Dial
- **3.** Select a number.
 - ► Use the keyboard on the touch screen for entering numbers.
- 4. Select
 - ▶ Dialing starts automatically.



■ To make a call using redial

- **1.** Go to the **Phone menu** screen. **▶ Phone menu screen** P. 362
- 2. Select Redial.
 - ▶ Dialing starts automatically.



■ To make a call using the Call History Call history is stored by All, Dialed,

Received, and Missed.

- 1. Go to the **Phone menu** screen. ▶ **Phone menu screen** P. 362
- 2. Select Call History.
- 3. Select All, Dialed, Received, or Missed.
- 4. Select a number.
 - ▶ Dialing starts automatically.

■ To make a call using a Speed Dial entry

- 1. Go to the **Phone menu** screen. P. 362
- 2. Select Speed Dial.
- 3. Select a number.
 - ▶ Dialing starts automatically.

■To make a call using the Call History

The call history displays the last 20 all, dialed, received, or missed calls. (Appears only when a phone is connected to the system.)

∑To make a call using a Speed Dial entry

When a voice tag is stored, press the 🛍 button to call the number using the voice tag.


Speed Dial P. 370

Any voice-tagged speed dial entry can be dialed by voice from any screen.

Press the 🔂 button and follow the prompts.



Receiving a Call



When there is an incoming call, an audible notification sounds (if activated) and the **Incoming call** screen appears.

Press the button to answer the call.

Press the button to decline or end the call.

Options During a Call

The following options are available during a call.

Mute: Mute your voice.

Transfer: Transfer a call from the system to your phone.

Touch Tones: Send numbers during a call. This is useful when you call a menudriven phone system.



The available options are shown on the lower half of the screen

Select the option.

➤ The mute icon appears when **Mute** is selected. Select **Mute** again to turn it off.

■ Receiving a Call

Call Waiting

Press the <u>L</u> button to put the current call on hold to answer the incoming call.

Press the button again to return to the current call.

Select **Ignore** to ignore the incoming call if you do not want to answer it.

Press the sutton if you want to hang up the current call.

You can select the icons on the audio/information screen instead of the 🖾 and 🕾 🛳 buttons.

○ Options During a Call

Touch Tones: Available on some phones.

You can select the icons on the audio/information screen.

Receiving a Text Message/E-mail

HFL can display newly received text or e-mail messages as well as 20 of the most recently received messages on a linked cell phone. Each received message can be read aloud and replied to using a fixed common phrase.



- **1.** A pop-up appears and notifies you of a new text message or e-mail.
- **2.** Select **Read** to listen to the message.
 - ➤ The text message or e-mail is displayed. The system automatically starts reading out the message.
- **3.** To discontinue the message read-out, select **Stop**.

Receiving a Text Message/E-mail

The system does not display any received messages while you are driving. You can only hear them read aloud.

The system can only receive massages that are sent a text (SMS) messages. The message sent using the data services will not be displayed in the list.

With some phones, you may be able to display up to 20 most recent text messages and e-mails.

State or local laws may limit your use of the HFL text message/e-mail feature. Only use the text message/e-mail feature when conditions allow you to do so safely.

When you receive a text message or e-mail for the first time since the phone is paired to HFL, you are asked to turn the **New Message Notification** setting to **On**.

To turn on or off the text/e-mail notice P. 367



■ Selecting a Mail Account

If a paired phone has text message or mail accounts, you can select one of them to be active and receive notifications.



- **1.** Go to the **Phone settings** screen. **▶ Phone settings screen** P. 359
- 2. Select the **Text/Email** tab, then **Select** Account.
 - A pop-up menu appears on the screen.
- **3.** Select **Text Message** or an e-mail account you want.

Selecting a Mail Account

You can also select a mail account from the folder list screen or the message list screen.



You can only receive notifications from one text message or mail account at a time.

Displaying Messages




■ Displaying text messages

- **1.** Go to the **Phone menu** screen.
 - **▶ Phone menu screen** P. 362
- 2. Select Text/Email.
 - ► Select account if necessary.
- 3. Select a message.
 - ➤ The text message is displayed. The system automatically starts reading the message aloud.

▶ Displaying Messages

If you delete a message on the phone, the message is also deleted in the system. If you send a message from the system, the message goes to your phone's outbox.

To see the previous or next message, select **◄** (previous) or **▶** (next) on the message screen.



■ Displaying e-mails

- **1.** Go to the **Phone menu** screen.
 - **Phone menu screen** P. 362
- 2. Select Text/Email.
 - ► Select **Select Account** if necessary.
- **3.** Select a folder.
- 4. Select a message.
 - ➤ The e-mail is displayed. The system automatically starts reading the message aloud.





■ Read or Stop reading a message

- **1.** Go to the text or e-mail message screen.
 - ► The system automatically starts reading the message aloud.
 - **Displaying Messages** P. 383
- Select Stop to stop reading.Select Read again to start reading the message from the beginning.

■ Reply to a message

- **1.** Go to the text or e-mail message screen.
 - ► The system automatically starts reading the message aloud.
 - **Displaying Messages** P. 383
- 2. Select Reply.
- **3.** Select the reply message.
 - ► The pop-up menu appears on the screen.
- **4.** Select **Send** to send the message.
 - ► **Complete** appears on the screen when the reply message was successfully sent.

■ Reply to a message

The available fixed reply messages are as follows:

- Talk to you later, I'm driving.
- I'm on my way.
- I'm running late.
- OK
- Yes
- No

You cannot add, edit, or delete reply messages.




■ Making a call to a sender

- **1.** Go to the text message screen.
- 2. Select Dial.

■ In Case of Emergency

■ Automatic collision notification



If your vehicle's airbags deploy or if the unit detects that the vehicle is severely impacted, your vehicle automatically will attempt to connect to the HondaLink operator. If connected, information about your vehicle, its location, and its condition will be sent to the operator; you also can speak to the operator when connected.

IMPORTANT: For vehicles equipped with HondaLink Assist, owner activation constitutes authorization for Honda to collect information from your vehicle needed to provide the service, and agreement to the Terms of Use at *www.hondalink.com/TermsAndConditions*. In a crash, HondaLink Assist will attempt to notify emergency services but NEITHER Honda-PRO NOR ITS SERVICE PROVIDERS GUARANTEE THAT SUCH NOTIFICATION WILL OCCUR.

Honda reserves the right to terminate HondaLink Assist services at any time or for any reason, and in the future may not be able to provide services due to changes in, or obsolescence of, technology integral to the service or changes in governmental regulation.

Your vehicle may not be able to connect to the operator if the battery level is low, the line is disconnected, or you do not have adequate cellular coverage.

You cannot use this emergency service when:


- You travel outside the HondaLink service coverage areas.
- There is a problem with the connecting devices, such as the microphones, speakers, or the unit itself.

You cannot operate other phone-related functions using the screen while talking to the operator. Select **Hang Up** to terminate the connection to your vehicle.

■ Automatic collision notification

If the unit fails to connect to the operator, it repeatedly tries until it succeeds.

■ To enable notification



- **1.** Go to the **Phone settings** screen.
 - **▶ Phone settings screen** P. 359
- 2. Select the **Phone** tab, then **HondaLink**Assist.
 - ► A pop-up menu appears on the screen.
- 3. Select On or Off.

>> To enable notification

Setting options:

- On: Notification is available.
- Off: Disable the feature.



This chapter discusses driving, refueling, and information on items such as accessories.

Before Driving
Driving Preparation 390
Maximum Load Limit393
Towing a Trailer395
When Driving
Starting the Engine 396, 398
Precautions While Driving403
Continuously Variable Transmission* 404
Shifting405, 407
ECON Button410
Cruise Control*41
Front Sensor Camera*414

Adaptive Cruise Control (ACC) with Speed Follow (LSF)*	
Road Departure Mitigation (RDM) System*	430
Lane Keeping Assist System (LKAS)*	. 434
Vehicle Stability Assist (VSA®), aka Elec	ctroni
Stability Control (ESC), System	. 441
LaneWatch TM *	. 444
Tire Pressure Monitoring System (TPMS)	446
Tire Pressure Monitoring System (TP	MS) -
Required Federal Explanation	. 449
raking	
Brake System	151

Anti-lock Brake System (ABS) 457
Brake Assist System 458
Collision Mitigation Braking System™
(CMBS™)*
Parking Your Vehicle
When Stopped 467
Multi-View Rear Camera 468
Refueling
Fuel Information 470
How to Refuel 471
Fuel Economy
Improving Fuel Economy 473
Accessories and Modifications 474

Before Driving

Driving Preparation

Check the following items before you start driving.

■ Exterior Checks

- Make sure there are no obstructions on the windows, door mirrors, exterior lights, or other parts of the vehicle.
 - Remove any frost, snow, or ice.
 - ▶ Remove any snow on the roof, as this can slip down and obstruct your field of vision while driving. If frozen solid, remove ice once it has softened.
 - ▶ When removing ice from around the wheels, be sure not to damage the wheel or wheel components.
- Make sure the hood is securely closed.
 - ▶ If the hood opens while driving, your front view will be blocked.
- Make sure the tires are in good condition.
 - ► Check air pressure, check for damage and excessive wear.

≧ Checking and Maintaining Tires P. 516

- Make sure there are no people or objects behind or around the vehicle.
 - ▶ There are blind spots from the inside.

Exterior Checks

NOTICE

When doors are frozen shut, use warm water around the door edges to melt any ice. Do not try to force them open, as this can damage the rubber trim around the doors. When done, wipe dry to avoid further freezing.

Do not pour warm water into the key cylinder. You will be unable to insert key if the water freezes in the hole.

Heat from the engine and exhaust can ignite flammable materials left under the hood, causing a fire. If you've parked your vehicle for an extended period, inspect and remove any debris that may have collected, such as dried grass and leaves that have fallen or have been carried in for use as a nest by a small animal. Also check under the hood for leftover flammable materials after you or someone else has performed maintenance on your vehicle.

■ Interior Checks

- Store or secure all items on board properly.
 - ► Carrying too much cargo, or improperly storing it, can affect your vehicle's handling, stability, stopping distance, and tires, and make it unsafe.
 - **► Maximum Load Limit** P. 393
- Do not pile items higher than the seat height.
 - ► They can block your view and may be thrown forward in the event of sudden braking.
- Do not place anything in the front seat footwells. Make sure to secure the floor mat.
 - An object or unsecured floor mat can interfere with your brake and accelerator pedal operation while driving.
- If you have any animals on board, do not let them move around in the vehicle.
 - ▶ They may interfere with driving and a crash could occur.
- Securely close and lock all doors and the trunk.
 - **Locking/Unlocking the Doors from the Inside** P. 134
- Adjust your seating position properly.
- Adjust the front head restraint, too.
 - **Adjusting the Seats** P. 167
 - **Adjusting the Front Head Restraints** P. 170
- Adjust the mirrors and steering wheel properly for your driving.
 - Adjust them while sitting in the proper driving position.
 - Adjusting the Mirrors P. 165
 - **Adjusting the Steering Wheel** P. 164


The headlight aim is set by the factory, and does not need to be adjusted. However, if you regularly carry heavy items in the trunk, have the aiming readjusted at a dealer or by a qualified technician.

- Be sure items placed on the floor behind the front seats cannot roll under the seats.
 - ▶ They can interfere with the driver's ability to operate the pedals, the operation of the seats, or the operation of the sensors under the seats.
- Everyone in the vehicle must fasten their seat belt.
 - Fastening a Seat Belt P. 40
- Make sure that the indicators in the instrument panel come on when you start the vehicle, and go off soon after.
 - ▶ Always have a dealer check the vehicle if a problem is indicated.
 - **▶ Indicators** P. 74

Maximum Load Limit

The maximum load for your vehicle is 850 lbs (385 kg). See the Tire and Loading Information label attached to the driver's doorjamb.

Label Example



This figure includes the total weight of all occupants, cargo, and accessories, and the tongue load if you are towing a trailer.

Steps for Determining Correct Load Limit -

- (1) Locate the statement "The combined weight of occupants and cargo should never exceed XXX kg or XXX lbs." on your vehicle's placard.
- (2) Determine the combined weight of the driver and passengers that will be riding in your vehicle.
- (3) Subtract the combined weight of the driver and passengers from XXX kg or XXX lbs.
- (4) The resulting figure equals the available amount of cargo and luggage load capacity. For example, if the "XXX" amount equals 1,400 lbs. and there will be five 150 lb. passengers in your vehicle, the amount of available cargo and luggage load capacity is 650 lbs. (1,400 750 (5 x 150) = 650 lbs.)

Maximum Load Limit

AWARNING

Overloading or improper loading can affect handling and stability and cause a crash in which you can be hurt or killed.

Follow all load limits and other loading guidelines in this manual.

Gross Vehicle Weight Rating (GVWR):

The maximum allowable weight of the vehicle, all occupants, all accessories, all cargo, and the tongue load.

Specifications P. 568, 570


Gross Axle Weight Rating (GAWR):

The maximum allowable weight of the vehicle axle.

Specifications P. 568, 570

- (5) Determine the combined weight of luggage and cargo being loaded on the vehicle. That weight may not safely exceed the available cargo and luggage load capacity calculated in step 4.
- **(6)** If your vehicle will be towing a trailer, load from your trailer will be transferred to your vehicle. Consult this manual to determine how this reduces the available cargo and luggage load capacity of your vehicle.

In addition, the total weight of the vehicle, all occupants, accessories, cargo, and trailer tongue load must not exceed the Gross Vehicle Weight Rating (GVWR) or the Gross Axle Weight Rating (GAWR). Both are on a label on the driver's doorjamb.



Driving

Towing a Trailer

Your vehicle is not designed to tow a trailer. Attempting to do so can void your warranties.


When Driving

Models without smart entry system

Starting the Engine




1. Make sure the parking brake is applied.



Continuously variable transmission models

- **2.** Check that the shift lever is in P, then depress the brake pedal.
 - ► Although it is possible to start the vehicle in N, it is safer to start it in P.



Manual transmission models

- **2.** Check that the shift lever is in N. Then depress the brake pedal with your right foot, and the clutch pedal with your left foot.
 - ► The clutch pedal must be fully depressed to start the engine.

Starting the Engine

Keep your foot firmly on the brake pedal when starting the engine.

The engine is harder to start in cold weather and in thinner air found at altitudes above 8,000 feet (2,400 meters).

When starting the engine in cold weather, turn off all electrical accessories such as the lights, heating system*/climate control system*, and rear defogger in order to reduce battery drain.

If you live in a region where winter is extremely cold, an engine block heater will improve starting and warming of the engine. If temperatures consistently below -22°F (-30°C) are expected, the coolant mixture should be changed to a higher concentration to prevent freezing. Consult a dealer for details.

If the exhaust system sounds abnormal or you can smell exhaust gas inside the vehicle, have your vehicle checked by a dealer. There may be a problem with the engine or exhaust system.

Driving



All models

3. Turn the ignition switch to START **III** without depressing the accelerator pedal.

Starting to Drive

Continuously variable transmission models

- **1.** Keeping your right foot on the brake pedal, put the shift lever in \boxed{D} . Select \boxed{R} when reversing.
- **2.** With the parking brake applied, release the brake pedal and gently depress the accelerator pedal.
 - ▶ Make sure the parking brake indicator goes off.
 - Parking Brake P. 451

■ Hill start assist system

Hill start assist keeps the brake engaged briefly to help prevent the vehicle from rolling on inclines as you move your foot from the brake pedal to the accelerator.

Manual transmission models

Depress the clutch pedal, and shift to one of the forward gears when facing uphill, or $\boxed{\mathbf{R}}$ when facing downhill, then release the brake pedal.

Continuously variable transmission models

Move the shift lever to \boxed{D} , \boxed{S} , or \boxed{L} when facing uphill, or \boxed{R} when facing downhill, then release the brake pedal.

Starting the Engine

Do not hold the key in START [III] for more than 10 seconds.

- If the engine does not start right away, wait for at least 30 seconds before trying again.
- If the engine starts, but then immediately stops, wait at least 30 seconds before repeating step 3 while gently depressing the accelerator pedal. Release the accelerator pedal once the engine starts.

The immobilizer system protects your vehicle from theft. If an improperly coded key (or other device) is used, the engine's fuel system is disabled.

▶ Immobilizer System P. 144

Hill start assist may not prevent the vehicle from rolling downhill on a very steep or slippery slope, and does not operate on small inclines.


Hill start assist is not a replacement for the parking brake.

Models with smart entry system

Starting the Engine




1. Make sure the parking brake is applied.



Continuously variable transmission models

- **2.** Check that the shift lever is in P, then depress the brake pedal.
 - ► Although it is possible to start the vehicle in N, it is safer to start it in P.



Manual transmission models

- **2.** Check that the shift lever is in N. Then depress the brake pedal with your right foot, and the clutch pedal with your left foot.
 - ► The clutch pedal must be fully depressed to start the engine.

Starting the Engine

Keep your foot firmly on the brake pedal when starting the engine.

The engine is harder to start in cold weather and in thinner air found at altitudes above 8,000 feet (2,400 meters).

When starting the engine in cold weather, turn off all electrical accessories such as the lights, climate control system, and rear defogger in order to reduce battery drain.

If you live in a region where winter is extremely cold, an engine block heater will improve starting and warming of the engine. If temperatures consistently below -22°F (-30°C) are expected, the coolant mixture should be changed to a higher concentration to prevent freezing. Consult a dealer for details.

If the exhaust system sounds abnormal or you can smell exhaust gas inside the vehicle, have your vehicle checked by a dealer. There may be a problem with the engine or exhaust system.

The immobilizer system protects your vehicle from theft.

If an improperly coded device is used, the engine's fuel system is disabled.

Immobilizer System P. 144



All models

3. Press the **ENGINE START/STOP** button without depressing the accelerator pedal.

Stopping the Engine

You can turn the engine off when the vehicle is completely stopped.

Continuously variable transmission models

- **1.** Shift to **P**.
- 2. Press the ENGINE START/STOP button.

Manual transmission models

- If the shift lever is in N, press the **ENGINE START/STOP** button.
- If the shift lever is in any gear other than N, depress the clutch pedal, then press the **ENGINE START/STOP** button.

Starting the Engine

Bring the smart entry remote close to the **ENGINE START/STOP** button if the battery in the smart entry remote is weak.

▶ If the Smart Entry Remote Battery is Weak P. 544

The engine may not start if the smart entry remote is subjected to strong radio waves.

Do not hold the **ENGINE START/STOP** button to start the engine.


If the engine does not start, wait at least 30 seconds before trying again.

Continued 399

■ Remote Engine Start with Vehicle Feedback*

You can remotely start the engine using the \(\bigcirc\) button on the smart entry remote.

■ To start the engine



When started remotely, the engine automatically shuts off after 10 minutes of idling and the brake pedal and **ENGINE START/STOP** button have not been pressed simultaneously.

To extend the run time for another 10 minutes during the first run, press the button, then press and hold the button.

transmitted successfully.

► Some exterior lights flash six times if a 10-minute extension request was

■ Remote Engine Start with Vehicle Feedback*

AWARNING

Engine exhaust contains toxic carbon monoxide

Breathing carbon monoxide can kill you or cause unconsciousness.

Never use the remote engine starter when the vehicle is parked in a garage or other area with limited ventilation.

The remote engine start may violate local laws. Before using the remote engine start, check your local laws


If there are buildings and obstacles between your vehicle and the remote, the range will be reduced. The range may be less when the vehicle is running. This distance may vary by external electrical interference

The engine may not start by the remote engine start

- You have disabled a remote engine start setting using the audio/information screen*.
- The power mode is not in VEHICLE OFF (LOCK).
- The gear is in a position other than P.
- The hood is open, or any door or the trunk is unlocked.

* Not available on all models

■ To stop the engine



■ Remote Engine Start with Vehicle Feedback*

- You have already used the remote twice to start the engine.
- Another registered smart entry remote is in the vehicle.
- There is an antenna failure.
- Door is unlocked with the built-in key.
- The engine oil pressure is low.
- The engine coolant temperature is extremely high.
- The security system alarm is not set.

While the engine is running, the vehicle will automatically activate climate control with a preset temperature of 72°F (22°C).

When it is warm outside:

• The air conditioning is activated in recirculation mode.

When it is cold outside:

- The defroster is activated at a moderately warm temperature.
- The rear defogger and door mirror heaters are activated.

Starting to Drive

Continuously variable transmission models

When the engine was started using the button* on the smart entry remote

1. Depress the brake pedal and press the **ENGINE START/STOP** button simultaneously.

When the engine was started in any case

- **2.** Put the shift lever in \boxed{D} . Select \boxed{R} when reversing.
- **3.** With the parking brake is applied, release the brake pedal and gently depress the accelerator pedal.
 - ► Make sure the parking brake indicator goes off.
- **4.** Gradually release the brake pedal and gently depress the accelerator pedal to pull away.

■ Hill start assist system

Hill start assist keeps the brake engaged briefly to help prevent the vehicle from rolling on inclines as you move your foot from the brake pedal to the accelerator.

Manual transmission models

Depress the clutch pedal, and shift to one of the forward gears when facing uphill, or $\boxed{\mathbf{R}}$ when facing downhill, then release the brake pedal.

Continuously variable transmission models

Move the shift lever to \boxed{D} , \boxed{S} , or \boxed{L} when facing uphill, or \boxed{R} when facing downhill, then release the brake pedal.

Starting to Drive

When the engine was started using the button on the smart entry remote

The engine stops when the shift lever is moved out of P before the **ENGINE START/STOP** button is pressed. Follow step 1 when starting to drive.

Hill start assist may not prevent the vehicle from rolling downhill on a very steep or slippery slope, and does not operate on small inclines.

Hill start assist is not a replacement for the parking brake.

Precautions While Driving

■ In Rain

Avoid driving in deep water and on flooded roads. This can damage the engine or driveline, or cause electrical component failure.

Other Precautions

If there is a strong impact with something under the vehicle, stop in a safe location. Check the underside of the vehicle for damage or any fluid leaks.

▶ Precautions While Driving

NOTICE

Do not operate the shift lever while pressing the accelerator pedal. You could damage the transmission.

If the ignition switch is turned to ACCESSORY Π^{*1} while driving, the engine will shut down and all steering and brake power assist functions will stop, making it difficult to control the vehicle.

Do not put the shift lever in $\boxed{\mathbf{N}}$, as you will lose engine braking (and acceleration) performance.

During the first 600 miles (1,000 km) of operation, avoid sudden acceleration or full throttle operation so as not to damage the engine or powertrain.

Avoid hard braking for the first 200 miles (300 km). You should also follow this when the brake pads are replaced.

NOTICE

If you repeatedly turn the steering wheel at an extremely low speed, or hold the steering wheel on the full left or right position for a while, the electric power steering (EPS) system heats up. The system goes into a protective mode, and limits its performance. The steering wheel becomes harder and harder to operate. Once the system cools down, the EPS system is restored.

Repeated operation under these conditions can eventually damage the system.

^{*1:} Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

Continuously Variable Transmission*

Creeping

The engine runs at a higher idle speed and creeping increases. Keep the brake pedal firmly depressed when stopped.

Kickdown


Quickly depressing the accelerator pedal while driving uphill may cause the transmission to drop to a lower ratio, unexpectedly increasing vehicle speed. Depress the accelerator pedal carefully, especially on slippery roads and curves.

Continuously variable transmission models

Shifting

Change the shift position in accordance with your driving needs.

■ Shift lever positions



^{*1:} Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

>> Shifting


You cannot turn the ignition switch to LOCK $\boxed{0}^{*1}$ and remove the key unless the shift lever is in \boxed{P} .

The vehicle may move forward very slightly even in $\boxed{\bf N}$ while the engine is cold.

Depress the brake pedal firmly and, when necessary, apply the parking brake.

Continued 405

Shift Lever Operation



Shift Lever Operation

NOTICE

When you change the shift lever from $\boxed{\mathbf{D}}$ to $\boxed{\mathbf{R}}$ and vice versa, come to a complete stop and keep the brake pedal depressed.

Operating the shift lever before the vehicle has come to a complete standstill can damage the transmission.

Use the shift lever position indicator to check the lever position before pulling away.

If the transmission indicator blinks when driving, in any shift position, there is a problem with the transmission.

Avoid sudden acceleration and have the transmission checked by a dealer as soon as possible.

The fuel supply may be cut off if you drive at engine speeds in or over the tachometer's red zone (engine speed limit). If this happens, you may experience a slight jolt.

It may not be possible to operate the shift lever if the brake pedal is applied while the shift lever release button is held down.

Depress the brake pedal first.

Manual transmission models

Shifting

■ Shift Lever Operation

Fully depress the clutch pedal to operate the shift lever and change gears, then slowly release the pedal.

Depress the clutch pedal, and pause for a few seconds before shifting into \mathbb{R} , or shift into one of the forward gears for a moment. This stops the gears so they do not "grind."

>> Shifting

NOTICE

Do not shift to $\boxed{\mathbf{R}}$ before the vehicle comes to a complete stop.

Shifting to $\overline{\mathbf{R}}$ before stopping can damage the transmission.

NOTICE

Before downshifting, make sure the engine will not go into the tachometer's red zone. Should this occur, it can severely damage your engine.

There is a metallic part on the shift lever. If you leave the vehicle parked outside for a long time on a hot day, be careful before moving the shift lever. Because of heat, the shift lever may be extremely hot. If the outside temperature is low, the shift lever may feel cold.

Continued 407



When you are not shifting, do not rest your foot on the clutch pedal. This can cause your clutch to wear out faster.

Shifting

Recommended Shift Points

Driving in the highest gear that allows the engine to run and accelerate smoothly helps to optimize fuel economy and effective emissions control. The following shift points are recommended:


Shift Up	Normal Acceleration	
1st to 2nd	16 mph (25 km/h)	
2nd to 3rd	26 mph (42 km/h)	
3rd to 4th	35 mph (56 km/h)	
4th to 5th	41 mph (66 km/h)	
5th to 6th	43 mph (69 km/h)	

If you exceed the maximum speed for the gear you are in, the engine speed will enter into the tachometer's red zone. When this happens, you may experience a slight jolt.

■ Reverse Lockout

The manual transmission has a lockout mechanism that stops you from accidentally shifting into $\boxed{\mathbf{R}}$ from a forward gear while the vehicle is moving above a certain speed.

If you cannot shift to $\boxed{\mathbf{R}}$ when the vehicle is stopped, do the following:




- **1.** Depress the clutch pedal, move the shift lever all the way to the left, and shift to R.
- **2.** If you still cannot shift into **R**, apply the parking brake, and turn the ignition switch to ACCESSORY **I** or LOCK **0***1.
- **3.** Depress the clutch pedal and shift into \mathbb{R} .
- **4.** Keep depressing the clutch pedal and start the engine.

Have the vehicle checked by a dealer if you have to go through this procedure repeatedly.

^{*1:} Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

ECON Button




The **ECON** button turns the ECON mode on and off.

The ECON mode helps you improve your fuel economy by adjusting the performance of the engine, transmission, heating system*/climate control system*, and cruise control*.

Cruise Control*

Maintains a constant vehicle speed without having to keep your foot on the accelerator. Use cruise control on freeways or open roads where you can travel at a constant speed with little acceleration or deceleration.



AWARNING

Improper use of the cruise control can lead to a crash.

Use the cruise control only when traveling on open highways in good weather.

It may not be possible to maintain a constant speed when driving uphill or downhill.

When not using cruise control:

Turn off cruise control by pressing the **CRUISE***/ **MAIN*** button.


While in ECON mode, it may take relatively more time to accelerate to maintain the set speed.

Manual transmission models

When the engine speed slows down, try to downshift.

You can maintain the set speed if you change gear within five seconds.

■ To Set the Vehicle Speed




Take your foot off the pedal and press the **–/SET** button when you reach the desired speed.

The moment you release the **–/SET** button, the set speed is fixed, and cruise control begins. The **CRUISE CONTROL** indicator comes on.

During cruise control, Straight Driving Assist Function is activated. This control function is an EPS function and it helps reduce the steering effort to keep the steering angle on a straight road with cants.


■ To Adjust the Vehicle Speed

Increase or decrease the vehicle speed using the **RES/+** or **-/SET** buttons on the steering wheel.



- Each time you press the button, the vehicle speed is increased or decreased by about 1 mph (1.6 km/h).
- If you keep the button pressed, the vehicle speed increases or decreases until you release it. This speed is then set.

■ To Cancel



To cancel cruise control, do any of the following:

- Press the **CANCEL** button
- Press the **CRUISE***/**MAIN*** button.
- Depress the brake pedal.
- Depress the clutch pedal* for five seconds or more.

The **CRUISE CONTROL** indicator goes off.

∑To Adjust the Vehicle Speed

You can set the vehicle speed using the **-/SET** button on the steering wheel when adjusting the speed with the accelerator and brake pedals.

∑To Cancel

Resuming the prior set speed:

After cruise control has been canceled, you can still resume the prior set speed by pressing the **RES/+** button while driving at a speed of at least 25 mph (40 km/h) or more.

You cannot set or resume in the following situations:

- When vehicle speed is less than 25 mph (40 km/h)
- When the **CRUISE***/**MAIN*** button is turned on.


At vehicle speeds of 22 mph (35 km/h) or less, cruise control is canceled automatically.

* Not available on all models

Front Sensor Camera*

The camera, used in systems such as LKAS, RDM, ACC with LSF, and CMBS™, is designed to detect an object that triggers any of the systems to operate its functions.

Camera Location and Handling Tips



This camera is located behind the rearview mirror

To help reduce the likelihood that high interior temperatures will cause the camera's sensing system to shut off, when parking, find a shady area or face the front of the vehicle away from the sun. If you use a reflective sun shade, do not allow it to cover the camera housing. Covering the camera can concentrate heat on it.

Never apply a film or attach any objects to the windshield, the hood, or the front grill that could obstruct the camera's field of vision and cause the system to operate abnormally.

Scratches, nicks, and other damage to the windshield within the camera's field of vision can cause the system to operate abnormally. If this occurs, we recommend that you replace the windshield with a genuine Honda replacement windshield. Making even minor repairs within the camera's field of vision or installing an aftermarket replacement windshield may also cause the system to operate abnormally. After replacing the windshield, have a dealer recalibrate the camera. Proper calibration of the camera is necessary for the system to operate properly.

Do not place an object on the top of the instrument panel. It may reflect onto the windshield and prevent the system from detecting lane lines properly.

>> Front Sensor Camera *

If the Some Driver Assist Systems Cannot Operate: Camera Temperature Too High message appears:

- Use the climate control system to cool down the interior and, if necessary, also use defroster mode with the airflow directed towards the camera.
- Start driving the vehicle to lower the windshield temperature, which cools down the area around the camera.

If the Some Driver Assist Systems Cannot Operate: Clean Front Windshield message appears:


 Park your vehicle in a safe place, and clean the windshield. If the message does not disappear after you have cleaned the windshield and driven for a while, have your vehicle checked by a dealer.

* Not available on all models

Adaptive Cruise Control (ACC) with Low Speed Follow (LSF)*

Helps maintain a constant vehicle speed and a set following interval behind a vehicle detected ahead of yours and, if the detected vehicle comes to a stop, can decelerate and stop your vehicle, without you having to keep your foot on the brake or the accelerator.

When ACC with LSF slows your vehicle by applying the brakes, your vehicle's brake lights will illuminate.



Magnetive Cruise Control (ACC) with Low Speed Follow (LSF)*

Adaptive Cruise Control (ACC) with Low Speed Follow (LSF)*

Magnetive Cruise Control (ACC) with Low Speed Follow (LSF)*

Magnetive Cruise Control (ACC) with Low Speed Follow (LSF)*

Magnetic Cruise Control (ACC) with Low Speed Follow (LSF)*

Magnetic Cruise Control (ACC) with Low Speed Follow (LSF)*

Magnetic Cruise Control (ACC) with Low Speed Follow (LSF)*

Magnetic Cruise Control (ACC) with Low Speed Follow (LSF)*

Magnetic Cruise Control (ACC) with Low Speed Follow (LSF)*

Magnetic Cruise Control (ACC) with Low Speed Follow (LSF)*

Magnetic Cruise Control (ACC) with Low Speed Follow (LSF)*

Magnetic Cruise Control (ACC) with Low Speed Follow (LSF)*

Magnetic Cruise Control (ACC) with Low Speed Follow (LSF)*

Magnetic Cruise Control (ACC) with Low Speed Follow (LSF)*

Magnetic Cruise Control (ACC) with Low Speed Follow (LSF)*

Magnetic Cruise Control (ACC) with Low Speed Follow (LSF)*

Magnetic Cruise Control (ACC) with Low Speed Follow (LSF)*

Magnetic Cruise Control (ACC) with Low Speed Follow (LSF)*

Magnetic Cruise Control (ACC) with Low Speed Follow (LSF)*

Magnetic Cruise Control (ACC) with Low Speed Follow (LSF)*

Magnetic Cruise Control (ACC) with Low Speed Follow (LSF)*

Magnetic Cruise Control (ACC) with Low Speed Follow (LSF)*

Magnetic Cruise Control (ACC) with Low Speed Follow (LSF)*

Magnetic Cruise Control (ACC) with Low Speed Follow (LSF)*

Magnetic Cruise Control (ACC) with Low Speed Follow (LSF)*

Magnetic Cruise Control (ACC) with Low Speed Follow (LSF)*

Magnetic Cruise Control (ACC) with Low Speed Follow (LSF)*

Magnetic Cruise Control (ACC) with Low Speed Follow (LSF)*

Magnetic Cruise Control (ACC) with Low Speed Follow (LSF)*

Magnetic Cruise Control (ACC) with Low Speed Follow (LSF)*

Magnetic Cruise Control (ACC) with Low Speed Follow (LSF)*

Magnetic Cruise Control (ACC) with Low Speed Follow (LSF)*

Magnetic Cruise Control (ACC) with Low Speed Follow (LSF)*

Magnetic Cruise Control (ACC) with Low Speed Follow (LSF)

AWARNING

Improper use of ACC with LSF can lead to a crash

Use ACC with LSF only when driving on expressways or freeways and in good weather conditions.

AWARNING


ACC with LSF has limited braking capability and may not stop your vehicle in time to avoid a collision with a vehicle that quickly stops in front of you.

Always be prepared to apply the brake pedal if the conditions require.

Important Reminder

As with any system, there are limits to ACC with LSF. Use the brake pedal whenever necessary, and always keep a safe distance between your vehicle and other vehicles.

■ How to activate the system



When the **MAIN** button is pressed, both ACC with LSF and the Lane Keeping Assist System (LKAS) are either turned on or off.

ACC with LSF may not work properly under certain conditions.


ACC with LSF Conditions and Limitations
P. 421

When not using ACC with LSF: Turn off adaptive cruise by pressing the **MAIN** button. This also will turn off the Lane Keeping Assist System (LKAS).

Do not use ACC with LSF under the following conditions:

- On roads with heavy traffic or while driving in continuous stop and go traffic.
- On roads with sharp turns.
- On roads with steep downhill sections, as the set vehicle speed can be exceeded by coasting. In such cases, ACC with LSF will not apply the brakes to maintain the set speed.
- On roads with toll collection facilities or other objects between lanes of traffic, or in parking areas, or facilities with drive through access.

To Set the Vehicle Speed



When driving at 25 mph (40 km/h) or above: Take your foot off the pedal and press the –/SET button when you reach the desired speed. The moment you release the button, the set speed is fixed, and ACC with LSF begins.

When driving slower than 25 mph (40 km/h): If the vehicle is moving and the brake pedal is not depressed, pressing the button fixes the set speed to 25 mph (40 km/h) regardless of current vehicle speed. If your vehicle is stationary and a vehicle is detected ahead, your vehicle speed can be set, even with the brake pedal depressed.



When ACC with LSF starts operating, the vehicle icon, distance bars and set speed appear on the driver information interface.

∑To Set the Vehicle Speed

You can switch the displayed set speed measurements on the driver information interface*/ audio/information screen* between mph and km/h.


Customized Features P. 111, 302

When in Operation

■ There is a vehicle ahead

ACC with LSF monitors if a vehicle ahead of you enters the ACC with LSF range. If a vehicle is detected doing so, the ACC with LSF system maintains or decelerates your vehicle's set speed in order to keep the vehicle's set following interval from the vehicle ahead.

▶ To Set or Change Following Interval P. 424






When a vehicle whose speed is slower than your set speed is detected in front of you, your vehicle starts to slow down.

When in Operation

If the vehicle ahead of you slows down abruptly, or if another vehicle cuts in front of you, the beeper sounds, a message appears on the driver information interface.

Depress the brake pedal, and keep an appropriate distance from the vehicle ahead.



Even if the distance between your vehicle and the vehicle ahead is short, ACC with LSF may start accelerating your vehicle under the following circumstances:

- The vehicle ahead of you is going at almost the same speed as, or faster than, your vehicle.
- A vehicle that cuts in front of you is going faster than your vehicle, gradually increasing the distance between the vehicles.

You can also set the system to beep when a vehicle in front of you comes in and goes out of the ACC with LSF detecting range. Change the **ACC Forward Vehicle Detect Beep** setting.

Customized Features P. 111, 302

■ There is no vehicle ahead



A vehicle icon with dotted-line contour appears on the driver information interface

Your vehicle maintains the set speed without having to keep your foot on the brake or accelerator pedal.

If there previously was a vehicle detected ahead that kept your vehicle from traveling at the set speed, ACC with LSF accelerates your vehicle to the set speed, and then maintains it.

■ When you depress the accelerator pedal

You can temporarily increase the vehicle speed. In this case, there is no audible or visual alert even if a vehicle is in the ACC with LSF range.

ACC with LSF stays on unless you cancel it. Once you release the accelerator pedal, the system resumes an appropriate speed for keeping the following interval while a vehicle ahead is within the ACC with LSF range.

■ A vehicle detected ahead is within ACC with LSF range and slows to a stop



Your vehicle also stops, automatically. The **Stopped** message appears on the driver information interface.

When the vehicle ahead of you starts again, the vehicle icon on the driver information interface blinks. If you press the **RES/+** or **-/ SET** button, or depress the accelerator pedal, ACC with LSF operates again within the prior set speed.

When in Operation ■ Continuous States States

AWARNING

Exiting a vehicle that has been stopped while the ACC with LSF system is operating can result in the vehicle moving without operator control.

A vehicle that moves without operator control can cause a crash, resulting in serious injury or death.

Never exit a vehicle when the vehicle is stopped by ACC with LSF.

Limitations

You may need to use the brake to maintain a safe distance when using ACC with LSF. Additionally, ACC with LSF may not work properly under certain conditions.

ACC with LSF Conditions and Limitations
P. 421

ACC with LSF Conditions and Limitations

The system may automatically shut off and the **ACC** indicator will come on under certain conditions. Some examples of these conditions are listed below. Other conditions may reduce some of the ACC functions.

Front Sensor Camera* P. 414

■ Environmental conditions

• Driving in bad weather (rain, fog, snow, etc.).

■ Roadway conditions

• Driving on a snowy or wet roadway (obscured lane marking, vehicle tracks, reflected lights, road spray, high contrast).

■ Vehicle conditions

- The outside of the windshield is blocked by dirt, mud, leaves, wet snow, etc.
- An abnormal tire or wheel condition (Wrong size, varied size or construction, improperly inflated, compact spare tire, etc.).
- The camera temperature gets too high.
- The parking brake is applied.
- When the lower bumper next to the fog light is dirty.
- When the front of the vehicle tilts up due to heavy cargo in the trunk or rear seats.
- When tire chains are installed

■ ACC with LSF Conditions and Limitations

The radar sensor for ACC with LSF is shared with the collision mitigation braking systemTM (CMBSTM).

Collision Mitigation Braking System™ (CMBS™)* P. 459

You can read about handling information for the camera equipped with this system.

Front Sensor Camera* P. 414

Do not put a sticker on the radar sensor cover or replace the radar sensor cover.

Have your vehicle checked by a dealer if you find any unusual behavior of the system (e.g., the warning message appears too frequently).

If the front of the vehicle is impacted in any of the following situations, the radar sensor may not work properly. Have your vehicle checked by a dealer:


- The vehicle mounted onto a bump, curb, chock, embankment, etc.
- You drive the vehicle where the water is deep.
- Your vehicle has a frontal collision.

■ Detection limitations

- A vehicle or pedestrian suddenly crosses in front of you.
- The distance between your vehicle and the vehicle or pedestrian ahead of you is too short.
- A vehicle cuts in front of you at a slow speed, and it brakes suddenly.
- When you accelerate rapidly and approach the vehicle or pedestrian ahead of you at high speed.
- The vehicle ahead of you is a motorcycle, bicycle, mobility scooter, or other small vehicle.
- When there are animals in front of your vehicle.
- When you drive on a curved or winding or undulating road that makes it difficult for the sensor to properly detect a vehicle or a pedestrian in front of you.
- The speed difference between your vehicle and a vehicle or pedestrian in front of you is significantly large.
- An oncoming vehicle suddenly comes in front of you.
- Your vehicle abruptly crosses over in front of an oncoming vehicle.
- When driving through a narrow iron bridge.
- When the vehicle ahead of you brakes suddenly.
- When the vehicle ahead of you has a unique shape.
- When your vehicle or the vehicle ahead of you is driving on one edge of the lane.

■ To Adjust the Vehicle Speed

Increase or decrease the vehicle speed using the **RES/+** or **-/SET** button on the steering wheel.




- Each time you press the **RES/+** or **-/SET** button, the vehicle speed is increased or decreased by about 1 mph or 1 km/h accordingly.
- If you keep pressing the **RES/+** or **-/SET** button, the vehicle speed increases or decreases by about 5 mph or 5 km/h accordingly.

∑To Adjust the Vehicle Speed

If a vehicle detected ahead is going at a speed slower than your increased set speed, ACC with LSF may not accelerate your vehicle. This is to maintain the set interval between your vehicle and the vehicle ahead.

Continued 423

■ To Set or Change Following Interval



Press the (distance) button to change the ACC with LSF following interval.

Each time you press the button, the following-interval (the interval behind a vehicle detected ahead of you) setting cycles through extra long, long, middle, and short following intervals.

Determine the most appropriate followinginterval setting based on your specific driving conditions. Be sure to adhere to any following-interval requirements set by local regulation.


425

The higher your vehicle's following-speed is, the longer the short, middle, long or extra long following interval becomes. See the following examples for your reference.

Following Interval		When the Set Speed is:	
		50 mph (80 km/h)	65 mph (104 km/h)
Short		83 feet 25 meters 1.1 sec	100 feet 31 meters 1.1 sec
Middle	9	110 feet 33 meters 1.5 sec	137 feet 42 meters 1.5 sec
Long	2	154 feet 47 meters 2.1 sec	200 feet 61 meters 2.1 sec
Extra Long	2	204 feet 62 meters 2.8 sec	265 feet 81 meters 2.8 sec

When your vehicle stops automatically because a vehicle detected ahead of you has stopped, the distance between the two vehicles will vary based on the ACC with LSF distance setting.

■ To Cancel



To cancel ACC with LSF, do any of the following:

- Press the **CANCEL** button.
- Press the **MAIN** button.
 - ACC with LSF indicator goes off.
- Depress the brake pedal.
 - ➤ When the LSF function has stopped the vehicle, you cannot cancel ACC with LSF by depressing the brake pedal.

∑To Cancel

Resuming the prior set speed: After you have canceled ACC with LSF, you can resume the prior set speed while it is still displayed. Press the **RES/+** button.

The set speed cannot be set or resumed when ACC with LSF has been turned off using the **MAIN** button. Press the **MAIN** button to activate the system, then set the desired speed.

■ Automatic cancellation

The beeper sounds and a message appears on the driver information interface when ACC with LSF is automatically canceled. Any of these conditions may cause the ACC with LSF to automatically cancel:

- Bad weather (rain, fog, snow, etc.)
- When the radar sensor in the lower bumper next to the fog light gets dirty.
- The vehicle ahead of you cannot be detected.
- An abnormal tire condition is detected, or the tires are skidding.
- Driving on a mountainous road, or driving off road for extended periods.
- Abrupt steering wheel movement.
- When the ABS, VSA® or CMBS™ is activated.
- When the ABS or VSA® system indicator comes on.
- When the vehicle is stopped on a very steep slope.
- When you manually apply the parking brake.
- When the detected vehicle within the ACC with LSF range is too close to your vehicle
- The camera behind the rearview mirror, or the area around the camera, including the windshield, gets dirty.

The ACC with LSF automatic cancellation can be also triggered by the following causes. In these cases, the parking brake will be automatically applied.


- The driver's seat belt is unfastened when the vehicle is stationary.
- The vehicle stops for more than 10 minutes.
- The engine is turned off.

■ Automatic cancellation ■ Auto

Even though ACC with LSF has been automatically canceled, you can still resume the prior set speed. Wait until the condition that caused ACC with LSF to cancel improves, then press the **–/SET** button.

Continued 427

■ To Switch ACC with LSF to Cruise Control



Press and hold the (distance) button for one second. **Cruise Mode Selected** appears on the driver information interface for two seconds, and then the mode switches to Cruise.

To switch back to ACC with LSF, press and hold the button again for one second. **ACC Mode Selected** appears on the driver information interface for two seconds.

■ When to use

Desired speed in a range above roughly 25 mph (40 km/h) ~.

To Set the Vehicle Speed

Take your foot off the pedal and press the **–/SET** button when you reach the desired speed.

The moment you release the **-/SET** button, the set speed is fixed, and cruise control begins. The **CRUISE CONTROL** indicator comes on.

■ To Adjust the Vehicle Speed

Each time you press the **RES/+** or **-/SET** button, the vehicle speed is increased or decreased by about 1 mph (1.6 km/h).

If you keep the **RES/+** or **-/SET** button pressed, the vehicle speed increases or decreases until you release it. This speed is then set.

To Switch ACC with LSF to Cruise Control

Always be aware which mode you are in. When you are driving in Cruise mode, the system will not assist you to maintain a following interval from a vehicle ahead of you.

■ To Cancel

To cancel cruise control, do any of the following:

- Press the **CANCEL** button.
- Press the **CRUISE** button.
- Depress the brake pedal.

The **CRUISE CONTROL** indicator goes off.

∑To Cancel

Resuming the prior set speed:

After cruise control has been canceled, you can still resume the prior set speed by pressing the **RES/+** button while driving at a speed of at least 25 mph (40 km/h) or more.

You cannot set or resume in the following situations:


- When vehicle speed is less than 25 mph (40 km/h)
- When the **MAIN** button is turned off.

At vehicle speeds of 22 mph (35 km/h) or less, cruise control canceled automatically.

Road Departure Mitigation (RDM) System*

Alerts and helps to assist you when the system detects a possibility of your vehicle unintentionally crossing over detected lane markings.

■ How the System Works



The front camera behind the rearview mirror monitors left and right lane markings (in white or yellow). If your vehicle is getting too close to detected lane markings without a turn signal activated, the system, in addition to a visual alert, applies steering torque and alerts you with rapid vibrations on the steering wheel, to help you remain within the detected lane.

As a visual alert, the **Lane Departure** message appears on the driver information interface.

If the system determines that its steering input is insufficient to keep your vehicle on the roadway, it may apply braking.

► Braking is applied only when the lane markings are solid continuous lines.

The system cancels assisting operations when you turn the steering wheel to avoid crossing over detected lane markings.

If the system operates several times without detecting driver response, the system beeps to alert you.

■Road Departure Mitigation (RDM) System*

Important Safety Reminder

Like all assistance systems, the RDM system has limitations.

Over-reliance on the RDM system may result in a collision. It is always your responsibility to keep the vehicle within your driving lane.

The RDM system only alerts you when lane drift is detected without a turn signal in use. The RDM system may not detect all lane markings or lane departures; accuracy will vary based on weather, speed and lane marker condition. It is always your responsibility to safely operate the vehicle and avoid collisions.

You can read about handling information for the camera equipped with this system.

Front Sensor Camera* P. 414

The RDM system may not work properly or may work improperly under the certain conditions:

₹ RDM Conditions and Limitations P. 432


There are times when you may not notice RDM functions due to your operation of the vehicle, or road surface conditions. If the **Lane Departure** message appears repeatedly and you do not apply responsive actions, the beeper sounds and RDM functions will be canceled.

How the System Activates

The system becomes ready to start searching for lane markings when all the following conditions are met:

- The vehicle is traveling between about 45 and 90 mph (72 and 145 km/h).
- The vehicle is on a straight or slightly curved road.
- The turn signals are off.
- The brake pedal is not depressed.
- The wipers are not in continuous operation.
- The system makes a determination that the driver is not actively accelerating, braking or steering.

RDM On and Off



Press the RDM button to turn the system on and off.

➤ The indicator in the button comes on and the message appears on the driver information interface when the system is on.

➤ How the System Activates

The RDM system may automatically shut off and the $|\vec{\xi}|$ indicator comes and stays on.

Indicators P. 74

RDM system function can be impacted when the vehicle is:

- Not driven within a traffic lane.
- Driven on the inside edge of a curve, or outside of a lane.
- Driven in a narrow lane.

When you have selected **Warning Only** from the customized options using the audio/information screen, the system does not operate the steering wheel and braking.

Continued 431

■ RDM Conditions and Limitations

The system may not properly detect lane markings and the position of your vehicle under certain conditions. Some examples of these conditions are listed below.

■ Environmental conditions

- Driving in bad weather (rain, fog, snow, etc.).
- Sudden changes between light and dark, such as an entrance or exit of a tunnel.
- There is little contrast between lane lines and the roadway surface.
- Driving into low sunlight (e.g., at dawn or dusk).
- Strong light is reflected onto the roadway.
- Driving in the shadows of trees, buildings, etc.
- Shadows of adjacent objects are parallel to lane markings.
- Roadway objects or structures are misinterpreted as lane markers.
- Reflections on the interior of the front windshield.

■ Roadway conditions

- Driving on a snowy or wet roadway (obscured lane marking, vehicle tracks, reflected lights, road spray, high contrast).
- Driving on a road with temporary lane markings.
- Faint, multiple, or varied lane markings are visible on the roadway due to road repairs or old lane markings.
- The roadway has merging, split, or crossing lines (e.g., such as at an intersection or crosswalk).
- The lane markings are extremely narrow, wide, or changing.
- The vehicle in front of you is driving near the lane lines.
- The road is hilly or the vehicle is approaching the crest of a hill.
- Driving on rough or unpaved roads, or over bumpy surfaces.
- When objects on the road (curb, guard rail, pylons, etc.) are recognized as white lines (or yellow lines).
- Driving on roads with double lines.

■ Vehicle conditions


- Headlight lenses are dirty or the headlights are not properly adjusted.
- The outside of the windshield is streaked or blocked by dirt, mud, leaves, wet snow, etc.
- The inside of the windshield is fogged.
- The camera temperature gets too high.
- An abnormal tire or wheel condition (wrong sized, varied size or construction, improperly inflated, compact spare tire, etc.).
- The vehicle is tilted due to a heavy load or suspension modifications.
- When tire chains are installed.

Lane Keeping Assist System (LKAS)*

Provides steering input to help keep the vehicle in the middle of a detected lane and provides tactile and visual alerts if the vehicle is detected drifting out of its lane.

■Steering input assist

The system applies torque to the steering to keep the vehicle between the left and right lane lines. The applied torque becomes stronger as the vehicle gets closer to either of the lane lines.



When you operate the turn signals to change lanes, the system is suspended, and resumes after the signals are off.

If you make a lane change without operating the turn signals, the LKAS alerts activate, and torque is applied to the steering.

∑Lane Keeping Assist System (LKAS)*

Important Safety Reminders

The LKAS is for your convenience only. It is not a substitute for your vehicle control. The system does not work if you take your hands off the steering wheel or fail to steer the vehicle.

Driver Information Interface Warning and Information Messages* P. 91

Do not place objects on the instrument panel. Objects may reflect on the front windshield and prevent correct detection of the traffic lanes.

LKAS only alerts you when lane drift is detected without a turn signal in use. The LKAS may not detect all lane markings or lane departures; accuracy will vary based on weather, speed, and lane marker condition.

It is always your responsibility to safely operate the vehicle and avoid collisions.

The LKAS is convenient when it is used on freeways.

The LKAS may not work properly or may work improperly under the certain conditions:


LKAS Conditions and Limitations P. 439

You can read about handling information for the camera equipped with this system.

Front Sensor Camera* P. 414


■ Lane Keep Support Function

Provides assistance to keep the vehicle in the center of the lane. When the vehicle nears a white or yellow line, steering force of the electric power steering will become stronger.



■ Lane Departure Warning Function

When the vehicle enters the warning area, the LKAS alerts you with slight steering wheel vibration as well as a warning display.



∑Lane Keeping Assist System (LKAS)*

LKAS may not function as designed while driving in frequent stop and go traffic, or on roads with sharp curves.


When it fails to detect lanes, the system will temporarily be canceled. When lane is detected, system will recover automatically.

When the System can be Used

The system can be used when the following conditions are met.

- The lane in which you are driving has detectable lane markers on both sides, and your vehicle is in the center of the lane.
- The vehicle speed is between 45 and 90 mph (72 and 145 km/h).
- You are driving on a straight or slightly curved road.
- The turn signals are off.
- The brake pedal is not depressed.
- The wipers are not in continuous operation.

■ How to activate the system



- 1. Press the MAIN button.
 - ► The LKAS is on in the driver information interface.

The system is ready to use.

- 2. Press the LKAS button.
 - ► Lane outlines appear on the driver information interface.

The system is activated.

If the vehicle drifts toward either the left or right lane line due to the system applying torque, turn off the LKAS and have your vehicle checked by a dealer.




- **3.** Keep your vehicle near the center of the lane while driving.
 - ➤ The dotted outer lines change to solid ones once the system starts operating after detecting the left and right lane markings.

When the System can be Used

The LKAS temporarily deactivates when it fails to detect lane lines. When the system detects the lines again, it comes back on automatically.

■ To cancel



To cancel the LKAS:

Press the **MAIN** or LKAS button.

The LKAS is turned off every time you stop the engine, even if you turned it on the last time you drove the vehicle.

∑To cancel

Pressing the **MAIN** button also turns ACC with LSF on and off.

Continued 437



When the LKAS is suspended, the lane lines on the driver information interface change to contour lines, and the beeper sounds (if activated).

■ The system operation is suspended if you:

- Set the wipers to continuous operation.
 - Turning the wipers off resumes the LKAS.

Models with automatic intermittent wipers

- Set the wiper switch to **AUTO** and the wipers operate continuously.
 - ► The LKAS resumes when the wipers stop or operate intermittently.

All models

- Decrease the vehicle speed to 40 mph (64 km/h) or less.
 - ► Increasing the vehicle speed to 45 mph (72 km/h) or more resumes the LKAS.
- Depress the brake pedal.
 - ► The LKAS resumes and starts detecting the lane lines again once you release the brake pedal.

■ The LKAS may automatically be suspended when:

- The system fails to detect lane lines.
- The steering wheel is quickly turned.
- You fail to steer the vehicle.
- The vehicle runs on a curved road over the speed limit.
- Driving through a sharp curve.
- Driving at a speed in excess of approximately 90 mph (145 km/h).
- The ABS or VSA system engages.

Once these conditions no longer exist, the LKAS automatically resumes.

439

■ The LKAS may automatically be canceled when:

- The camera temperature gets extremely high or low.
- The camera behind the rearview mirror, or the area around the camera, including the windshield, gets dirty.

The beeper sounds if the LKAS is automatically canceled.

LKAS Conditions and Limitations

The system may not detect lane markings and therefore may not keep the vehicle in the middle of a lane under certain conditions, including the following:

■ Environmental conditions

- Driving in bad weather (rain, fog, snow, etc.).
- Sudden changes between light and dark, such as an entrance or exit of a tunnel.
- There is little contrast between lane lines and the roadway surface.
- Driving into low sunlight (e.g., at dawn or dusk).
- Strong light is reflected onto the roadway.
- Driving in the shadows of trees, buildings, etc.
- Shadows of adjacent objects are parallel to lane markings.
- Roadway objects or structures are misinterpreted as lane markers.
- Reflections on the interior of the front windshield.

■ Roadway conditions

- Driving on a snowy or wet roadway (obscured lane marking, vehicle tracks, reflected lights, road spray, high contrast).
- Driving on a road with temporary lane markings.
- Faint, multiple, or varied lane markings are visible on the roadway due to road repairs or old lane markings.
- The roadway has merging, split, or crossing lines (e.g., such as at an intersection or crosswalk).
- The lane markings are extremely narrow, wide, or changing.
- The vehicle in front of you is driving near the lane lines.
- The road is hilly or the vehicle is approaching the crest of a hill.
- Driving on rough or unpaved roads, or over bumpy surfaces.
- When objects on the road (curb, guard rail, pylons, etc.) are recognized as white lines (or yellow lines).
- Driving on roads with double lines.


■ Vehicle conditions

- Headlight lenses are dirty or the headlights are not properly adjusted.
- The outside of the windshield is streaked or blocked by dirt, mud, leaves, wet snow, etc.
- The inside of the windshield is fogged.
- The camera temperature gets too high.
- An abnormal tire or wheel condition (wrong size, varied size or construction, improperly inflated, compact spare tire, etc.).
- The vehicle is tilted due to a heavy load or suspension modifications.

Vehicle Stability Assist (VSA®), aka Electronic Stability Control (ESC), System

Helps to stabilize the vehicle during cornering if the vehicle turns more or less than what was intended. It also assists in maintaining traction on slippery surfaces. It does so by regulating engine output and selectively applying the brakes.

■ VSA® Operation



When VSA® activates, you may notice that the engine does not respond to the accelerator. You may also notice some noise from the hydraulic system. You will also see the indicator blink.

■Vehicle Stability Assist (VSA®), aka Electronic Stability Control (ESC), System

VSA® may not function properly if tire types and sizes are mixed. Make sure to use the same size and type of tire, and the air pressures are as specified.

When the VSA® system indicator comes on and stays on while driving, there may be a problem with the system. While this may not interfere with normal driving, have your vehicle checked by a dealer immediately.

The VSA® indicator may come on after re-connecting the battery. Drive a short distance at more than 12 mph (20 km/h). The indicator should go off. If it does not, have your vehicle checked by a dealer.

VSA® cannot enhance stability in all driving situations and does not control the entire braking system. You still need to drive and corner at speeds appropriate for the conditions and always leave a sufficient margin of safety.

The main function of the VSA® system is generally known as Electronic Stability Control (ESC). The system also includes a traction control function.

Continued 441

■ VSA® On and Off



This button is on the driver side control panel. To partially disable VSA® functionality/ features, press and hold it until you hear a beep.

The traction control stops fully functioning, allowing the wheels to spin more freely at low speed. The VSA® OFF indicator will also come on and a message on the driver information interface* informs you that the mode is changed.

To restore VSA® functionality/features, press the (VSA® OFF) button until you hear a beep.

VSA® is turned on every time you start the engine, even if you turned it off the last time you drove the vehicle.

■Vehicle Stability Assist (VSA®), aka Electronic Stability Control (ESC), System

Without VSA®, your vehicle will have normal braking and cornering ability, but it will not have VSA® traction and stability enhancement.

With the Button pressed, your vehicle will have normal braking and cornering ability, but VSA® traction and stability enhancement becomes less effective.

When the B button is pressed, the traction control function becomes less effective. This allows for the wheels to spin more freely at low speed. You should only attempt to free your vehicle with the B button pressed if you are not able to free it without.

Immediately after freeing your vehicle, be sure to press the 💂 button again. We do not recommend driving your vehicle with the 💂 button pressed (indicator on).

You may hear a motor sound coming from the engine compartment while system checks are being performed immediately after starting the engine or while driving. This is normal.

The VSA® OFF indicator may come on after reconnecting the battery. Drive a short distance at more than 12 mph (20 km/h). The indicator should go off. If it does not, have your vehicle checked by a dealer.

Agile Handling Assist System

Lightly brakes selective wheels, as needed, when you turn the steering wheel, and helps support the vehicle's stability and performance during cornering.

■ Agile Handling Assist System


The agile handling assist system cannot enhance stability in all driving situations. You still need to drive and corner at speeds appropriate for the conditions and always leave a sufficient margin of safety.

When the VSA® indicator comes on and stays on while driving, the agile handling assist system does not activate.

You may hear a sound coming from the engine compartment while the system is activated. This is normal.

LaneWatch™*

Is an assistance system that allows you to check the passenger side rear areas displayed on the audio/information screen when the turn signal is activated to the passenger's side. A camera in the passenger side door mirror monitors these areas and allows you to check for vehicles, in addition to your visual check and use of the passenger door mirror. You can also keep the system on for your convenience while driving.



∑LaneWatch™*

AWARNING

Failure to visually confirm that it is safe to change lanes before doing so may result in a crash and serious injury or death.

Do not rely only on LaneWatch while driving.

Always look in your mirrors, to either side of your vehicle, and behind you for other vehicles before changing lanes.

Important Safety Reminder

Like all assistance systems, LaneWatch has limitations. Over reliance on LaneWatch may result in a collision.

The LaneWatch function can be affected by weather, lighting (including headlights and low sun angle), ambient darkness, camera condition, and loading.

The LaneWatch may not provide the intended display of traffic to the side and rear under the following conditions:

- Your vehicle's suspension has been altered, changing the height of the vehicle.
- Your tires are over or under inflated.
- Your tires or wheels are of varied size or construction.

■ Customizing the LaneWatch settings*

You can customize the following items using the audio/information screen.

- **Show with Turn Signal**: Selects whether LaneWatch monitor comes on when you operate the turn signal light lever.
- **Display Time after Turn Signal Off**: Changes the length of time the LaneWatch display stays on after you pull the turn signal lever back.
- **Reference Lines**: Selects whether the reference lines appear on the LaneWatch monitor.
- **Display**: Allows for display adjustments of items, such as brightness, contrast and black level. This setting is part of the **System** setup group.
 - **≧** Customized Features P. 302

■ Reference Lines



Three lines that appear on the screen can give an idea of how far the vehicles or objects on the screen are from your vehicle, respectively. If an object is near line 1 (in red), it indicates that it is close to your vehicle whereas an object near line 3 farther away.

∑LaneWatch™*

The LaneWatch camera view is restricted. Its unique lens makes objects on the screen look slightly different from what they are.

LaneWatch display does not come on when the shift lever is in $\boxed{\textbf{R}}$.

For proper LaneWatch operation:

- The camera is located in the passenger side door mirror. Always keep this area clean. If the camera lens is covered with dirt or moisture, use a soft, moist cloth to keep the lens clean and free of debris.
- Do not cover the camera lens with labels or stickers of any kind.
- Do not touch the camera lens.

■ Reference Lines

The area around the reference line 1 (red) is very close to your vehicle. As always, make sure to visually confirm the safety of a lane change before changing lanes.

The distance between your vehicle and lines 1, 2 and 3 on the screen vary depending on road conditions and vehicle loading. For example, the reference lines on the screen may seem to appear closer than the actual distances when the rear of your vehicle is more heavily loaded.

Consult a dealer if:

- The passenger side door mirror, or area around it is severely impacted, resulting in changing the camera angle.
- The LaneWatch display does not come on at all.

* Not available on all models

U.S. models

Tire Pressure Monitoring System (TPMS)

Instead of directly measuring the pressure in each tire, the TPMS on this vehicle monitors and compares the rolling radius and rotational characteristics of each wheel and tire while you are driving to determine if one or more tires are significantly under-inflated. This will cause the low tire pressure/TPMS indicator to come on and a message to appear on the driver information interface*.

■ TPMS Calibration

You must start TPMS calibration every time you:

- Adjust the pressure in one or more tires.
- Rotate the tires.
- Replace one or more tires.

Before calibrating the TPMS:

- Set the cold tire pressure in all four tires.
 - **≧ Checking Tires** P. 516

Make sure:

• The vehicle is at a complete stop.

Manual transmission models

• The shift lever is in **N**.

Continuously variable transmission models

• The shift lever is in **P**.

All models

- The ignition switch is in ON III*1.
- *1: Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.
- * Not available on all models

∑Tire Pressure Monitoring System (TPMS)

The system does not monitor the tires when driving at low speed.

Conditions such as low ambient temperature and altitude change directly affect tire pressure and can trigger the low tire pressure/TPMS indicator to come on.

Tire pressure checked and inflated in:

- Warm weather can become under-inflated in colder weather.
- Cold weather can become over-inflated in warmer weather.

The low tire pressure indicator will not come on as a result of over inflation.

The TPMS may not function properly if tire type and size are mixed. Make sure to use the same size and type of tire.


⚠ Checking and Maintaining Tires P. 516


The low tire pressure/TPMS indicator may come on with a delay or may not come on at all when:

- You rapidly accelerate, decelerate, or turn the steering wheel.
- You drive on snowy or slippery roads.
- Snow chains are used.

The low tire pressure/TPMS indicator may come on under the following conditions:

- A compact spare tire is used.
- There is a heavier and uneven load on the tires, such as when towing a trailer, than the condition at calibration.
- Snow chains are used.





Models with information display

Press and hold the TPMS button until the low tire pressure/TPMS indicator blinks twice, indicating the calibration process has begun.

- If the low tire pressure/TPMS indicator does not blink, confirm the above conditions then press and hold the TPMS button again.
- The calibration process finishes automatically.

Models with color audio system

Models with driver information interface

You can calibrate the system from the customized features on the driver information interface.

- Press the then button to select button to select button.
 Wehicle Settings), then press the ENTER button.
 - ► TPMS Calibration appears on the display.
- 2. Press the ENTER button.
 - ▶ The display switches to the customization setup screen, where you can select Cancel or Calibrate.
- 3. Press the ▲/▼ button and select Calibrate, then press the ENTER button.
 - ► Calibration Started screen appears, then the display returns to the customization menu screen.
- If the **Calibration Failed to Start** message appears, repeat steps 2-3.
- The calibration process finishes automatically.

TPMS Calibration

- TPMS cannot be calibrated if a compact spare tire is installed.
- The calibration process requires approximately 30 minutes of cumulative driving at speeds between 30-65 mph (48-105 km/h).
- During calibration, if the ignition is turned off then on again, and the vehicle is not moved within 45 seconds, the low tire pressure indicator may come on briefly. This is normal and indicates that the calibration process is not yet complete.

If the snow chains are installed, remove them before calibrating the TPMS.

If the low tire pressure/TPMS indicator comes on even when the properly inflated specified regular tires are installed, have your vehicle checked by a dealer.

We recommend that the tires be replaced with the same brand, model, and size as the originals. Ask a dealer for details.

The low tire pressure/TPMS indicator may come on after re-connecting the battery. Drive a short distance at more than 12 mph (20 km/h). The indicator should go off. If it does not, have your vehicle checked by a dealer.



Models with Display Audio

You can calibrate the system from the customized feature on the audio/information screen.

- **1.** Turn the ignition switch to ON $[II]^{*1}$.
- 2. Select
- 3. Select Settings.
- 4. Select Vehicle.
- 5. Select TPMS Calibration.
- 6. Select Cancel or Calibrate
 - ➤ When the calibration is complete, the display returns to the customization menu screen.
- If the **Unable to initialize TPMS.** message appears, repeat steps 4-5.
- The calibration process finishes automatically.

^{*1:} Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

U.S. models

Tire Pressure Monitoring System (TPMS) - Required Federal Explanation

Each tire, including the spare (if provided), should be checked monthly when cold and inflated to the inflation pressure recommended by the vehicle manufacturer on the vehicle placard or tire inflation pressure label.

(If your vehicle has tires of a different size than the size indicated on the vehicle placard or tire inflation pressure label, you should determine the proper tire inflation pressure for those tires.)

As an added safety feature, your vehicle has been equipped with a tire pressure monitoring system (TPMS) that illuminates a low tire pressure telltale



when one or more of your tires is significantly under-inflated.

Accordingly, when the low tire pressure telltale illuminates, you should stop and check your tires as soon as possible, and inflate them to the proper pressure.

Driving on a significantly under-inflated tire causes the tire to overheat and can lead to tire failure. Under-inflation also reduces fuel efficiency and tire tread life, and may affect the vehicle's handling and stopping ability. Please note that the TPMS is not a substitute for proper tire maintenance, and it is the driver's responsibility to maintain correct tire pressure, even if under-inflation has not reached the level to trigger illumination of the TPMS low tire pressure telltale.

Your vehicle has also been equipped with a TPMS malfunction indicator to indicate when the system is not operating properly. The TPMS malfunction indicator is combined with the low tire pressure telltale. When the system detects a malfunction, the telltale will flash for approximately one minute and then remain continuously illuminated. This sequence will continue upon subsequent vehicle start-ups as long as the malfunction exists.

When the malfunction indicator is illuminated, the system may not be able to detect or signal low tire pressure as intended.

TPMS malfunctions may occur for a variety of reasons, including the installation of replacement or alternate tires or wheels on the vehicle that prevent the TPMS from functioning properly.

Always check the TPMS malfunction telltale after replacing one or more tires or wheels on your vehicle to ensure that the replacement or alternate tires and wheels allow the TPMS to continue to function properly.

Braking

Brake System

Parking Brake

Use the parking brake to keep the vehicle stationary when parked. You can manually apply and release, or automatically release it.


■ Manual operations

Use the electric parking brake switch to apply or release the parking brake. Manually releasing the parking brake using the switch helps your vehicle start slowly and smoothly when facing down hill on steep hills.



Electric Parking

Brake Switch



The electric parking brake can be applied any time the vehicle has battery, no matter which position the ignition switch*1 is in.


Pull the electric parking brake switch up gently and securely.

► The parking brake indicator comes on.

■ To release manually

The vehicle must be ON [II]*1 in order to release the electric parking brake.

- **1.** Depress the brake pedal.
- **2.** Press the electric parking brake switch.
 - The parking brake indicator goes off.



▶ Parking Brake

You may hear the electric parking brake system operating from the rear wheel area when you apply or release the parking brake. This is normal.

The brake pedal may slightly move due to the electric parking brake system operation when you apply or release the parking brake. This is normal.

You cannot apply or release the parking brake if the battery goes dead.

☑ Jump Starting P. 546

If you pull up and hold the electric parking brake switch while driving, the brakes on all four wheels are applied by the VSA system until the vehicle come to a stop. The electric parking brake then applies, and the switch should be released.

In the following situations, the parking brake automatically operates.

- When the vehicle stops with the automatic brake hold system activated for more than 10 minutes.
- When the driver's seat belt is unfastened while your vehicle is stopped and the brake hold system is applied.
- When the engine is turned off while the brake hold system is applied.
- When there is a problem with the brake hold system while brake hold is applied.

Models with ACC with LSF

- When the vehicle is stops more than 10 minutes while ACC with LSF is activated.
- When the driver's seat belt is unfastened while your vehicle is stopped automatically by ACC with LSF.
- When the engine is turned off while ACC with LSF is activated.

Manual transmission models

 When there is a problem with the electric parking brake switch, after you turn the ignition switch to LOCK 0 *1.

Continued 451

■ To release automatically


Use the accelerator pedal to release the parking brake when you are starting the vehicle facing uphill, or in a traffic jam.

Continuously variable transmission models

Depressing the accelerator pedal releases the parking brake.

Manual transmission models


Depress the accelerator pedal while releasing the clutch pedal releases the parking brake.



Continuously variable transmission models

Gently depress the accelerator pedal.

▶ The parking brake indicator goes off.



Manual transmission models

Gently depress the accelerator pedal and release the clutch pedal.

▶ The parking brake indicator goes off.

▶ Parking Brake

If the parking brake cannot be released automatically, release it manually.

When the vehicle is travelling uphill, the accelerator pedal may need to be pressed farther to automatically release the electric parking brake.

The parking brake cannot be released automatically while the following indicators are on:

- Malfunction indicator lamp
- Transmission indicator

The parking brake may not be released automatically while the following indicators are on:

- Brake system indicator
- VSA® system indicator
- ABS indicator
- Supplemental restraint system indicator

Manual transmission models

The clutch pedal is fully depressed before gently depress the accelerator pedal and release the clutch pedal.

The parking brake automatically releases as you depress the accelerator pedal when:

- You are wearing the driver's seat belt.
- The engine is running.

Continuously variable transmission models

• The transmission is not in P or N.

Manual transmission models

• The transmission is not in **N**.

■ Foot Brake

Your vehicle is equipped with disc brakes at all four wheels. A vacuum power assist helps to reduce the effort needed on the brake pedal. The brake assist system increases the stopping force when you depress the brake pedal hard in an emergency situation. The anti-lock brake system (ABS) helps you retain steering control when braking very hard.

Brake Assist System P. 458

■ Anti-lock Brake System (ABS) P. 457

>> Foot Brake

Check the brakes after driving through deep water, or if there is a buildup of road surface water. If necessary, dry the brakes by lightly depressing the pedal several times.

If you hear a continuous metallic friction sound when applying the brakes, the brake pads need to be replaced. Have your vehicle checked by a dealer.


Constantly using the brake pedal while going down a long hill builds up heat, which reduces the brake effectiveness. Apply engine braking by taking your foot off the accelerator pedal and downshifting to a lower gear/speed position. With manual transmission use a lower gear for greater engine braking.

Do not rest your foot on the brake pedal while driving, as it will lightly apply the brakes and cause them to lose effectiveness over time and reduce pad life. It will also confuse drivers behind you.

Automatic Brake Hold

Continuously variable transmission models

Keeps the brake applied after releasing the brake pedal until the accelerator pedal is pressed. You can use this system while the vehicle is temporarily stopped, like at traffic lights and in heavy traffic.



Fasten your seat belt properly, then start the engine. Press the automatic brake hold button.

 The automatic brake hold system indicator comes on. The system is turned on. Depress the brake pedal to come to a complete stop. The shift lever must not be in P or R.

- The automatic brake hold indicator comes on. Braking is kept for up to 10 minutes.
- Release the brake pedal after the automatic brake hold indicator comes on.

Depress the accelerator pedal while the shift lever is in a position other than P or N. The brake hold is disengaged and the vehicle starts to move.

 The automatic brake hold indicator goes off. The system releases the brake automatically. ■ Automatic Brake Hold

AWARNING

Activating the automatic brake hold system on steep hills or slippery roads may still allow the vehicle to move if you remove your foot from the brake pedal.

If a vehicle unexpectedly moves, it may cause a crash resulting in serious injury or death.

Never activate the automatic brake hold system or rely on it to keep a vehicle from moving when stopped on a steep hill or slippery roads.

AWARNING

Using the automatic brake hold system to park the vehicle may result in the vehicle unexpectedly moving.


If a vehicle moves unexpectedly, it may cause a crash, resulting in serious injury or death.

Never leave the vehicle when braking is temporarily kept by automatic brake hold and always park the vehicle by putting the transmission in P and applying the parking brake

Manual transmission models

Keeps the brake applied after releasing the brake pedal until you change a gear to a position other than $\boxed{\mathbf{N}}$ and:

- Release the clutch pedal on a level road or when facing downhill.
- Release the clutch pedal and depress the accelerator pedal when facing uphill. You can use this system while the vehicle is temporarily stopped, like at traffic lights and in heavy traffic.



Continued 455

■ The system automatically cancels when:

• You engage the parking brake.

Continuously variable transmission models

• You depress the brake pedal and move the shift lever to P or R.

All models


Under the following conditions, the system automatically cancels, and the parking brake is applied:

- Braking is kept for more than 10 minutes.
- The driver's seat belt is unfastened.
- The engine is turned off.
- There is a problem with automatic brake hold system.
- The battery is disconnected.

Manual transmission models

• The engine stalls.

■ Turning off the automatic brake hold system



While the system is on, press the automatic brake hold button again.

► The automatic brake hold system indicator goes off.

If you want to turn off automatic brake hold while the system is in operation, press the automatic brake hold button with the brake pedal depressed.

While the system is activated, you can turn off the engine or park the vehicle through the same procedure as you normally do.

When Stopped P. 467

Whether the system is on, or the system is activated, the automatic brake hold turns off once the engine is off.

Manual transmission models

The system turns off if the engine stalls while automatic brake hold is active or the system is on.

∑Turning on the system

Make sure to turn off the automatic brake hold system before using an automated car wash.

You may hear an operating noise if the vehicle moves while the automatic brake hold system is in operation.

Anti-lock Brake System (ABS)

ABS

Helps prevent the wheels from locking up, and helps you retain steering control by pumping the brakes rapidly, much faster than you.

The electronic brake distribution (EBD) system, which is part of the ABS, also balances the front-to-rear braking distribution according to vehicle loading.

You should never pump the brake pedal. Let the ABS work for you by always keeping firm, steady pressure on the brake pedal. This is sometimes referred to as "stomp and steer."

■ ABS operation

The brake pedal may pulsate slightly when the ABS is working. Keep holding the pedal firmly down. On dry pavement, you will need to press on the brake pedal very hard before the ABS activates. However, you may feel the ABS activate immediately if you are trying to stop on snow or ice.

When the vehicle speed goes under 6 mph (10 km/h), the ABS stops.

Mari Anti-lock Brake System (ABS) Mari Anti-

NOTICE

The ABS may not function correctly if you use an incorrect tire type and size.

When the **ABS** indicator comes on while driving, there may be a problem with the system. While normal braking is not affected, there is a possibility of the ABS not operating. Have the vehicle checked by a dealer immediately.

The ABS does not reduce the time or distance it takes to stop the vehicle. It only helps with steering control during hard braking.

In the following cases, your vehicle may need more stopping distance than a vehicle without the ABS:

- When driving on rough road surfaces, including when driving on uneven surfaces, such as gravel or snow.
- When snow chains are installed.

You may hear a motor sound coming from the engine compartment while system checks are being performed immediately after starting the engine or while driving. This is normal.

Brake Assist System

■ Brake Assist System

Designed to assist the driver by generating greater braking force when you depress the brake pedal hard during emergency braking.

■ Brake assist system operation


Press the brake pedal firmly for more powerful braking.

When brake assist operates, the pedal may wiggle slightly and an operating noise may be heard. This is normal. Keep holding the brake pedal firmly down.

Collision Mitigation Braking System™ (CMBS™)*

Can assist you when there is a possibility of your vehicle colliding with a vehicle or a pedestrian detected in front of yours. The CMBS™ is designed to alert you when a potential collision is determined, as well as to reduce your vehicle speed to help minimize collision severity when a collision is deemed unavoidable.

■ How the system works



The system starts monitoring the roadway ahead when your vehicle speed is about 3 mph (5 km/h) and there is a vehicle in front of you.

The CMBS™ activates when:

- The speed difference between your vehicle and a vehicle or pedestrian detected in front of you becomes about 3 mph (5 km/h) and over with a chance of a collision.
- Your vehicle speed is about 62 mph (100 km/h) or less and there is a chance of a collision with an oncoming detected vehicle or a pedestrian in front of you.

Important Safety Reminder

The CMBS™ is designed to reduce the severity of an unavoidable collision. It does not prevent collision nor stop the vehicle automatically. It is still your responsibility to operate the brake pedal and steering wheel appropriately according to the driving conditions.

The CMBS™ may not activate or may not detect a vehicle in front of your vehicle under certain conditions:

■ CMBS[™] Conditions and Limitations P. 463

You can read about handling information for the camera equipped with this system.

Front Sensor Camera* P. 414

Be careful not to have the radar sensor cover strongly impacted.

➤ How the system works


Rapid vibrations on the steering wheel alert you when your vehicle speed is between 19 and 62 mph (30 and 100 km/h) with an oncoming vehicle detected in front of you.

When the CMBS™ activates, it may automatically apply the brake. It will be canceled when your vehicle stops or a potential collision is not determined.

■ When the system activates

The system provides visual, audible and tactile alerts of a possible collision, and stops if the collision is avoided.

► Take appropriate action to prevent a collision (apply the brakes, change lanes, etc.)



At system's earliest collision alert stage, you can change the distance (**Long/Normal/Short**) between vehicles at which alerts will come on through audio/information screen setting options.

≥ List of customizable options P. 114

■ Vibration alert on the steering wheel

When a potential collision to an oncoming detected vehicle is determined, the system alerts you with rapid vibration on the steering wheel, in addition to visual and audible alerts.

➤ Take appropriate action to prevent a collision (apply the brakes, operate the steering wheel, etc.).

When the system activates

The camera in the CMBS™ is also designed to detect pedestrians.

However, this pedestrian detection feature may not activate or may not detect a pedestrian in front of your vehicle under certain conditions.

Refer to the ones indicating the pedestrian detection limitations from the list.

► CMBS™ Conditions and Limitations P. 463

Vibration alert function is disabled when the electric power steering (EPS) system indicator comes on.


Electric Power Steering (EPS) System Indicator P. 80

■ Collision Alert Stages

The system has three alert stages for a possible collision. However, depending on circumstances, the CMBS™ may not go through all of the stages before initiating the last stage.

Distance between vehicles		CMBS TM			
		The radar sensor detects a vehicle	Audible & Visual WARNINGS	Steering Wheel	Braking
Stage one	Normal Vehicle Long Short Ahead Your Vehicle	There is a risk of a collision with the vehicle ahead of you.	When in Long , visual and audible alerts come on at a longer distance from a vehicle ahead than in Normal setting, and in Short , at a shorter distance than in Normal .	In case of an oncoming vehicle detected, rapid vibration is provided.	_
Stage two	Your Vehicle Ahead	The risk of a collision has increased, time to respond is reduced.	Visual and audible alerts.	_	Lightly applied
Stage three	Your Vehicle Vehicle Ahead →	The CMBS [™] determines that a collision is unavoidable.			Forcefully applied

CMBS™ On and Off



Press this button until the beeper sounds to switch the system on or off.

When the CMBS™ is off:

- The beeper sounds.
- The CMBS™ indicator in the instrument panel comes on.
- A message on the driver information interface reminds you that the system is off.

The CMBSTM is in the previously selected ON or OFF setting each time you start the engine.

Collision Mitigation Braking System™ (CMBS™)*

The CMBS™ may automatically shut off, and the CMBS™ indicator will come and stay on under certain conditions:

► CMBS™ Conditions and Limitations P. 463

The CMBS $^{\text{TM}}$ indicator may come on after reconnecting the battery.

Drive a short distance at more than 12 mph (20 km/h). The indicator should go off. If it does not, have your vehicle checked by a dealer.

■ CMBS™ Conditions and Limitations

The system may automatically shut off and the CMBS™ indicator will come on under certain conditions. Some examples of these conditions are listed below. Other conditions may reduce some of the CMBS™ functions.

Front Sensor Camera* P. 414

■ Environmental conditions

- Driving in bad weather (rain, fog, snow, etc.).
- Sudden changes in ambient light, such as an entrance or exit of a tunnel.
- There is little contrast between objects and the background.
- Driving into low sunlight (e.g., at dawn or dusk).
- Strong light is reflected onto the roadway.
- Driving in the shadows of trees, buildings, etc.
- Roadway objects or structures are misinterpreted as vehicles and pedestrians.
- Reflections on the interior of the windshield.

■ Roadway conditions

- Driving on a snowy or wet roadway (obscured lane marking, vehicle tracks, reflected lights, road spray, high contrast on a snowy or wet roadway).
- Driving on curvy, winding, or undulating roads.

CMBS™ Conditions and Limitations

Do not put a sticker on the radar sensor cover or replace the radar sensor cover.

If you need the radar sensor to be repaired, or removed, or the radar sensor cover is strongly impacted, turn off the system by pressing the $CMBS^TM$ off button and take your vehicle to a dealer.

■ Vehicle conditions

- Headlight lenses are dirty or the headlights are not properly adjusted.
- The outside of the windshield is blocked by dirt, mud, leaves, wet snow, etc.
- The inside of the windshield is fogged.
- An abnormal tire or wheel condition (wrong size, varied size or construction, improperly inflated, compact spare tire, etc.).
- When tire chains are installed.
- The vehicle is tilted due to a heavy load or suspension modifications.
- The camera temperature gets too high.
- Driving with the parking brake applied.
- When the radar sensor in the front grille gets dirty.

■ Detection limitations

- A vehicle or pedestrian suddenly crosses in front of you.
- The distance between your vehicle and the vehicle or pedestrian ahead of you is too short.
- A vehicle cuts in front of you at a slow speed, and it brakes suddenly.
- When you accelerate rapidly and approach the vehicle or pedestrian ahead of you at high speed.
- The vehicle ahead of you is a motorcycle, bicycle, mobility scooter or other small vehicle
- When there are animals in front of your vehicle.
- When you drive on a curved, winding or undulating road that makes it difficult for the sensor to properly detect a vehicle in front of you.
- The speed difference between your vehicle and a vehicle or pedestrian in front of you is significantly large.
- An oncoming vehicle suddenly comes in front of you.
- Another vehicle suddenly comes in front of you at an intersection, etc.
- Your vehicle abruptly crosses over in front of an oncoming vehicle.
- When driving through a narrow iron bridge.
- When the lead vehicle suddenly slows down.

Limitations applicable to pedestrian detection only

- When there is a group of people in front of your vehicle walking together side by side.
- Surrounding conditions or belongings of the pedestrian alter the pedestrian's shape, preventing the system from recognizing that the person is a pedestrian.
- When the pedestrian is shorter than about 3.3 feet (1 meter) or taller than about 6.6 feet (2 meters) in height.
- When a pedestrian blends in with the background.
- When a pedestrian is bent over or squatting, or when their hands are raised or they are running.
- When several pedestrians are walking ahead in a group.
- When the camera cannot correctly identify that a pedestrian is present due to an unusual shape (holding luggage, body position, size).

Continued 465

■ With Little Chance of a Collision

The CMBS™ may activate even when you are aware of a vehicle ahead of you, or when there is no vehicle ahead. Some examples of this are:

■ When Passing

Your vehicle approaches another vehicle ahead of you and you change lanes to pass.

■ At an intersection

Your vehicle approaches or passes another vehicle that is making a left or right turn.

On a curve

When driving through curves, your vehicle comes to a point where an oncoming vehicle is right in front of you.

■ Through a low bridge at high speed

You drive under a low or narrow bridge at high speed.

■ Speed bumps, road work sites, train tracks, roadside objects, etc.

You drive over speed bumps, steel road plates, etc., or your vehicle approaches train tracks or roadside objects (such as a traffic sign and guard rail) on a curve or, when parking, stationary vehicles and walls.

Collision Mitigation Braking System™ (CMBS™)*

For the CMBS™ to work properly:

Always keep the radar sensor cover clean.

Never use chemical solvents or polishing powder for cleaning the sensor cover. Clean it with water or a mild detergent.

Do not paint, or apply any coverings or paint to the radar sensor area. This can impact CMBS operation.

Have your vehicle checked by a dealer if you find any unusual behavior of the system (e.g., the warning message appears too frequently).

If the front of the vehicle is impacted in any of the following situations, the radar sensor may not work properly. Have your vehicle checked by a dealer:

- The vehicle mounted onto a bump, curb, chock, embankment, etc.
- You drive the vehicle where the water is deep.
- Your vehicle has a frontal collision.

Parking Your Vehicle

When Stopped

- **1.** Depress the brake pedal firmly.
- **2.** With the brake pedal depressed, pull up the electric parking brake switch slowly, but fully.

Continuously variable transmission models

3. Move the shift lever from **D** to **P**.

Manual transmission models

3. Move the shift lever to \mathbb{R} or $\mathbb{1}$.

All models

- 4. Turn off the engine.
 - ▶ The parking brake indicator goes off in about 15 seconds.

Always confirm the electric parking brake is set, in particular if you are parked on an incline.

▶ Parking Your Vehicle

Do not park your vehicle near flammable objects, such as dry grass, oil, or timber.

Heat from the exhaust can cause a fire.

NOTICE

Continuously variable transmission models

The following can damage the transmission:

- Depressing the accelerator and brake pedals simultaneously.
- Holding the vehicle in place when facing uphill by depressing the accelerator pedal.
- Moving the shift lever into P before the vehicle stops completely.


Multi-View Rear Camera

About Your Multi-View Rear Camera

The audio/information screen can display your vehicle's rear view.

The display automatically changes to a rear view when the shift lever is moved to \mathbb{R} .

■ Multi-View Rear Camera Display Area



The rear camera view is restricted. You cannot see the corner ends of the bumper or what is underneath the bumper. Its unique lens also makes objects appear closer or farther than they actually are.

Visually confirm that it is safe to drive before backing up. Certain conditions (such as weather, lighting, and high temperatures) may also restrict the rear view. Do not rely on the rearview display which does not give you all information about conditions at the back of your vehicle.

If the camera lens is covered with dirt or moisture, use a soft, moist cloth to keep the lens clean and free of debris.

You can change the **Fixed Guideline** and **Dynamic Guideline** settings.

■ Customized Features P. 302

Fixed Guideline

On: Guidelines appear when you shift into **R**.

Off: Guidelines do not appear.

Dynamic Guidelines

On: Guidelines move according to the steering wheel direction.

Off: Guidelines do not move.

You can view three different camera angles on the rearview display.

Models with color audio system

Press the **LIST/SELECT** (selector) knob to switch the angle.

Models with Display Audio

Touch the appropriate icon to switch the angle.

🕮 : Wide view

🙎 : Normal view

🖺 : Top down view

All models

- If the last used viewing mode was Wide or Normal, the same mode is selected the next time you shift into $\boxed{\mathbf{R}}$.
- If Top View was last used before you turned off the engine, Wide mode is selected next time you turn the ignition switch to ON [II]*1 and shift to R.
- If Top View was last used more than 10 seconds after you shift from R, Wide mode is selected the next time you turn the ignition switch to ON II *1.

^{*1:} Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

Refueling

Fuel Information

■ Fuel recommendation

Unleaded gasoline, pump octane number 87 or higher

Use of a lower octane gasoline can cause a persistent, heavy metallic knocking noise that can lead to engine damage.

■ Top tier detergent gasoline

Because the level of detergency and additives in gasoline vary in the market, Honda endorses the use of "TOP TIER Detergent Gasoline" where available to help maintain the performance and reliability of your vehicle. TOP TIER Detergent Gasoline meets a new gasoline standard jointly established by leading automotive manufacturers to meet the needs of today's advanced engines.

Qualifying gasoline retailers will, in most cases, identify their gasoline as having met "TOP TIER Detergent Gasoline" standards at the retail location. This fuel is guaranteed to contain the proper level of detergent additives and be free of metallic additives. The proper level of detergent additives, and absence of harmful metallic additives in gasoline, help avoid build-up of deposits in your engine and emission control system.

For further important fuel-related information for your vehicle, or on information on gasoline that does not contain MMT, visit www.hondacars.com. In Canada, visit www.honda.ca for additional information on gasoline. For more information on top tier gasoline, visit www.toptiergas.com.

■ Fuel tank capacity: 12.39 US gal (46.9 liters)

NOTICE

We recommend quality gasoline containing detergent additives that help prevent fuel system and engine deposits. In addition, in order to maintain good performance, fuel economy, and emissions control, we strongly recommend the use of gasoline that does NOT contain harmful manganese-based fuel additives such as MMT, if such gasoline is available.

Use of gasoline with these additives may adversely affect performance, and cause the malfunction indicator lamp on your instrument panel to come on. If this happens, contact a dealer for service. Some gasoline today is blended with oxygenates such as ethanol. Your vehicle is designed to operate on oxygenated gasoline containing up to 15% ethanol by volume. Do not use gasoline containing methanol. If you notice any undesirable operating symptoms, try another service station or switch to another brand of gasoline.

How to Refuel

Your fuel tank is not equipped with a fuel fill cap. You can insert the filler nozzle directly into the filler neck. The tank seals itself again when you pull out the filler nozzle.



- **1.** Stop your vehicle with the service station pump on the left side of the vehicle in the rear.
- 2. Turn off the engine.
- **3.** Press the area indicated by the arrow to release the fuel fill door. You will hear a click.
 - ▶ Driver's door must be unlocked.

AWARNING


Gasoline is highly flammable and explosive. You can be burned or seriously injured when handling fuel.

- Stop the engine, and keep heat, sparks, and flame away.
- Handle fuel only outdoors.
- Wipe up spills immediately.

The fuel filler opening is designed to accept only service station filler nozzles for refueling. Use of smaller diameter tubes (e.g., to siphon fuel for other uses) or other non-service station devices can damage the area in and around the filler opening.

The filler nozzle automatically stops to leave space in the fuel tank so that fuel does not overflow as a result of changes in air temperature.

If the fuel nozzle keeps turning off when the tank is not full, there may be a problem with the pump's fuel vapor recovery system. Try filling at another pump. If this does not fix the problem, consult a dealer.



- **4.** Place the end of the filler nozzle on the lower part of filler opening, then insert it slowly and fully.
 - ► Make sure that the end of the filler nozzle goes down along with the filler pipe.
 - ► Keep the filler nozzle level.
 - ► When the tank is full, the filler nozzle will click off automatically.
 - After filling, wait about five seconds before removing the filler nozzle.
- **5.** Shut the fuel fill door by hand.

Do not continue to add fuel after the nozzle has automatically stopped. Additional fuel can exceed the full tank capacity.

If you have to refuel your vehicle from a portable container, use the funnel provided with your vehicle.

Refueling From a Portable Fuel Container
P. 565

Fuel Economy

Improving Fuel Economy


Fuel economy depends on several conditions, including driving conditions, your driving habits, the condition of your vehicle, and loading. Depending on these and other conditions, you may or may not achieve the rated fuel economy of this vehicle.

Maintenance and Fuel Economy

You can optimize your fuel economy with proper maintenance of your vehicle. Always maintain your vehicle in accordance with the messages displayed on the information display*/driver information interface*.

- Use the recommended viscosity engine oil, displaying the API Certification Seal.
- Maintain the specified tire pressure.
- Do not load the vehicle with excess cargo.
- Keep your vehicle clean. A buildup of snow or mud on your vehicle's underside adds weight and increases wind resistance.

Direct calculation is the recommended method to determine actual fuel consumed while driving.



In Canada, posted fuel economy numbers are established following a simulated test. For more information on how this test is performed, please visit http://oee.nrcan.gc.ca/

* Not available on all models 473

Accessories and Modifications

Accessories

When installing accessories, check the following:

- Do not install accessories on the windshield. They can obstruct your view and delay your reaction to driving conditions.
- Do not install accessories over areas marked **SRS AIRBAG**, on the sides or backs of the front seats, on front or side pillars, or near the side windows. Accessories installed in these areas may interfere with proper operation of the vehicle's airbags or may be propelled into you or another occupant if the airbags deploy.
- Be sure electronic accessories do not overload electrical circuits or interfere with proper operation of your vehicle.

Fuses P. 558

• Before installing any electronic accessory, have the installer contact a dealer for assistance. If possible, have a dealer inspect the final installation.

Modifications

Do not modify your vehicle or use non-Honda components that can affect its handling, stability, and reliability.

Overall vehicle performance can be affected. Always make sure all equipment is properly installed and maintained, and that it meets federal, state, province, territory, and local regulations.

■ Accessories and Modifications

AWARNING

Improper accessories or modifications can affect your vehicle's handling, stability, and performance, and cause a crash in which you can be seriously hurt or killed.

Follow all instructions in this owner's manual regarding accessories and modifications.

Honda Genuine accessories are recommended to ensure proper operation on your vehicle.



This chapter discusses basic maintenance.

Before Performing Maintenance	
Inspection and Maintenance	47
Safety When Performing Maintenance.	47
Parts and Fluids Used in Maintenand	ce
Service	47
Maintenance Minder™	47
Maintenance Under the Hood	
Maintenance Items Under the Hood	48
Opening the Hood	49
Recommended Engine Oil	49
Oil Check	49
Adding Engine Oil	
Changing the Engine Oil and Oil Filter	

Engine Coolant	499
Transmission Fluid	50 <i>°</i>
Brake/Clutch * Fluid	502
Refilling Window Washer Fluid	503
Replacing Light Bulbs	504
Checking and Maintaining Wipe	er
Blades	513
Checking and Maintaining Tires	
Checking Tires	516
Tire and Loading Information Label	517
Tire Labeling	517
DOT Tire Quality Grading (U.S. Vehicles)	519
Wear Indicators	52 [′]

Tire Service Life	521
Tire and Wheel Replacement	522
Tire Rotation	523
Winter Tires	524
attery	525
emote Transmitter Care	
Replacing the Button Battery	527
leating System*/Climate Control	
System* Maintenance	529
leaning	
Interior Care	530
Exterior Care	532

* Not available on all models

Before Performing Maintenance

Inspection and Maintenance

For your safety, perform all listed inspections and maintenance to keep your vehicle in good condition. If you become aware of any abnormality (noise, smell, insufficient brake fluid, oil residue on the ground, etc.), have your vehicle inspected by a dealer. (Note, however, that service at a dealer is not mandatory to keep your warranties in effect.)

■ Types of Inspection and Maintenance

■ Daily inspections

Perform inspections before long distance trips, when washing the vehicle, or when refueling.

■ Periodic inspections

- Check the continuously variable transmission fluid level monthly.
 - **▶ Continuously Variable Transmission Fluid** P. 501
- Check the brake/clutch* fluid level monthly.
 - Brake/Clutch* Fluid P. 502
- Check the tire pressure monthly. Examine the tread for wear and foreign objects.
 Checking and Maintaining Tires P. 516
- Check the operation of the exterior lights monthly.
 - Replacing Light Bulbs P. 504
- Check the condition of the wiper blades at least every six months.
 - **≧** Checking and Maintaining Wiper Blades P. 513

≥ Inspection and Maintenance

U.S. models

Maintenance, replacement, or repair of emissions control devices and systems may be done by any automotive repair establishment or individuals using parts that are "certified" to EPA standards.

According to state and federal regulations, failure to perform maintenance on the maintenance main items marked with # will not void your emissions warranties. However, all maintenance services should be performed in accordance with the intervals indicated by the information display*/driver information interface*.

Maintenance Service Items P. 481, 486

If you want to perform complex maintenance tasks that require more skills and tools, you can purchase a subscription to the Service Express website at www techinfo honda com

Authorized Manuals P. 579

If you want to perform maintenance yourself, make sure that you have the necessary tools and skills first. After performing maintenance, update the records in the separate maintenance booklet.

Safety When Performing Maintenance

Some of the most important safety precautions are given here. However, we cannot warn you of every conceivable hazard that can arise in performing maintenance. Only you can decide whether or not you should perform a given task.

Maintenance Safety

- To reduce the possibility of fire or explosion, keep cigarettes, sparks, and flames away from the battery and all fuel related parts.
- Never leave rags, towels, or other flammable objects under the hood.
 - ▶ Heat from the engine and exhaust can ignite them causing a fire.
- To clean parts, use a commercially available degreaser or parts cleaner, not gasoline.
- Wear eye protection and protective clothing when working with the battery or compressed air.
- Engine exhaust contains carbon monoxide, which is poisonous and can kill you.
 - ▶ Operate the engine only when there is sufficient ventilation.

Vehicle Safety

- The vehicle must be in a stationary condition.
 - ► Make sure your vehicle is parked on level ground, the parking brake is set, and the engine is off.
- Be aware that hot parts can burn you.
 - ► Make sure to let the engine and exhaust system cool thoroughly before touching vehicle parts.
- Be aware that moving parts can injure you.
 - ▶ Do not start the engine unless instructed, and keep your hands and limbs away from moving parts.

Safety When Performing Maintenance

AWARNING

Improperly maintaining this vehicle or failing to correct a problem before driving can cause a crash in which you can be seriously hurt or killed.

Always follow the inspection and maintenance recommendations according to the schedules in this owner's manual.

AWARNING

Failure to properly follow maintenance instructions and precautions can cause you to be seriously hurt or killed.

Always follow the procedures and precautions in this owner's manual.

Parts and Fluids Used in Maintenance Service

The use of Honda genuine parts and fluids is recommended when maintaining and servicing your vehicle. Honda genuine parts are manufactured according to the same high quality standards used in Honda vehicles.


Select the Maintenance Minder to see maintenance items that are due soon and to see the percentage of life remaining in the engine oil.

When the engine oil life is less than 15%, a Maintenance Minder message will appear every time you turn the ignition switch to ON \boxed{II}^{*1} , reminding you to bring your vehicle to a dealer for service.

Models with information display

To Use Maintenance Minder™

Displaying the Engine Oil Life



- **1.** Turn the ignition switch to ON II.
- **2.** Press the (TRIP) knob repeatedly until the engine oil life appears on the information display.

The Maintenance Minder indicator (على) stays on in the instrument panel after the engine oil life becomes **0%**. Have the indicated maintenance done by a dealer immediately.

Based on the engine operating conditions and oil age, the remaining engine oil life is calculated and displayed as a percentage.

Displayed Engine Oil Life (%)	Calculated Engine Oil Life (%)
100	100 to 91
90	90 to 81
80	80 to 71
70	70 to 61
60	60 to 51
50	50 to 41
40	40 to 31
30	30 to 21
20	20 to 16
15	15 to 11
10	10 to 6
5	5 to 1
0	0

^{*1:} Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

Continued 479


Displaying the Engine Oil Life

■ Maintenance Minder Messages on the Information Display

To switch the display, press the (TRIP) knob.

witch the display, press t	_ <u></u>		
Oil Life Display	Explanation	Information	Maintenance Minder Indicator
^ 135 OLUFE SO*	When you select the Maintenance Minder screen, it displays codes for maintenance items due at the next engine oil change, along with the percentage of engine oil life remaining.		Comes on for a few seconds when you set the ignition switch to ON, then goes off.
^ 135 OLLIFE 15*	The engine oil life indicator starts to appear along with other duesoon maintenance item codes when the remaining oil life drops to 15 percent.	The engine oil is approaching the end of its service life.	Starts to come on when the remaining engine oil life drops to 15 percent. It goes off when the display is switched.
^ 135 30 miles /	The remaining engine oil has passed its service life, and a negative distance appears after driving over 10 miles (U.S. models) or 10 km (Canadian models). The negative distance on the display blinks.	The engine oil life has passed. The maintenance items must be inspected and serviced immediately.	Stays on as a reminder even when the display is switched.

■ Maintenance Service Items



Maintenance Service Items

- Inspect idle speed every 160,000 miles (256,000 km)
- Adjust the valves during services A, B, 1, 2, or 3 if they are noisy.

U.S. models

CODE	Maintenance Main Items
Α	• Replace engine oil*1
В	 Replace engine oil*¹ and oil filter Inspect front and rear brakes Inspect these items: Tie rod ends, steering gearbox, and boots Suspension components Driveshaft boots Brake hoses and lines (including ABS/VSA) All fluid levels and condition of fluids Exhaust system# Fuel lines and connections#

^{*1:} If a Maintenance Minder indicator does not appear more than 12 months after the display is reset, change the engine oil every year.

CODE	Maintenance Sub Items
1	Rotate tires
2	Replace air cleaner element*2
	• Replace dust and pollen filter*3
	Inspect drive belt
3	• Replace transmission fluid*4
4	Replace spark plugs
	Inspect valve clearance
5	Replace engine coolant
7	• Replace brake fluid*5

- *2: If you drive in dusty conditions, replace the air cleaner element every 15,000 miles (24,000 km).
- *3: If you drive primarily in urban areas that have high concentrations of soot in the air from industry and from diesel-powered vehicles, replace the dust and pollen filter every 15,000 miles (24,000 km).
- *4: Driving in mountainous areas at very low vehicle speeds results in higher transmission temperatures. This requires transmission fluid changes more frequently than recommended by the Maintenance Minder. If you regularly drive your vehicle under these conditions, have the transmission fluid changed every 25,000 miles (40,000 km).
- *5: If a Maintenance Minder Indicator does not appear more than 36 months after the display for item 7 is reset, change the brake fluid every 3 years.

Continued 481

^{#:} See information on maintenance and emissions warranty.

Canadian models

CODE	Maintenance Main Items
Α	• Replace engine oil*1
0	• Replace engine oil*1 and oil filter

- *1: If a Maintenance Minder indicator does not appear more than 12 months after the display is reset, change the engine oil every year.
- *2: If you drive in dusty conditions, replace the air cleaner element every 24,000 km (15,000 miles).
- *3: If you drive primarily in urban areas that have high concentrations of soot in the air from industry and from diesel-powered vehicles, replace the dust and pollen filter every 24,000 km (15,000 miles).
- *4: Driving in mountainous areas at very low vehicle speeds results in higher transmission temperatures. This requires transmission fluid changes more frequently than recommended by the Maintenance Minder. If you regularly drive your vehicle under these conditions, have the transmission fluid changed every 40,000 km (25,000 miles).
- *5: If a Maintenance Minder Indicator does not appear more than 36 months after the display for item 7 is reset, change the brake fluid every 3 years.
- #: See information on maintenance and emissions warranty.


Maintenance Service Items

- Inspect idle speed every 256,000 km (160,000 miles).
- Adjust the valves during services A, 0, 9, 1, 2, or 3 if they are noisy.

CODE	Maintenance Sub Items
1	Rotate tires
2	 Replace air cleaner element*² Replace dust and pollen filter*³ Inspect drive belt
3	 Replace transmission fluid*4
4	Replace spark plugsInspect valve clearance
5	Replace engine coolant
7	• Replace brake fluid*5
9	 Service front and rear brakes Inspect these items: Tie rod ends, steering gearbox, and boots Suspension components Driveshaft boots Brake hoses and lines (including ABS/VSA) All fluid levels and condition of fluids Exhaust system# Fuel lines and connections#

Resetting the Display

Reset the Maintenance Minder display if you have performed the maintenance service.



- **1.** Turn the ignition switch to ON \boxed{II} and have the vehicle at a complete stop.
- **2.** Display the Maintenance Minder by repeatedly pressing the ((TRIP) knob.
- **3.** Press and hold the knob for ten seconds or more.
 - ➤ The display will blink to show it is in reset mode.
- **4.** Rotate the knob to select the item you wish to reset.
 - Reset the selected item by pushing the knob for five seconds or more.

■ Resetting the Display

NOTICE

Failure to reset the relevant item(s) after a maintenance service results in the system showing incorrect maintenance intervals, which can lead to serious mechanical problems.

The dealer will reset the Maintenance Minder display after completing the required maintenance service. If someone other than a dealer performs maintenance service, reset the relevant maintenance item(s) yourself.

Models with driver information interface


To Use Maintenance Minder™

Displaying the Engine Oil Life and Maintenance Items

Certain maintenance items due soon, along with the estimated remaining oil life, appear on the driver information interface.

You can view them on the Maintenance Minder screen at any time.

- **1.** Turn the ignition switch to ON II^{*1}.
- 2. Press the button several times until sist displayed.
- **3.** Press **ENTER** to go to the **Maintenance Minder** screen. The engine oil life appears on the driver information interface along with maintenance items due soon.



*1: Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

Displaying the Engine Oil Life and Maintenance Items

Based on the engine operating conditions and oil age, the remaining engine oil life is calculated and displayed as a percentage.

Displayed Engine Oil Life (%)	Calculated Engine Oil Life (%)
100	100 to 91
90	90 to 81
80	80 to 71
70	70 to 61
60	60 to 51
50	50 to 41
40	40 to 31
30	30 to 21
20	20 to 16
15	15 to 11
10	10 to 6
5	5 to 1
0	0

There is a list of maintenance main and sub items you can view on the driver information interface.


► Maintenance Service Items P. 486

■ Maintenance Minder Messages on the Driver Information Interface

Maintenance Message	Oil Life Display	Explanation	Information
_	Oil Life 50%	When you select the Maintenance Minder screen, it displays codes for maintenance items due at the next engine oil change, along with the percentage of engine oil life remaining.	
SERVICE DUE SOON Maintenance Due Soon A 1 2 3 4 5	Oil Life 15%	The engine oil life indicator starts to appear along with other due-soon maintenance item codes when the remaining oil life drops to 15 percent.	The engine oil is approaching the end of its service life.
SERVICE DUE NOW Maintenance Due Now A 1 2 3 4 5	Oil Life 5%	The remaining engine oil life is 5 to 1 percent. Press the button to switch to another display.	The engine oil has almost reached the end of its service life, and the maintenance items should be inspected and serviced as soon as possible.
SERVICE PAST DUE Maintenance Past Due -10 miles A 1 2 3 4 5	Oil Life -10 miles	The engine oil has passed its service life, and a negative distance appears after driving over 10 miles (U.S. models) or 10 km (Canadian models). The negative distance on the display blinks.	The engine oil life has passed. The maintenance items must be inspected and serviced immediately.

The system message indicator (①) comes on along with the Maintenance Minder message.

■ Maintenance Service Items



Maintenance Service Items

- Inspect idle speed every 160,000 miles (256,000 km).
- Adjust the valves during services A, B, 1, 2, or 3 if they are noisy.

U.S. models

A • Replace engine oil*1 B • Replace engine oil*1 and oil filter • Inspect front and rear brakes • Inspect these items: • Tie rod ends, steering gearbox, and boots • Suspension components • Driveshaft boots • Brake hoses and lines (including ABS/VSA) • All fluid levels and condition of fluids • Exhaust system# • Fuel lines and connections#

*1: If a Maintenance Minder message does not appear more than 12 more	iths after the display is reset,
change the engine oil every year.	

^{#:} See information on maintenance and emissions warranty.

CODE	Maintenance Sub Items
1	Rotate tires
2	 Replace air cleaner element*² Replace dust and pollen filter*³ Inspect drive belt
3	Replace transmission fluid*4
4	Replace spark plugsInspect valve clearance
5	Replace engine coolant
7	Replace brake fluid*5

^{*3:} If you drive primarily in urban areas that have high concentrations of soot in the air from industry and from diesel-powered vehicles, replace the dust and pollen filter every 15,000 miles (24,000 km).

^{*2:} If you drive in dusty conditions, replace the air cleaner element every 15,000 miles (24,000 km).

^{*4:} Driving in mountainous areas at very low vehicle speeds results in higher transmission temperatures. This requires transmission fluid changes more frequently than recommended by the Maintenance Minder. If you regularly drive your vehicle under these conditions, have the transmission fluid changed every 25,000 miles (40,000 km).

^{*5:} If a Maintenance Minder Indicator does not appear more than 36 months after the display for item 7 is reset, change the brake fluid every 3 years.

Canadian models

CODE	Maintenance Main Items
A	• Replace engine oil*1
0	• Replace engine oil*1 and oil filter

- *1: If a Maintenance Minder message does not appear more than 12 months after the display is reset, change the engine oil every year.
- *2: If you drive in dusty conditions, replace the air cleaner element every 24,000 km (15,000 miles).
- *3: If you drive primarily in urban areas that have high concentrations of soot in the air from industry and from diesel-powered vehicles, replace the dust and pollen filter every 24,000 km (15,000 miles).
- *4: Driving in mountainous areas at very low vehicle speeds results in higher transmission temperatures. This requires transmission fluid changes more frequently than recommended by the Maintenance Minder. If you regularly drive your vehicle under these conditions, have the transmission fluid changed every 40,000 km (25,000 miles).
- *5: If a Maintenance Minder Indicator does not appear more than 36 months after the display for item 7 is reset, change the brake fluid every 3 years.
- #: See information on maintenance and emissions warranty.

Maintenance Service Items


- Inspect idle speed every 256,000 km (160,000 miles).
- Adjust the valves during services A, 0, 9, 1, 2, or 3 if they are noisy.

CODE	Maintenance Sub Items
1	Rotate tires
2	Replace air cleaner element*2
	• Replace dust and pollen filter*3
	Inspect drive belt
3	 Replace transmission fluid*4
4	Replace spark plugs
	Inspect valve clearance
5	Replace engine coolant
7	Replace brake fluid*5
9	Service front and rear brakes
	• Inspect these items:
	 Tie rod ends, steering gearbox, and boots
	 Suspension components
	 Driveshaft boots
	 Brake hoses and lines (including ABS/VSA)
	 All fluid levels and condition of fluids
	 Exhaust system#
	 Fuel lines and connections#

Continued 487

Resetting the Display

Reset the Maintenance Minder display if you have performed the maintenance service.



- **1.** Turn the ignition switch to ON II^{*1}.
- 2. Press the (display/information) button repeatedly until the page appears.
- 3. Press the ENTER button.
- **4.** Press and hold the **ENTER** button for about 10 seconds to enter the reset mode.
- **5.** Press ▲ / ▼ to select a maintenance item to reset, or to select **All Due Items** (You can also select **Cancel** to end the process).
- **6.** Press the **ENTER** button to reset the selected item.
- **7.** Repeat from step 4 for other items you wish to reset.

■ Resetting the Display

NOTICE

Failure to reset the relevant item(s) after a maintenance service results in the system showing incorrect maintenance intervals, which can lead to serious mechanical problems.

The dealer will reset the Maintenance Minder display after completing the required maintenance service. If someone other than a dealer performs maintenance service, reset the relevant maintenance item(s) yourself.

Models with color audio system

You can also reset the Maintenance MinderTM display using the customized features on the driver infromation interface.

Customized Features P. 111

Models with Display Audio


You can also reset the Maintenance Minder™ display using the audio/information touch screen.


■ Customized Features P. 302

Maintenance Under the Hood

Maintenance Items Under the Hood

1.5 ℓ engine models





Opening the Hood



- **1.** Park the vehicle on a level surface, and set the parking brake.
- **2.** Pull the hood release handle under the lower left corner of the dashboard.
 - ► The hood will pop up slightly.



Support Rod

3. Push the hood latch lever in the center to the right to release the lock mechanism, and open the hood.

4. Remove the support rod from the clamp using the grip. Mount the support rod in the hood.



When closing, remove the support rod, and stow it in the clamp, then gently lower the hood. Remove your hand at a height of approximately 12 inches (30 cm) and let the hood close.

■Opening the Hood

NOTICE

Do not open the hood when the wiper arms are raised.

The hood will strike the wipers, and may damage either the hood or the wipers.

When closing the hood, check that the hood is securely latched.

If the hood latch lever moves stiffly, or if you can open the hood without lifting the lever, the latch mechanism should be cleaned and lubricated.

Recommended Engine Oil

- Genuine Honda Motor Oil
- Premium-grade 0W-20 detergent oil with an API Certification Seal on the container.



Oil is a major contributor to your engine's performance and longevity. If you drive the vehicle with insufficient or deteriorated oil, the engine may fail or be damaged.


This seal indicates the oil is energy conserving and that it meets the American Petroleum Institute's latest requirements.

Use Genuine Honda Motor Oil or another commercial engine oil of suitable viscosity for the ambient temperature as shown here.

■ Recommended Engine Oil

Engine Oil Additives

Your vehicle does not require oil additives. In fact, they may adversely affect the engine performance and durability.




■ Synthetic oil

You may also use synthetic motor oil if it is labeled with the API Certification Seal and is the specified viscosity grade.

Oil Check

We recommend that you check the engine oil level every time you refuel. Park the vehicle on level ground.

Wait approximately three minutes after turning the engine off before you check the oil.




- **1.** Remove the dipstick (orange).
- **2.** Wipe the dipstick with a clean cloth or paper towel.
- **3.** Insert the dipstick back all the way into its hole.

≫Oil Check


If the oil level is near or below the lower mark, slowly add oil being careful not to overfill.


Continued 493



4. Remove the dipstick again, and check the level. It should be between the upper and lower marks. Add oil if necessary.

Adding Engine Oil





- **1.** Unscrew and remove the engine oil fill cap.
- 2. Add oil slowly.
- **3.** Reinstall the engine oil fill cap, and tighten it securely.
- **4.** Wait for three minutes and recheck the engine oil dipstick.

If any oil spills, wipe it away immediately. Spilled oil may damage the engine compartment components.


NOTICE

Do not fill the engine oil above the upper mark. Overfilling the engine oil can result in leaks and engine damage.

Changing the Engine Oil and Oil Filter

You must change the engine oil and oil filter regularly in order to maintain the engine's lubrication. The engine may be damaged if they are not changed regularly.

Change the oil and filter in accordance with the maintenance message on the information display*/driver information interface*.





- **1.** Run the engine until it reaches normal operating temperature, and then turn the engine off.
- **2.** Open the hood and remove the engine oil fill cap.
- **3.** Remove the phillips head screws and slotted head screws by turning 90° counterclockwise on the undercarriage and remove the under cover.

∑Changing the Engine Oil and Oil Filter

NOTICE


You may damage the environment if you do not dispose of the oil in a suitable way. If you are changing the oil by yourself, appropriately dispose of the used oil. Put the oil in a sealed container and take it to a recycling center. Do not throw the oil away into a garbage can or onto the ground.






4. Remove the drain bolt and washer from the bottom of the engine, and drain the oil into a suitable container.

Continued 497





- **5.** Remove the oil filter and dispose of the remaining oil.
- **6.** Check that the filter gasket is not stuck to the engine contact surface.
 - ▶ If it is stuck, you must detach it.
- Wipe away dirt and dust adhering to the contact surface of the engine block, and install a new oil filter.
 - ► Apply a light coat of new engine oil to the oil filter gasket.
- **8.** Put a new washer on the drain bolt, then reinstall the drain bolt.
 - ➤ Tightening torque: 30 lbf·ft (40 N·m, 4.0 kgf·m)
- **9.** Pour the recommended engine oil into the engine.
 - ► Engine oil change capacity (including filter):

1.5 ℓ engine models

3.7 US at (3.5 L)

2.0 ℓ engine models

4.4 US at (4.2 L)

- **10.** Reinstall the engine oil fill cap securely and start the engine.
- **11.** Run the engine for a few minutes, and then check that there is no leak from the drain bolt or oil filter.
- **12.** Stop the engine, wait for three minutes, and then check the oil level on the dipstick.
 - If necessary, add more engine oil.

∑Changing the Engine Oil and Oil Filter

You will need a special wrench to replace the oil filter. You can buy this wrench from a dealer.

When installing the new oil filter, follow the instructions supplied with the oil filter.

Reinstall the engine oil fill cap. Start the engine. The low oil pressure indicator should go off within five seconds. If it does not, turn off the engine, and check your work.

Engine Coolant

Specified coolant: Honda Long Life Antifreeze/Coolant Type 2

This coolant is premixed with 50% antifreeze and 50% water. Do not add any straight antifreeze or water.

We recommend you check the engine coolant level every time you refuel. Check the reserve tank. Add the engine coolant accordingly.

■ Checking the Coolant



- **1.** Check the amount of coolant in the reserve tank.
- **2.** If the coolant level is below the **MIN** mark, add the specified coolant until it reaches the **MAX** mark.
- **3.** Inspect the cooling system for leaks.

NOTICE


If temperatures consistently below –22°F (–30°C) are expected, the coolant mixture should be changed to a higher concentration. Consult a dealer for more information.


If Honda antifreeze/coolant is not available, you may use another major brand non-silicate coolant as a temporary replacement. Check that it is a high quality coolant recommended for aluminum engines. Continued use of any non-Honda coolant can result in corrosion, causing the cooling system to malfunction or fail. Have the cooling system flushed and refilled with Honda antifreeze/coolant as soon as possible.

Do not add rust inhibitors or other additives to your vehicle's cooling system. They may not be compatible with the coolant or with the engine components.

Continued 499

Adding the Coolant





- Make sure the engine and radiator are cool.
- **2.** Turn the reserve tank cap 1/8 of a turn counterclockwise and relieve any pressure in the cooling system. Do not push the cap down when turning.
- **3.** Push down and turn the reserve tank cap counterclockwise to remove it.
- **4.** Pour coolant into the reserve tank until it reaches the **MAX** mark.
- **5.** Put the reserve tank cap back on, and tighten it fully.

■ Adding the Coolant

AWARNING

Removing the reserve tank cap while the engine is hot can cause the coolant to spray out, seriously scalding you.

Always let the engine and radiator cool down before removing the reserve tank cap.

NOTICE

Pour the fluid slowly and carefully so you do not spill any. Clean up any spills immediately; they can damage components in the engine compartment.

Transmission Fluid

Models with continuously variable transmission

Continuously Variable Transmission Fluid

Specified fluid: Honda HCF-2 Transmission Fluid

Have a dealer check the fluid level and replace if necessary.

Models with manual transmission

Manual Transmission Fluid

Specified fluid: Honda Manual Transmission Fluid (MTF)

Have a dealer check the fluid level and replace if necessary.

○ Continuously Variable Transmission Fluid

NOTICE

Do not mix HCF-2 with other transmission fluids.

Using a transmission fluid other than HCF-2 may adversely affect the operation and durability of your vehicle's transmission, and damage the transmission. Any damage caused by using a transmission fluid that is not equivalent to HCF-2 is not covered by Honda's new vehicle warranty.

Manual Transmission Fluid

If Honda MTF is not available, you may use the API certificated SAE 0 W-20 or 5 W-20 viscosity motor oil as a temporary measure.


Replace with MTF as soon as possible. Motor oil does not contain the proper additives for the transmission and continued use can cause decreased shifting performance and lead to transmission damage.

Brake/Clutch* Fluid

Specified fluid: Honda Heavy Duty Brake Fluid DOT 3

Use the same fluid for both the brakes and clutch.

■ Checking the Brake/Clutch* Fluid



The fluid level should be between the **MIN** and **MAX** marks on the side of the reservoir.

Manual transmission models

The brake fluid reservoir is also used for your vehicle's clutch fluid. As long as you keep the brake fluid level as instructed above, there is no need for checking the clutch fluid level.

NOTICE

Brake fluid marked DOT 5 is not compatible with your vehicle's braking system and can cause extensive damage.

If the specified brake fluid is not available, you should use only DOT 3 or DOT 4 fluid from a sealed container as a temporary replacement.

Using any non-Honda brake fluid can cause corrosion and decrease the longevity of the system. Have the brake system flushed and refilled with Honda Heavy Duty Brake Fluid DOT 3 as soon as possible.

If the brake fluid level is at or below the **MIN** mark, have a dealer inspect the vehicle for leaks or worn brake pads as soon as possible.

Refilling Window Washer Fluid

Check the amount of window washer fluid by looking at the reservoir.

Except Canadian 1.5 ℓ engine models

Canadian 1.5 ℓ engine models

If the level is low, fill the washer reservoir.

Canadian models with information display

If the washer fluid is low, the washer level indicator comes on.

Canadian models with driver information interface

If the washer fluid is low, a message appears on the driver information interface.

Pour the washer fluid carefully. Do not overflow the reservoir.

Refilling Window Washer Fluid

NOTICE

Do not use engine antifreeze or a vinegar/water solution in the windshield washer reservoir. Antifreeze can damage your vehicle's paint. A vinegar/water solution can damage the windshield washer pump.

Replacing Light Bulbs

Headlight Bulbs

When replacing, use the following bulbs.

High beam headlight: 60 W (HB3 for halogen bulb type)*


High beam headlight: LED type*

Low beam headlight: 55 W (H11 for halogen bulb type)*

Low beam headlight: LED type*

■ High Beam Headlight

Models with halogen headlights



- **1.** Push the tab to remove the coupler.
- **2.** Rotate the old bulb counter-clockwise to remove.
- **3.** Insert a new bulb into the headlight assembly and turn it clockwise.
- **4.** Insert the coupler into the connector of the bulb.

Models with halogen headlights

NOTICE

Halogen bulbs get very hot when lit.

Oil, perspiration, or a scratch on the glass can cause the bulb to overheat and shatter.

The headlight aim is set by the factory, and does not need to be adjusted. However, if you regularly carry heavy items in the trunk, have the aiming readjusted at a dealer or by a qualified technician.


When replacing a halogen bulb, handle it by its base, and protect the glass from contact with your skin or hard objects. If you touch the glass, clean it with denatured alcohol and a clean cloth.

Models with LED headlights

Headlights are LED type. Have an authorized Honda dealer inspect and replace the light assembly.

■ Low Beam Headlights

Models with halogen headlights



- **1.** Push the tab to remove the coupler.
- **2.** Rotate the old bulb counter-clockwise to remove.
- **3.** Insert a new bulb into the headlight assembly and turn it clockwise.
- **4.** Insert the coupler into the connector of the bulb.

Fog Light Bulbs*

When replacing, use the following bulbs.


Fog Light: 35 W (H8 for halogen bulb type)




1. Remove the clips using a flat-tip screwdriver, remove the bolt, and push up the under cover.


Fog Light Bulbs *

Insert a flat-tip screwdriver, lift and remove the center pin to remove the clip.



Insert the clip with the center pin raised, and push until it is flat.





- 2. Push the tab to remove the coupler.
- **3.** Rotate the old bulb counter-clockwise to remove.
- **4.** Insert a new bulb into the fog light assembly and turn it clockwise.
- **5.** Insert the coupler into the connector of the bulb.

∑Fog Light Bulbs*

NOTICE

Halogen bulbs get very hot when lit. Oil, perspiration, or a scratch on the glass can cause the bulb to overheat and shatter.


When replacing a halogen bulb, handle it by its plastic case, and protect the glass from contact with your skin or hard objects. If you touch the glass, clean it with denatured alcohol and a clean cloth.

Models with halogen headlights

Front Turn Signal Light Bulbs

When replacing, use the following bulbs.

Front Turn Signal Light: 21 W (Amber)



- **1.** Turn the socket counter-clockwise and remove it.
- 2. Remove the old bulb and insert a new bulb.

Models with LED headlights


Front Turn Signal Lights

Front turn signal lights are LED type. Have an authorized Honda dealer inspect and replace the light assembly.


Front Side Marker Light Bulbs

When replacing, use the following bulbs.

Front Side Marker Light: 3 W




- **1.** Push the tab to remove the light assembly.
- 2. Push the tab to remove the coupler.



Driver side

- **3.** Turn the socket counter-clockwise to remove it, then remove the old bulb.
- **4.** Insert a new bulb.

Continued 509



Passenger side

- **4.** Turn the socket clockwise to remove it, then remove the old bulb.
- 5. Insert a new bulb.

Parking/Daytime Running Lights

Parking/daytime running lights are LED type. Have an authorized Honda dealer inspect and replace the light assembly.


Side Turn Signal/Emergency Indicator Lights*

Side turn lights are LED type. Have an authorized Honda dealer inspect and replace the light assembly.


Brake Light, Tail/Rear Side Marker Light, Rear Turn Signal Light and Back-Up Light Bulbs

When replacing, use the following bulbs.

Brake Light: 21 W
Tail/Rear Side Marker Light: LED
Rear Turn Signal Light: 21 W (Amber)
Back-Up Light: 16 W



- **1.** Use a Phillip-head screwdriver or socket to remove the bolts.
- **2.** Pull the light assembly out of the rear pillar.



- **3.** Turn the socket counter-clockwise and remove it.
- **4.** Remove the old bulb and insert a new bulb.
- **5.** Slide the light assembly onto the guide on the body.
- **6.** Align the pins with the body grommets, then push in until they fully seat.

▶ Brake Light, Tail/Rear Side Marker Light, Rear Turn Signal Light and Back-Up Light Bulbs

Tail/rear side marker lights are LED type. Have an authorized Honda dealer inspect and replace the light assembly.

Taillights

Taillights are LED type. Have an authorized Honda dealer inspect and replace the light assembly.


Rear License Plate Light

Rear license plate light is LED type. Have an authorized Honda dealer inspect and replace the light assembly.

High-Mount Brake Light Bulb

When replacing, use the following bulb.

High-Mount Brake Light: 21 W



- 1. Open the trunk.
- **2.** Turn the socket counter-clockwise and remove it.
- **3.** Remove the old bulb and insert a new bulb.

Checking and Maintaining Wiper Blades

Checking Wiper Blades

If the wiper blade rubber has deteriorated, it will leave streaks and the hard surfaces of the blade may scratch the window glass.

Changing the Wiper Blade Rubber






- **1.** Turn the ignition switch to LOCK $[0]^{*1}$.
- 2. While holding the wiper switch in the MIST position, turn the ignition switch to ON III^{*1} , then to LOCK III^{*1} .
 - ▶ Both wiper arms are set to the maintenance position as shown in the image.
- 3. Lift both wiper arms.


○ Changing the Wiper Blade Rubber

NOTICE


Avoid dropping the wiper arm; it may damage the windscreen.




Continued 513




4. Press and hold the tab, then slide the blade out from the wiper arm.



5. Pull the end of the wiper blade to the direction of the arrow in the image until it unfastens from the holder's end cap.



6. Pull the wiper blade to the opposite direction to slide it out from its holder.



- **7.** Insert the flat side of the new wiper blade onto the bottom part of the holder. Insert the blade all the way.
- **8.** Install the end of the wiper blade into the cap.
- **9.** Slide the wiper blade onto the wiper arm until it locks.
- **10.** Lower both wiper arms.
- **11.** Turn the ignition switch to ON II and hold the wiper switch in the **MIST** position until both wiper arms return to the standard position.

^{*1:} Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

Checking and Maintaining Tires

Checking Tires

To safely operate your vehicle, your tires must be of the proper type and size, in good condition with adequate tread, and properly inflated.

■ Inflation guidelines

Properly inflated tires provide the best combination of handling, tread life, and comfort. Refer to the driver's doorjamb label or specification's page for the specified pressure.

Underinflated tires wear unevenly, adversely affect handling and fuel economy, and are more likely to fail from overheating.

Overinflated tires make your vehicle ride harshly, are more prone to road hazards, and wear unevenly.

Every day before you drive, look at each of the tires. If one looks lower than the others, check the pressure with a tire gauge.

At least once a month or before long trips, use a gauge to measure the pressure in all tires, including the spare*. Even tires in good condition can lose 1 to 2 psi (10 to 20 kPa, 0.1 to 0.2 kgf/cm²) per month.

■ Inspection guidelines

Every time you check inflation, also examine the tires and valve stems. Look for:

- Bumps or bulges on the side or in the tread. Replace the tire if you find any cuts, splits, or cracks in the side of the tire. Replace it if you see fabric or cord.
- Remove any foreign objects and inspect for air leaks.
- Uneven tread wear. Have a dealer check the wheel alignment.
- Excessive tread wear.

Wear Indicators P. 521

- Cracks or other damage around valve stem.
- * Not available on all models

○ Checking Tires

AWARNING

Using tires that are excessively worn or improperly inflated can cause a crash in which you can be seriously hurt or killed.

Follow all instructions in this owner's manual regarding tire inflation and maintenance.

Measure the air pressure when tires are cold. This means the vehicle has been parked for at least three hours, or driven less than 1 mile (1.6 km). If necessary, add or release air until the specified pressure is reached.

If checked when hot, tire pressure can be as much as 4–6 psi (30–40 kPa, 0.3–0.4 kgf/cm²) higher than if checked when cold

U.S. models

Whenever tire pressure is adjusted, you must calibrate the TPMS


₹ TPMS Calibration P. 446

Have a dealer check the tires if you feel a consistent vibration while driving. New tires and any that have been removed and reinstalled should be properly balanced.


Measure the spare tire pressure once a month or before long trips.

Tire and Loading Information Label

The label attached to the driver's doorjamb provides necessary tire and loading information



Tire Labeling



The tires that came on your vehicle have a number of markings. Those you should be aware of are described below.

■ Tire Sizes

Whenever tires are replaced, they should be replaced with tires of the same size.

∑Tire and Loading Information Label

The tire and loading information label attached to the driver's doorjamb contains:

- 1 The number of people your vehicle can carry.
- 2 The total weight your vehicle can carry. Do not exceed this weight.
- 3 The original tire sizes for front, rear, and spare, if equipped.
- The proper cold tire pressure for front, rear, and spare.

∑Tire Sizes

Following is an example of tire size with an explanation of what each component means.

P205/55 R16 89H

P: Vehicle type (P indicates passenger vehicle).

205: Tire width in millimeters.

55: Aspect ratio (the tire's section height as a percentage of its width).

R: Tire construction code (R indicates radial).

16: Rim diameter in inches.

89: Load index (a numerical code associated with the maximum load the tire can carry).

H: Speed symbol (an alphabetical code indicating the maximum speed rating).

Continued 517

■ Tire Identification Number (TIN)

The tire identification number (TIN) is a group of numbers and letters that look like the example in the side column. TIN is located on the sidewall of the tire.

Glossary of Tire Terminology

Cold Tire Pressure – The tire air pressure when the vehicle has been parked for at least three hours or driven less than 1 mile (1.6 km).

Load Rating – Means the maximum load that a tire is rated to carry for a given inflation pressure.

Maximum Inflation Pressure – The maximum tire air pressure that the tire can hold

Maximum Load Rating – Means the load rating for a tire at the maximum permissible inflation pressure for that tire.

Recommended Inflation Pressure – The cold tire inflation pressure recommended by the manufacturer.

Treadwear Indicators (TWI) – Means the projections within the principal grooves designed to give a visual indication of the degrees of wear of the tread.

∑Tire Identification Number (TIN)

DOT B97R FW6X 2209

DOT: This indicates that the tire meets all requirements of the U.S. Department of Transportation.

B97R: Manufacturer's identification mark. FW6X: Tire type code.

22 09: Date of manufacture.

Year
Week

DOT Tire Quality Grading (U.S. Vehicles)

The tires on your vehicle meet all U.S. Federal Safety Requirements. All tires are also graded for treadwear, traction, and temperature performance according to Department of Transportation (DOT) standards. The following explains these gradings.

Uniform Tire Quality Grading

Quality grades can be found where applicable on the tire sidewall between tread shoulder and maximum section width.

■ Treadwear

The treadwear grade is a comparative rating based on the wear rate of the tire when tested under controlled conditions on a specified government test course. For example, a tire graded 150 would wear one and one-half (1 1/2) times as well on the government course as a tire graded 100. The relative performance of tires depends upon the actual conditions of their use, however, and may depart significantly from the norm due to variations in driving habits, service practices and differences in road characteristics and climate.

■Uniform Tire Quality Grading

For example:

Treadwear 200 Traction AA Temperature A

All passenger car tires must conform to Federal Safety Requirements in addition to these grades.

Continued 519

■ Traction

The traction grades, from highest to lowest, are AA, A, B, and C. Those grades represent the tire's ability to stop on wet pavement as measured under controlled conditions on specified government test surfaces of asphalt and concrete. A tire marked C may have poor traction performance.

Temperature


The temperature grades are A (the highest), B, and C, representing the tire's resistance to the generation of heat and its ability to dissipate heat when tested under controlled conditions on a specified indoor laboratory test wheel. Sustained high temperature can cause the material of the tire to degenerate and reduce tire life, and excessive temperature can lead to sudden tire failure. The grade C corresponds to a level of performance which all passenger car tires must meet under the Federal Motor Vehicle Safety Standard No. 109. Grades B and A represent higher levels of performance on the laboratory test wheel than the minimum required by law.

Warning: The traction grade assigned to this tire is based on straight-ahead braking traction tests, and does not include acceleration, cornering, hydroplaning, or peak traction characteristics.

∑Temperature

Warning: The temperature grade for this tire is established for a tire that is properly inflated and not overloaded. Excessive speed, underinflation, or excessive loading, either separately or in combination, can cause heat buildup and possible tire failure.

Wear Indicators



The groove where the wear indicator is located is 1/16 inch (1.6 mm) shallower than elsewhere on the tire. If the tread has worn so that the indicator is exposed, replace the tire. Worn out tires have poor traction on wet roads.

Tire Service Life

The life of your tires is dependent on many factors, including driving habits, road conditions, vehicle loading, inflation pressure, maintenance history, speed, and environmental conditions (even when the tires are not in use).

In addition to regular inspections and inflation pressure maintenance, it is recommended that you have annual inspections performed once the tires reach five years old. All tires, including the spare, should be removed from service after 10 years from the date of manufacture, regardless of their condition or state of wear.

Tire and Wheel Replacement

Replace your tires with radials of the same size, load range, speed rating, and maximum cold tire pressure rating (as shown on the tire's sidewall). Using tires of a different size or construction can cause the ABS and VSA® (vehicle stability assist) system to work incorrectly.

It is best to replace all four tires at the same time. If that isn't possible, replace the front or rear tires in pairs.

Make sure that the wheel's specifications match those of the original wheels.

∑Tire and Wheel Replacement

AWARNING


Installing improper tires on your vehicle can affect handling and stability. This can cause a crash in which you can be seriously hurt or killed.

Always use the size and type of tires recommended in this owner's manual.

Tire Rotation


Rotating tires according to the maintenance messages on the information display*/ driver information interface* helps to distribute wear more evenly and increase tire life.

■ Tires without rotation marks



Rotate the tires as shown here.


■ Tires with rotation marks



Rotate the tires as shown here.

∑Tire Rotation

Tires with directional tread patterns should only be rotated front to back (not from one side to the other). Directional tires should be mounted with the rotation indication mark facing forward, as shown below.



U.S. models

Whenever tires are rotated, you must calibrate the TPMS.

TPMS Calibration P. 446

Winter Tires

If driving on snowy or frozen roads, mount all season marked **M+S** tires, snow tires, or tire chains; reduce speed; and maintain sufficient distance between vehicles when driving.

Be particularly careful when operating the steering wheel or brakes to prevent skidding.

Use tire chains, snow tires, or all season tires when necessary or according to the law.

When mounting, refer to the following points.

For winter tires:

- Select the size and load ranges that are the same as the original tires.
- Mount the tires to all four wheels.

For tire chains:

- Install them on the front tires only.
- Because your vehicle has limited tire clearance, we strongly recommend using the chains listed below:

Models with 215/55R16 tires

Cable-type: Autotrac 0154505

Models with 215/50R17 tires

Cable-type: Autotrac 0154005

- Follow the chain manufacturer's instruction when installing. Mount them as tightly as you can.
- Check that the chains do not touch the brake lines or suspension.
- Drive slowly.

≫Winter Tires

AWARNING

Using the wrong chains, or not properly installing chains, can damage the brake lines and cause a crash in which you can be seriously injured or killed.

Follow all instructions in this owner's manual regarding the selection and use of tire chains.

NOTICE


Traction devices that are the wrong size or improperly installed can damage your vehicle's brake lines, suspension, body, and wheels. Stop driving if they are hitting any part of the vehicle.

When tire chains are mounted, follow the chain manufacturer's instructions regarding vehicle operational limits.

If your vehicle is equipped with summer tires, be aware that these tires are not designed for winter driving conditions. For more information, contact a dealer.

Battery

Checking the Battery



Check the battery terminals for corrosion monthly.

If your vehicle's battery is disconnected or goes dead:

- The audio system is disabled.
 - Reactivating the audio system P. 200
- The clock* resets.
 - Adjusting the Clock P. 122
- The navigation system* is disabled.
 - **≥** Refer to the Navigation System Manual
- Canadian models only

The immobilizer system needs to be reset.

▶ Immobilizer System Indicator P. 83

Battery

AWARNING

The battery gives off explosive hydrogen gas during normal operation.

A spark or flame can cause the battery to explode with enough force to kill or seriously hurt you.

When conducting any battery maintenance, wear protective clothing and a face shield, or have a skilled technician do it.

WARNING: Battery post, terminals, and related accessories contain lead and lead compounds.

Wash your hands after handling.

* Not available on all models

Charging the Battery

Disconnect both battery cables to prevent damaging your vehicle's electrical system. Always disconnect the negative (–) cable first, and reconnect it last.

≫ Battery

When you find corrosion, clean the battery terminals by applying a baking powder and water solution. Clean the terminal with a damp towel. Cloth/towel dry the battery. Coat the terminals with grease to help prevent future corrosion.

When replacing the battery, the replacement must be of the same specifications.

Please consult a dealer for more information.

The VSA® and CMBS^{TM*} indicators may come on when your turn the ignition switch to ON \boxed{II}^{*1} after re-connecting a battery.

Drive a short distance at 12 mph (20 km/h). Each indicator should go off. If either or both do not, have your vehicle checked by a dealer.


^{*1:} Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.


Remote Transmitter Care

Replacing the Button Battery

If the indicator does not come on when the button is pressed, replace the battery.

Keys with Remote Transmitter*





Battery type: CR1620

- **1.** Unscrew the cover with a small Phillipshead screwdriver.
- 2. Open the remote transmitter.
 - ➤ Wrap the small flat-tip screwdriver with a cloth to prevent scratching the transmitter.
- **3.** Remove the button battery with the small flat-tip screwdriver.
- **4.** Make sure to replace the battery with the correct polarity.

■ Replacing the Button Battery

NOTICE

An improperly disposed of battery can damage the environment. Always confirm local regulations for battery disposal.


Replacement batteries are commercially available or at a dealer.

■ Smart Entry Remote*



Battery type: CR2032

1. Remove the built-in key.



- **2.** Remove the upper half of the cover by carefully prying on the edge with a coin.
 - ► Remove carefully to avoid losing the buttons.
 - ► Wrap a coin with a cloth to prevent scratching the smart entry remote.
- **3.** Make sure to replace the battery with the correct polarity.

Heating System*/Climate Control System* Maintenance

Air Conditioning

To ensure proper and safe operation, the Society of Automotive Engineers (SAE J2845) recommends that the refrigerant system only be serviced by trained and certified technicians.

Never repair or replace the air conditioning evaporator (cooling coil) with one removed from a used or salvaged vehicle.

New replacement mobile air conditioning evaporators must be certified (and labeled) as meeting SAE Standard J2842.

Dust and Pollen Filter

The heating system*/climate control system* is equipped with a dust and pollen filter that collects pollen, dust, and other debris in the air. The Maintenance Minder™ messages will let you know when to replace the filter.

We recommend that you replace the dust and pollen filter sooner when using your vehicle in areas with high concentrations of dust.

* Not available on all models

NOTICE

Vented refrigerant is harmful to the environment. To avoid refrigerant from venting, never replace the evaporator with one removed from a used or salvaged vehicle.

Refrigerant in your vehicle's air conditioning system is flammable and can be ignited during servicing if proper procedures are not followed.

The air conditioner label is found under the hood:

Safety Labels P. 71

≥ Specifications P. 568, 570

Canadian models



↑: Caution

: Flammable Refrigerant

: Requires Registered Technician to Service

: Air Conditioning System

Dust and Pollen Filter

If the airflow from the heating system*/climate control system* deteriorates noticeably, and the windows fog up easily, the filter may need to be replaced. Please contact a dealer for replacement.

529


Cleaning

Interior Care

Use a damp cloth with a mixture of mild detergent and warm water to remove dirt. Use a clean cloth to remove detergent residue.

Cleaning Seat Belts

Use a soft brush with a mixture of mild soap and warm water to clean the seat belts. Let the belts air dry. Wipe the loops of the seat belt anchors using a clean cloth.



Cleaning the Window

Wipe using a glass cleaner.

Do not spill liquids inside the vehicle.

Electrical devices and systems may malfunction if liquids are splashed on them.

Do not use silicone based sprays on electrical devices such as audio devices and switches.

Doing so may cause the items to malfunction or a fire inside the vehicle.

If a silicone based spray is inadvertently used on electrical devices, consult a dealer.

Depending on their composition, chemicals and liquid aromatics may cause discoloration, wrinkles, and cracking to resin-based parts and textiles. Do not use alkali solvents or organic solvents such as benzene or gasoline.


After using chemicals, make sure to gently wipe them away using a dry cloth.

Do not place used cloths on top of resin based parts or textiles for long periods of time without washing.

○ Cleaning the Window

Wires are mounted to the inside of the rear window. Wipe along the same direction as the wires with a soft cloth so as not to damage them.

■ Floor Mats*



The driver's floor mat hooks over the floor anchors, which keep the mat from sliding forward. To remove a mat for cleaning, turn the anchor knobs to the unlock position. When reinstalling the mat after cleaning, turn the knobs to the lock position.

Do not put additional floor mats on top of the anchored mat.

Maintaining Genuine Leather*

Vacuum dirt and dust from the leather frequently. Pay close attention to the pleats and seams. Clean the leather with a soft cloth dampened with a 90% water and 10% neutral soap solution. Then buff it with a clean, dry cloth. Remove any dust or dirt on leather surfaces immediately.

If you use any floor mats that were not originally provided with your vehicle, make sure they are designed for your specific vehicle, fit correctly, and are securely anchored by the floor anchors. Position the rear-seat floor mats properly. If they are not properly positioned, the floor mats can interfere with the front seat functions.

* Not available on all models

Exterior Care

Dust off the vehicle body after you drive.

Regularly inspect your vehicle for scratches on painted surfaces. A scratch on a painted surface can result in body rust. If you find a scratch, promptly repair it.

■ Washing the Vehicle

Wash the vehicle regularly. Wash more frequently when driving in the following conditions:

- If driving on roads with road salt.
- If driving in coastal areas.
- If tar, soot, bird droppings, insects, or tree sap are stuck to painted surfaces.

Using an Automated Car Wash

- Make sure to follow the instructions indicated on the automated car wash.
- Fold in the door mirrors.
- Turn off the automatic intermittent wipers*.

Using High Pressure Cleaners

- Keep sufficient distance between the cleaning nozzle and the vehicle body.
- Take particular care around the windows. Standing too close may cause water to enter the vehicle interior.
- Do not spray high pressure water directly into the engine compartment. Instead, use low pressure water and a mild detergent.

≥ Washing the Vehicle

Do not spray water into the air intake vents. It can cause a malfunction.



Applying Wax

A good coat of automotive body wax helps protect your vehicle's paint from the elements. Wax will wear off over time and expose your vehicle's paint to the elements, so reapply as necessary.

■ Maintaining the Bumpers and Other Resin Coated Parts

If you get gasoline, oil, engine coolant, or battery fluid on resin coated parts, they may be stained or the coating may peel. Promptly wipe it away using a soft cloth and clean water.

Cleaning the Window

Wipe using a glass cleaner.

Maintaining Aluminum Wheels*

Aluminum is susceptible to deterioration caused by salt and other road contaminants. Use a sponge and mild detergent to wipe away promptly. Be careful not to use harsh chemicals (including some commercial wheel cleaners) or a stiff brush. They can damage the clear coat of the aluminum alloy wheels that helps keep the aluminum from corroding and tarnishing.

■ Applying Wax

NOTICE

Chemical solvents and strong cleaners can damage the paint, metal, and plastic on your vehicle. Wipe away spills immediately.

Maintaining the Bumpers and Other Resin Coated Parts

Ask a dealer about the correct coating material when you want to repair the painted surface of the parts made of resin.

■ Fogged Exterior Light Lenses

The inside lenses of exterior lights (headlights, brake lights, etc.) may fog temporarily if you have driven in the rain, or after the vehicle has been run through a car wash. Dew condensation also may build up inside the lenses when there is a significant enough difference between the ambient and inside-lens temperatures (similar to vehicle windows fogging up in rainy conditions). These conditions are natural processes, not structural design problems in the exterior lights.

Lens design characteristics may result in moisture developing on the lens frame surfaces. This also is not a malfunction. However, if you see large amounts of water accumulation, or large water drops building up inside the lenses, have your vehicle inspected by a dealer.

Handling the Unexpected

This chapter explains how to handle unexpected troubles.

536
537
543
5
544
545
546
549
550

Indicator, Coming On/Blinking

the Low Oil Pressure Indicator Comes
On 552
the Charging System Indicator Comes
On 552
the Malfunction Indicator Lamp Comes
On or Blinks 553
the Brake System Indicator (Red) Comes
On or Blinks 554
the Brake System Indicator (Red) Comes
On or Blinks at the Same Time When the
Brake System Indicator (Amber) Comes
On 555

If the Electric Power Steering (EPS) S Indicator Comes On If the Low Tire Pressure/TPMS Indica Comes On or Blinks	. 556 ator
uses	
Fuse Locations	558
Inspecting and Changing Fuses	561
mergency Towing	. 562
Vhen You Cannot Unlock the Fuel	Fill
Door	. 563
When You Cannot Open the Trunk	564
efueling .	565

Types of Tools



∑Types of Tools

The tools are stored in the trunk.

If a Tire Goes Flat

Changing a Flat Tire

If a tire goes flat while driving, grasp the steering wheel firmly, and brake gradually to reduce speed. Then, stop in a safe place. Replace the flat tire with a compact spare tire. Go to a dealer as soon as possible to have the full-size tire repaired or replaced.

1. Park the vehicle on firm, level, and non-slippery surface, and apply the parking brake.

Continuously variable transmission models

2. Move the shift lever to **P**.

Manual transmission models

2. Move the shift lever to $\boxed{\mathbf{R}}$.

All models

3. Turn on the hazard warning lights and turn the ignition switch to LOCK $\boxed{0}^{*1}$.

○ Changing a Flat Tire

Follow compact spare precautions: Periodically check the tire pressure of the compact spare. It should be set to the specified pressure. Specified Pressure: 60 psi (420 kPa, 4.2 kgf/cm²)

When driving with the compact spare tire, keep the vehicle speed under 50 mph (80 km/h). Replace with a full-size tire as soon as possible.

The compact spare tire and wheel in your vehicle are specifically for this model. Do not use them with another vehicle. Do not use another type of compact spare tire or wheel with your vehicle.

Do not mount tire chains on a compact spare tire. If a chain-mounted front tire goes flat, remove one of the full-size rear tires and replace it with the compact spare tire. Remove the flat front tire and replace it with the full-size tire that was removed from the rear. Mount the tire chains on the front tire.

NOTICE

Do not use the jack if it doesn't work properly. Call your dealer or a professional towing service.


Continued 537

^{*1:} Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.


■ Getting Ready to Replace the Flat Tire



1. Open the trunk floor lid.



- **2.** Take the tool case out of the trunk. Take the jack and wheel nut wrench out of the tool case.
- **3.** Unscrew the wing bolt, and remove the spacer cone. Then, remove the spare tire.




4. Place a wheel block or rock in front and rear of the wheel diagonal to the flat tire.

■ Getting Ready to Replace the Flat Tire

The wheel nut wrench supplied with your vehicle is specially adapted to fit the holder shaft. Do not use any other tool.



5. Place the compact spare tire (wheel side up) under the vehicle body, near the tire that needs to be replaced.





Models with wheel cover


- **6.** Put the flat tip of the jack handle bar into the edge of the wheel cover. Carefully pry the edge and remove the cover.
 - Wrap a cloth around the flat tip of the jack handle bar to prevent scratches on the cover.

All models


7. Loosen each wheel nut about one turn using the wheel nut wrench.

Continued 539


■ How to Set Up the Jack



1. Place the jack under the jacking point closest to the tire to be changed.



- **2.** Turn the end bracket clockwise as shown in the image until the top of the jack contacts the jacking point.
 - ► Make sure that the jacking point tab is resting in the jack notch.



Raise the vehicle, using the jack handle bar and the jack handle, until the tire is off the ground.

AWARNING

The vehicle can easily roll off the jack, seriously injuring anyone underneath.

Follow the directions for changing a tire exactly, and never get under the vehicle when it is supported only by the jack.

Do not use the jack with people or luggage in the vehicle.

Use the jack provided in your vehicle. Other jacks may not support the weight ("load") or may not fit the jacking point.


The following instructions must be followed to use the jack safely:

- Do not use while the engine is running.
- Use only where the ground is firm and level.
- Use only at the jacking points.
- Do not get in the vehicle while using the jack.
- Do not put anything on top of or underneath the jack.


■ Replacing the Flat Tire



1. Remove the wheel nuts and flat tire.



- **2.** Wipe the mounting surfaces of the wheel with a clean cloth.
- 3. Mount the compact spare tire.
- **4.** Screw the wheel nuts until they touch the lips around the mounting holes, and stop rotating.



5. Lower the vehicle and remove the jack. Tighten the wheel nuts in the order indicated in the image. Go around, tightening the nuts, two to three times in this order.

Wheel nut torque:


80 lbf·ft (108 N·m, 11 kgf·m)

■ Replacing the Flat Tire


Do not over tighten the wheel nuts by applying extra torque using your foot or a pipe.

Models with wheel cover


Make sure the wire support ring is hooked into the clips around the edge of the wheel cover.



Align the valve mark on the wheel cover to the tire valve on the wheel, then install the wheel cover.



Storing the Flat Tire



Models with aluminum wheels

1. Remove the center cap.

All models

- **2.** Place the flat tire face down in the spare tire well.
- **3.** Remove the spacer cone from the wing bolt, flip it over, and insert it back on the bolt. Secure the flat tire with the wing bolt.
- **4.** Securely put the jack and wheel nut wrench back in the tool case. Store the case in the trunk.

U.S. models

TPMS and the Spare Tire

If you replace a flat tire with the spare tire, the low tire pressure/TPMS indicator comes on while you are driving. After driving for a few miles (kilometers), the indicator will start blinking for a short time and then stay on. **Tire Pressures Low** appears on the driver information interface*, but this is normal.

Calibrate the TPMS when you replace the tire with a specified regular tire.

▶ TPMS Calibration P. 446

Storing the Flat Tire


AWARNING

Loose items can fly around the interior in a crash and can seriously injure the occupants.

Store the wheel, jack, and tools securely before driving.

Models with wheel cover

Make sure the wire support ring is on the outer side of the tire valve as shown.



Engine Does Not Start

Checking the Engine

If the engine does not start, check the starter.

○ Checking the Engine

If you must start the vehicle immediately, use an assisting vehicle to jump start it.

▶ Jump Starting P. 546

Starter condition	Checklist
Starter doesn't turn or turns over slowly. The battery may be dead. Check each of the items on the right and respond accordingly.	Models with smart entry system Check for a message on the driver information interface. If the To Start, Hold Remote Near Start Button message appears If the Smart Entry Remote Battery is Weak P. 544 Make sure the smart entry remote is in its operating range. ENGINE START/STOP Button Operating Range P. 152
	Check the brightness of the interior lights. Turn on the interior lights and check the brightness. If the interior lights are dim or do not come on at all Battery P. 525 If the interior lights come on normally Fuses P. 558
The starter turns over normally but the engine doesn't start. There may be a problem with the	Review the engine start procedure. Follow its instructions, and try to start the engine again. Starting the Engine P. 396
fuse. Check each of the items on the right and respond accordingly.	Check the immobilizer system indicator. When the immobilizer system indicator is blinking, the engine cannot be started. ▶ Immobilizer System P. 144
	Check the fuel level. There should be enough fuel in the tank. ▶ Fuel Gauge P. 103
	Check the fuse. Check all fuses, or have the vehicle checked by a dealer. Inspecting and Changing Fuses P. 561
	If the problem continues: Emergency Towing P. 562

Models with smart entry system

If the Smart Entry Remote Battery is Weak

If the beeper sounds, the **To Start, Hold Remote Near Start Button** message appears on the driver information interface, the indicator on the **ENGINE START/STOP** button flashes, and the engine won't start, start the engine as follows.



- Touch the center of the ENGINE START/ STOP button with the H logo on the smart entry remote while the indicator on the ENGINE START/STOP button is flashing. The buttons on the smart entry remote should be facing you.
 - ➤ The indicator flashes for about 30 seconds.



- 2. Depress the brake pedal (continuously variable transmission) or clutch pedal (manual transmission) and press the ENGINE START/STOP button within 10 seconds after the beeper sounds and the indicator stays on.
 - ► If you don't depress the pedal, the mode will change to ACCESSORY.

Models with smart entry system

Emergency Engine Stop

The **ENGINE START/STOP** button may be used to stop the engine due to an emergency situation even while driving. If you must stop the engine, do either of the following operations:

- Press and hold the **ENGINE START/STOP** button for about two seconds.
- Firmly press the **ENGINE START/STOP** button twice.

The steering wheel will not lock. However, because turning off the engine disables the power assist the engine provides to the steering and braking systems, it will require significantly more physical effort and time to steer and slow the vehicle. Use both feet on the brake pedal to slow down the vehicle and stop immediately in a safe place. With manual transmission models you can also downshift the transmission to utilize engine braking.

Continuously variable transmission models

The power mode is in ACCESSORY when the engine is stopped.

To change the mode to VEHICLE OFF, move the shift lever to $\boxed{\mathbf{P}}$ after the vehicle comes to a complete stop.

Canadian continuously variable transmission models

Then press the **ENGINE START/STOP** button twice without depressing the brake pedal.

Manual transmission models

The power mode changes to VEHICLE OFF.

Emergency Engine Stop


Do not press the button while driving unless it is absolutely necessary for the engine to be switched off

Jump Starting

Jump Starting Procedure

Jump Starting Procedure

Turn off the power to electric devices, such as audio and lights. Turn off the engine, then open the hood.



- **1.** Connect the first jumper cable to your vehicle's battery \bigoplus terminal.
- **2.** Connect the other end of the first jumper cable to the booster battery \oplus terminal.
 - ► Use a 12-volt booster battery only.
 - ▶ When using an automotive battery charger to boost your 12-volt battery, select a lower charging voltage than 15-volt. Check the charger manual for the proper setting.
- **3.** Connect the second jumper cable to the booster battery \bigcirc terminal.





AWARNING


A battery can explode if you do not follow the correct procedure, seriously injuring anyone nearby.

Keep all sparks, open flames, and smoking materials away from the battery.

Securely attach the jumper cables clips so that they do not come off when the engine vibrates. Also be careful not to tangle the jumper cables or allow the cable ends to touch each other while attaching or detaching the jumper cables.







- **4.** Connect the other end of the second jumper cable to the engine mounting bolt as shown. Do not connect this jumper cable to any other part.
- **5.** If your vehicle is connected to another vehicle, start the assisting vehicle's engine and increase its rpm slightly.
- **6.** Attempt to start your vehicle's engine. If it turns over slowly, check that the jumper cables have good metal-to-metal contact.

≥ Jump Starting

Battery performance degrades in cold conditions and may prevent the engine from starting.

Continued 547

What to Do After the Engine Starts

Once your vehicle's engine has started, remove the jumper cables in the following order.

- 1. Disconnect the jumper cable from your vehicle's ground.
- **2.** Disconnect the other end of the jumper cable from the booster battery \bigcirc terminal.
- **3.** Disconnect the jumper cable from your vehicle's battery \oplus terminal.
- **4.** Disconnect the other end of the jumper cable from the booster battery \oplus terminal.

Have your vehicle inspected by a nearby service station or a dealer.

What to Do After the Engine Starts

The VSA® and CMBS^{TM*} indicators may come on when your turn the ignition switch to ON \boxed{II}^{*1} after re-connecting a battery.

Drive a short distance at more than 12 mph (20 km/h). Each indicator should go off. If either or both do not, have your vehicle checked by a dealer.


^{*1:} Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

Shift Lever Does Not Move

Continuously variable transmission models

Follow the procedure below if you cannot move the shift lever out of the P position.

■ Releasing the Lock



1. Set the parking brake.

Models without smart entry system

2. Remove the key from the ignition switch.

Models with smart entry system


2. Remove the built-in key from the smart entry remote.

All models

3. Move the removable beverage holder tray rearward.

Front seat beverage holders P. 179

- **4.** Wrap a cloth around the tip of a small flattip screwdriver to remove the cover of the shift lock release slot. Put the tip of the flattip screwdriver into the slot and remove it as shown in the image.
- **5.** Insert the key into the shift lock release slot.
- **6.** While pushing the key in, press the shift lever release button and place the shift lever into [N].
 - ► The lock is now released. Have the shift lever checked by a dealer as soon as possible.



Overheating

How to Handle Overheating

Overheating symptoms are as follows:

- The temperature gauge pointer is at the H mark or the engine suddenly loses power.
- Steam or spray comes out of the engine compartment.

■ First thing to do

- 1. Immediately park the vehicle in a safe place.
- 2. Turn off all accessories and turn on the hazard warning lights.
 - ▶ **No steam or spray present:** Keep the engine running and open the hood.
 - ➤ Steam or spray is present: Turn off the engine and wait until it subsides. Then open the hood.

AWARNING

Steam and spray from an overheated engine can seriously scald you.

Do not open the hood if steam is coming out.

NOTICE

Continuing to drive with the temperature gauge pointer at the $\boxed{\rm H}$ mark may damage the engine.

■ Next thing to do



- **1.** Check that the cooling fan is operating and stop the engine once the temperature gauge pointer comes down.
 - ► If the cooling fan is not operating, immediately stop the engine.
- **2.** Once the engine has cooled down, inspect the coolant level and check the cooling system components for leaks.
 - ▶ If the coolant level in the reserve tank is low, or no coolant in the tank, check that the radiator is cool. Cover the reserve tank cap with a heavy cloth and open the cap. Add coolant until it reaches the MAX mark, and put the cap back on.

■ Last thing to do

Once the engine has cooled sufficiently, restart it and check the temperature gauge. If the temperature gauge pointer has gone down, resume driving. If it has not gone down, contact a dealer for repairs.

AWARNING

Removing the reserve tank cap while the engine is hot can cause the coolant to spray out, seriously scalding you.

Always let the engine and radiator cool down before removing the reserve tank cap.

If the coolant is leaking, contact a dealer for repairs.

Use water as an emergency/temporary measure only. Have a dealer flush the system with proper antifreeze as soon as possible.

Indicator, Coming On/Blinking

If the Low Oil Pressure Indicator Comes On



■ Reasons for the indicator to come on

Comes on when the engine oil pressure is low.

- What to do as soon as the indicator comes on
- **1.** Immediately park the vehicle on level ground in a safe place.
- 2. If necessary, turn the hazard warning lights on.
- What to do after parking the vehicle
- **1.** Stop the engine and let it sit for about three minute.
- 2. Open the hood and check the oil level.
 - Add oil as necessary.

Oil Check P. 493

- **3.** Start the engine and check the low oil pressure indicator.
 - ► The indicator goes off: Start driving again.
 - ► The indicator does not go off within 10 seconds: Stop the engine and contact a dealer for repairs immediately.

If the Charging System Indicator Comes On



■ Reasons for the indicator to come on

Comes on when the battery is not being charged.

■ What to do when the indicator comes on

Turn off the heating system*/climate control system*, rear defogger, and other electrical systems, and immediately contact a dealer for repairs.

If the Low Oil Pressure Indicator Comes On

NOTICE

Running the engine with low oil pressure can cause serious mechanical damage almost immediately.

∑If the Charging System Indicator Comes On

If you need to stop temporarily, do not turn off the engine. Restarting the engine may rapidly discharge the battery.

If the Malfunction Indicator Lamp Comes On or Blinks



■ Reasons for the indicator lamp to come on or blink

- Comes on if there is a problem with the engine emissions control system.
- Blinks when engine misfiring is detected.

■ What to do when the indicator lamp comes on

Avoid high speeds and immediately get your vehicle inspected at a dealer.

■ What to do when the indicator lamp blinks

Park the vehicle in a safe place with no flammable items and wait at least 10 minutes or more with the engine stopped until it cools.

≥ If the Malfunction Indicator Lamp Comes On or Blinks

NOTICE

If you drive with the malfunction indicator lamp on, the emissions control system and the engine could be damaged.

If the malfunction indicator lamp blinks again when restarting the engine, drive to the nearest dealer at 31 mph (50 km/h) or less. Have your vehicle inspected.

If the Brake System Indicator (Red) Comes On or Blinks

U.S. BRAKE

Canada

(Red)

■ Reasons for the indicator to come on

- The brake fluid is low.
- There is a malfunction in the brake system.
- What to do when the indicator comes on while driving

Depress the brake pedal lightly to check pedal pressure.

- If normal, check the brake fluid level the next time you stop.
- If abnormal, take immediate action. If necessary, downshift the transmission to slow the vehicle using engine braking.
- Reason for the indicator to blink
- There is a problem with the electric parking brake system.
- What to do when the indicator blinks

Avoid using the parking brake and have your vehicle checked by a dealer immediately.

≥ If the Brake System Indicator (Red) Comes On or Blinks

Have your vehicle repaired immediately. It is dangerous to drive with low brake fluid. If there is no resistance from the brake pedal, stop immediately in a safe place. If necessary downshift the gears.

If the brake system indicator and **ABS** indicator come on simultaneously, the electronic brake distribution system is not working. This can result in vehicle instability under sudden braking.

Have your vehicle inspected by a dealer immediately.

If the brake system indicator (red) blinks at the same time when the brake system indicator (amber) comes on, the parking brake may not work.

Avoid using the parking brake and have your vehicle checked by a dealer immediately.

☑ If the Brake System Indicator (Red) Comes On or Blinks at the Same Time When the Brake System Indicator (Amber) Comes On P. 555

If you repeatedly operate the electric parking brake in a short period of time, the brake stops operating to prevent heating of the system and the indicator blinks.

It returns to its original state in approximately 1 minute.

If the Brake System Indicator (Red) Comes On or Blinks at the Same Time When the Brake System Indicator (Amber) Comes On



U.S.

BRAKE

SYSTEM

Canada

(Amber)

■If the brake system indicator (red) comes on or blinks at the same time when the brake system indicator (amber) comes on, release the parking brake manually or automatically.

Parking Brake P. 451

•If the brake system indicator (red) continuously comes on or blinks at the same time when the brake system indicator (amber) comes on, stop the vehicle in a safe place and have it inspected by a dealer immediately.

▶ Preventing the vehicle from moving

Continuously variable transmission models

Move the shift lever to \mathbf{P} .

Manual transmission models

Move the shift lever to $\boxed{1}$ or \boxed{R} .

•If the brake system indicator (amber) comes on alone, avoid using the parking brake and have your vehicle checked by a dealer immediately.

■ If the Brake System Indicator (Red) Comes On or Blinks at the Same Time When the Brake System Indicator (Amber) Comes On

If you apply the parking brake, you may not be able to release it

If the brake system indicator (red) and the brake system indicator (amber) come on at the same time, the parking brake is working.

If the brake system indicator (red) blinks at the same time when the brake system indicator (amber) comes on, the parking brake may not work because it is checking the system.

If the Electric Power Steering (EPS) System Indicator Comes On



Reasons for the indicator to come on

- Comes on when there is a problem with the EPS system.
- If you depress the accelerator pedal repeatedly to increase the engine speed while the engine is idling, the indicator comes on, and sometimes the steering wheel becomes harder to operate.
- Comes on when EPS steering angle center point memory is lost. This
 could be due to a number of problems to include: battery disconnect,
 main fuse blow, low battery causing reset of the EPS system, wire
 damage to EPS harness. Vehicle Stability Assist (VSA®), VSA® OFF,
 Collision Mitigation Braking System™ (CMBS™)*, and low tire
 pressure/TPMS* indicators also come on with EPS indicator.

Models with driver information interface

The **Drive Carefully Systems Initializing...** message appears on the driver information interface.

■ What to do when the indicator comes on

- Stop the vehicle in a safe place and restart the engine.

 If the indicator comes on and stays on, immediately have your vehicle inspected by a dealer.
- If the EPS indicator, VSA® indicator, VSA® OFF indicator, CMBS™ indicator*, and low tire pressure/TPMS indicator* come on simultaneously, you need to calibrate the VSA and EPS systems.
 Drive straight at speed more than 12 mph (20 km/h) for less than 10 seconds to calibrate the VSA and EPS systems.

If the indicators come on and stay on, park your vehicle in a safe place, turn off and restart the engine, then repeat the above operation.

If the indicators still come on and stay on, immediately have your vehicle inspected by a dealer.

U.S. models

If the Low Tire Pressure/TPMS Indicator Comes On or Blinks



■ Reasons for the indicator to come on or blink

A tire pressure is significantly low, or the TPMS has not been calibrated. If there is a problem with the TPMS or the compact spare tire is installed, the indicator blinks for about one minute, and then stays on.

■ What to do when the indicator comes on

Drive carefully and avoid abrupt cornering and hard braking. Stop your vehicle in a safe place. Check the tire pressure and adjust the pressure to the specified level. The specified tire pressure is on a label on the driver side doorjamb.

- Calibrate the TPMS after the tire pressure is adjusted.
- What to do when the indicator blinks, then remains on Have the tire inspected by a dealer as soon as possible. If the compact spare tire causes the indicator to blink, change the tire to a full-size tire. The indicator goes off after driving for a few miles (kilometers).
 - Calibrate the TPMS after a full-size tire is reinstalled.

■If the Low Tire Pressure/TPMS Indicator Comes On or Blinks

NOTICE

Driving on an extremely underinflated tire can cause it to overheat. An overheated tire can fail. Always inflate your tires to the prescribed level.

Fuses


Fuse Locations

If any electrical devices are not working, turn the ignition switch to LOCK 0^{*1} and check to see if any applicable fuse is blown.

■ Engine Compartment Fuse Box

Located near the battery. Push the tabs to open the box.

Fuse locations are shown on the fuse box cover. Locate the fuse in question by the fuse number and box cover number.



■ Circuit protected and fuse rating

	Circuit Protected	Amps
	Passenger's Power Seat*/ Rear Seat Heaters*	(60 A)
	Cooling Fan*2	(30 A)
	Cooling Fan*3	(50 A)
1		-
	IG Main*4	30 A
	_*5	-
	Headlight High Beam Main	30 A
	Battery	125 A
	EPS	70 A
	IG Main	30 A*4
	IG IVIAITI	50 A*5
2	Fuse Box Option*	(40 A)
	Fuse Box	60 A
	Front Wiper Motor	30 A
	Headlight Low Beam Main	30 A
	Rear Defroster	40 A
	Starter Motor*4	30 A
3	*5	-
	Fuse Box	40 A
	ABS/VSA Motor	40 A
	ABS/VSA FSR	40 A
	Blower Motor	40 A

	Circuit Protected	Amps
_	-	_
4 -	-	_
4_	_	_
	-	-
5	Cooling Fan	5 A
6	Washer	15 A
7	FI Main	15 A
8	FI Sub	15 A
9	Stop Lights	10 A
10	Injector*³	(15 A)
11	LAF	5 A
12	FI ECU	10 A
13	Parking Lights	10 A
14	Hazard	15 A
15	IG Coil	15 A
16	Transmission*6	(15 A)
17	Daytime Running Lights	10 A
18	Back Up	10 A

^{*1:}Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

^{*2:2.0}L engine models

^{*3:1.5}L engine models

^{*4:}Models with smart entry system

^{*5:}Models without smart entry system


^{*6:}Continuously variable transmission models

	Circuit Protected	Amps
19	Audio	15 A
20	Audio AMP*	(30 A)
21	Interior Lights	10 A
22	Front Fog Lights*	(15 A)
23	A/C Compressor*	(10 A)
24	Horn	10 A
25	Left Headlight Low Beam	10 A
26	Right Headlight Low Beam	10 A
27	VB ACT*3	(10 A)
28	Left Headlight High Beam	10 A
29	Right Headlight High Beam	10 A
30	-	-
31	Rear Seat Heaters	(15 A)
32	Passenger's Power Seat Sliding*	(20 A)
33	Passenger's Power Seat Reclining*	(20 A)
34	_	-
35	-	-
36	_	_

^{*3:1.5}L engine models

■ Interior Fuse Box

Located under the dashboard.



Fuse locations are shown on the label on the side panel.

Locate the fuse in question by the fuse number and label number.

■ Circuit protected and fuse rating

	Circuit Protected	Amps
1	Accessory	10 A
2	_*1	_
2	Key Lock*2	(5 A)
3	-	-
4	Front Sensor Camera*1	(5 A)
4	Transmission*2, *3	(10 A)
5	Option	10 A
6	SRS Indicator	10 A
7	Meter	10 A
8	Fuel Pump	15 A


	Circuit Protected	Amps
9	AIRCON	10 A
10	_	-
11	Engine Control	5 A
12	Passenger Side Door Lock	10 A
13	Driver Side Rear Door Unlock	(10 A)
14	Rear Driver's Side Power Window	(20 A)
15	Front Passenger's Side Power Window	20 A
16	Door Lock	20 A
17	Transmission*1, *3 Front Sensor Camera*2	(10 A) (5 A)
18	_	_
19	Moonroof*	(20 A)
20	_	_
21	ACG	10 A
22	Daytime Running Lights	10 A
23	-	_
24	Front Sensor Camera*	(5 A)
25	Driver's Door Lock	10 A
26	Passenger Side Door Unlock	10 A
27	Rear Passenger's Side Power Window	(20 A)


- *1:Models with smart entry system
- *2:Models without smart entry system
- *3:Continuously variable transmission models

	Circuit Protected	Amps
28	Driver's Power Window	20 A
29	Front Accessory Power Socket	20 A
30	Smart Entry* ¹ _* ²	10 A –
31	Driver's Power Seat Reclining*	(20 A)
32	Front Seat Heater*	(20 A)
33	Driver's Power Seat Sliding*	(20 A)
34	VSA/ABS	10 A
35	SRS	10 A
36	-	-
37	-	_
38	Driver Side Rear Door Lock	(10 A)
39	Driver's Door Unlock	10 A

^{*1:}Models with smart entry system
*2:Models without smart entry system

Inspecting and Changing Fuses





- **1.** Turn the ignition switch to LOCK 0^{*1} . Turn headlights and all accessories off.
- **2.** Remove the fuse box cover.
- **3.** Check the large fuse in the engine compartment.
 - ▶ If the fuse is blown, use a Phillips-head screwdriver to remove the screw and replace it with a new one.
- **4.** Inspect the small fuses in the engine compartment and the vehicle interior.
 - ▶ If there is a burned out fuse, remove it with the fuse puller and replace it with a new one.

NOTICE

Replacing a fuse with one that has a higher rating greatly increases the chances of damaging the electrical system.

There is a fuse puller on the back of the engine compartment fuse box cover.

^{*1:} Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

Emergency Towing

Call a professional towing service if you need to tow your vehicle.

■ Flat bed equipment

The operator loads your vehicle on the back of a truck.

This is the best way to transport your vehicle.

■ Wheel lift equipment

The tow truck uses two pivoting arms that go under the front tires and lift them off the ground. The rear tires remain on the ground. **This is an acceptable way to tow your vehicle.**

Emergency Towing

NOTICE

Trying to lift or tow your vehicle by the bumpers will cause serious damage. The bumpers are not designed to support the vehicle's weight.

NOTICE

Improper towing such as towing behind a motorhome or other motor vehicle can damage the transmission.


Never tow your vehicle with just a rope or chain. It is very dangerous, since ropes or chains may shift from side to side or break.

Make sure the parking brake is released. If you cannot release the parking brake, your vehicle must be transported by the flat bed equipment.

Parking Brake P. 451

When You Cannot Unlock the Fuel Fill Door

If you cannot unlock the fuel fill door, use the following procedure.



- **1.** Open the trunk.
- **2.** Pull the green release cord beneath the rear tray to the right.
 - ➤ The release cord unlocks the fuel fill door when it is pulled.

>> When You Cannot Unlock the Fuel Fill Door


After taking these steps, contact a dealer to have your vehicle checked.

When You Cannot Open the Trunk

If you cannot open the trunk, use the following procedure.



- **1.** Remove the cover with a key.
 - ➤ Wrap a key with a cloth to prevent scratching the cover.



- 2. Pull the release lever.
- **3.** Replace the cover.

≫When You Cannot Open the Trunk

What to do-following up After taking these steps, contact a dealer to have your vehicle checked.

Refueling

Refueling From a Portable Fuel Container

If you have run out of fuel and need to refuel your vehicle from a portable fuel container, use the funnel provided with your vehicle.



- **1.** Turn off the engine.
- **2.** Press on the edge of the fuel fill door to make it pop up slightly.
 - ► The fuel fill door opens.
- **3.** Take the funnel out of the tool case in the trunk.
 - **Types of Tools** P. 536
- **4.** Place the end of the funnel on the lower part of filler opening, then insert it slowly and fully.
 - ► Make sure that the end of the funnel goes down along with the filler pipe.
- **5.** Fill the tank with fuel from the portable fuel container.
 - Pour fuel carefully so you do not spill any.
- **6.** Remove the funnel from the filler neck.
 - ➤ Wipe up any fuel from the funnel before storing it.
- 7. Shut the fuel fill door by hand.



AWARNING

Gasoline is highly flammable and explosive. You can be burned or seriously injured when handling fuel.


- Stop the engine, and keep heat, sparks, and flame away.
- Handle fuel only outdoors.
- Wipe up spills immediately.

NOTICE

system and its seal.

Do not insert the nozzle of a portable fuel container or any funnel other than the one provided with your vehicle. Doing so can damage the fuel system. Do not try to pry open or push open the sealed fuel tank with foreign objects. This can damage the fuel

Make sure the fuel in the portable fuel container is gasoline before you refuel.



Information

This chapter includes your vehicle's specifications, locations of identification numbers, and other information required by regulation.

specifications	568
dentification Numbers	
Vehicle Identification Number (VIN),	
Engine Number and Transmission	
Number	572
Devices that Emit Radio Waves	573
Reporting Safety Defects	574

Emissions Testing	
Testing of Readiness Codes	575
Warranty Coverages	577
Authorized Manuals	579
Customer Service Information	580

Specifications

2.0 ℓ engine models

■ Vehicle Specifications

Model	Honda Civic 4-Door
No. of Passengers:	
Front	2
Rear	3
Total	5
Weights:	
Gross Vehicle Weight Rating	U.S.: 3,737 lbs (1,695 kg) Canada: 1,695 kg
Gross Axle Weight	
Rating (Front)	U.S.: 1,984 lbs (900 kg) Canada: 900 kg
Gross Axle Weight	
Rating (Rear)	U.S.: 1,786 lbs (810 kg) Canada: 810 kg

■ Air Conditioning*

Refrigerant Type	HFO-1234yf (R-1234yf)
Charge Quantity	13.2 - 15.0 oz (375 - 425 g)
Lubricant Type	RL85HM (POE)
Quantity	2.7 – 3.6 oz (77 – 103 g)

■ Engine Specifications

Displacement	121.76 cu-	121.76 cu-in (1,996 cm³)		
Spark Plugs	NGK	DILKAR7H11GS		
		DILKAR7G11GS		
	DENSO	DXE22HQR-D11S		

■ Fuel

Fuel:	Unleaded gasoline, Pump octane number
Type	of 87 or higher
Fuel Tank Capacity	12.39 US gal (46.9 ℓ)

■Washer Fluid

Tank Capacity	U.S.: 2.6 US qt (2.5 ℓ)
тапк Сараспу	Canada: 4.8 US qt (4.5 ℓ)

■Light Bulbs

= Light Builds	
Headlights (Low Beam)	55W (H11)
Headlights (High Beam)	60W (HB3)
Parking/Daytime Running Lights	LED
Front Side Marker Lights	3W
Front Turn Signal Lights	21W (Amber)
Brake Lights	21W
Rear Turn Signal Lights	21W (Amber)
Rear Side Marker Lights	LED
Back-Up Lights	16W
Taillights	LED
High-Mount Brake Light	21W
Rear License Plate Light	LED
Trunk Light	5W
Interior Lights	
Map Lights	8W
Ceiling Light	8W

■ Brake/Clutch* Fluid

Specified	Honda Heavy Duty Brake Fluid DOT 3

■ Continuously Variable Transmission Fluid

Specified	Honda HCF-2 Trans	mission Fluid
Capacity	Change	3.7 US qt (3.5 ℓ)

■ Manual Transmission Fluid

Specified	Honda Manual Tra	nsmission Fluid (MTF)
Capacity	Change	2.0 US qt (1.9 ℓ)

■ Engine Oil

Recommended	·Genuine Honda Motor Oil 0W-20 ·API Premium-grade 0W-20 detergent oil	
	Change	4.2 US qt (4.0 ℓ)
Capacity	Change including filter	4.4 US qt (4.2 ℓ)

■ Engine Coolant

Specified	Honda Long-Life Antifreeze/Coolant Type2
Ratio	50/50 with distilled water
Capacity	1.4 US gal (5.30 ℓ) (change including the remaining 0.2 US gal (0.75 ℓ) in the reserve tank)

■ Tire

	Size	215/55R16 93H
Regular	Pressure psi (kPa [kgf/cm²])	32 (220 [2.2])
Commont	Size	T125/80D16 97M
Compact Spare*	Pressure psi (kPa [kgf/cm²])	60 (420 [4.2])
Wheel Size	Regular	16 x 7J
	Compact Spare	16 x 4T

* Not available on all models

1.5 ℓ engine models

■ Vehicle Specifications

Model	Honda Civic 4-Door
No. of Passengers:	
Front	2
Rear	3
Total	5
Weights:	
Gross Vehicle	U.S.: 3,902 lbs (1,770 kg)
Weight Rating	Canada: 1,770 kg
Gross Axle Weight	
Rating (Front)	U.S.: 2,105 lbs (955 kg)
	Canada: 955 kg
Gross Axle Weight	
Rating (Rear)	U.S.: 1,808 lbs (820 kg)
	Canada: 820 kg

■ Air Conditioning

Refrigerant Type	HFO-1234yf (R-1234yf)
Charge Quantity	13.2 - 15.0 oz (375 - 425 g)
Lubricant Type	RL85HM (POE)
Quantity	2.7 – 3.6 oz (77 – 103 g)

■ Engine Specifications

Displacement	91.26 cu-in (1,496 cm ³)		
Spark Plugs	NGK	ILZKAR8H8S	

■ Fuel

Fuel: Type	Unleaded gasoline, Pump octane number of 87 or higher
Fuel Tank Capacity	12.39 US gal (46.9 l)

■ Washer Fluid

Tank Capacity U.S.: 2.6 US qt (2.5 ℓ) Canada: 4.8 US qt (4.5 ℓ)	
---	--

■ Light Bulbs

Headlights (Low Beam)	55W (H11)*1 LED*2
Headlights (High Beam)	60W (HB3)*1 LED*2
Fog Lights	35W (H8)
Parking/Daytime Running Lights	LED
Front Side Marker Lights	3W
Front Turn Signal Lights	21W (Amber)*1 LED*2
Side Turn Signal Lights (on Door Mirrors)*	LED
Brake Lights	21W
Rear Turn Signal Lights	21W (Amber)
Rear Side Marker Lights	LED
Back-Up Lights	16W
Taillights	LED
High-Mount Brake Light	21W
Rear License Plate Light	LED
Trunk Light	5W
Interior Lights	
Map Lights	8W
Ceiling Light	8W
*4 5 .7 11	

^{*1:} Except Tour models *2: Tour models

■ Brake Fluid

Specified	Honda Heavy Duty Brake Fluid DOT 3

■ Continuously Variable Transmission Fluid

Specified	Honda HCF-2 Trans	mission Fluid
Capacity	Change	3.9 US qt (3.7 ℓ)

■Engine Oil

Recommended	·Genuine Honda Motor Oil 0W-20 ·API Premium-grade 0W-20 detergent oil	
	Change	3.4 US qt (3.2 ℓ)
Capacity	Change including filter	3.7 US qt (3.5 ℓ)

■ Engine Coolant


Specified	Honda Long-Life Antifreeze/Coolant Type2
Ratio	50/50 with distilled water
Capacity	1.34 US gal (5.09 ℓ) (change including the remaining 0.2 US gal (0.75 ℓ) in the reserve tank)

■Tire

	Size	215/50R17 91H
Regular	Pressure psi (kPa [kgf/cm²])	32 (220 [2.2])
Compact Spare	Size	T125/80D16 97M
	Pressure psi (kPa [kgf/cm²])	60 (420 [4.2])
Wheel Size	Regular	17 x 7J
	Compact Spare	16 x 4T

Vehicle Identification Number (VIN), Engine Number and Transmission Number

Your vehicle has a 17-digit vehicle identification number (VIN) used to register your vehicle for warranty purposes, and for licensing and insuring your vehicle. The locations of your vehicle's VIN, engine number and transmission number are shown as follows.



■ Vehicle Identification Number (VIN), Engine Number and Transmission Number

The interior vehicle identification number (VIN) is located under the cover.



Devices that Emit Radio Waves

The following products and systems on your vehicle emit radio waves when in operation.

Audio System

Bluetooth® Audio

Bluetooth® HandsFreeLink®

Collision Mitigation Braking System™

Immobilizer System

Keyless Access System*

Remote Transmitter

Wireless charger*

Each of the above complies with the appropriate requirements or the required standards of FCC (Federal Communications Commission) and Industry Canada Standard, described below:

As required by the FCC:

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

* Not available on all models

Reporting Safety Defects

In the U.S.

If you believe that your vehicle has a defect which could cause a crash or could cause injury or death, you should immediately inform the National Highway Traffic Safety Administration (NHTSA) in addition to notifying American Honda Motor Co., Inc.

If NHTSA receives similar complaints, it may open an investigation, and if it finds that a safety defect exists in a group of vehicles, it may order a recall and remedy campaign. However, NHTSA cannot become involved in individual problems between you, your dealer, or American Honda Motor Co., Inc.

To contact NHTSA, you may call the Vehicle Safety Hotline toll-free at 1-888-327-4236 (TTY: 1-800-424-9153); go to http://www.safercar.gov; or write to: Administrator, NHTSA, 1200 New Jersey Avenue, SE., Washington, DC 20590. You can also obtain other information about motor vehicle safety from http://www.safercar.gov.

In Canada

If you believe that your vehicle has a defect which could cause a crash or could cause injury or death, you should immediately inform Honda Canada Inc. and you may also inform Transport Canada.

If Transport Canada receives similar complaints, it may open an investigation, and if it finds that a safety defect exists in a group of vehicles, it may lead to a recall and remedy campaign. However, Transport Canada cannot become involved in individual problems between you, your dealer, or Honda Canada Inc.

To contact Transport Canada's Defect Investigations and Recalls Division, you may call 1-800-333-0510. For more information on reporting safety defects or about motor vehicle safety, go to http://www.tc.gc.ca/roadsafety.

Emissions Testing

Testing of Readiness Codes

Your vehicle has "Readiness Codes," as part of the onboard self diagnostic system. Some States use these codes as a test to see if your vehicle's emissions components are working properly.

The codes may not be read properly if testing is performed just after the battery has gone dead or been disconnected.

To check if they are set, turn the ignition switch to ON III^{*1} , without starting the engine. The malfunction indicator lamp will come on for several seconds. If it then goes off, the readiness codes are set. If it blinks five times, the readiness codes are not set.

If you are required to have your vehicle tested before the readiness codes are ready, prepare the vehicle for retesting by doing the following:

- 1. Fill the gas tank to approximately 3/4 full.
- 2. Park the vehicle and leave the engine off for 6 hours or more.
- **3.** Make sure the ambient temperature is between 40°F and 95°F (4°C and 35°C).
- **4.** Start the engine without touching the accelerator pedal, and let it idle for 20 seconds.
- **5.** Keep the vehicle in P (continuously variable transmission) or N (manual transmission). Increase the engine speed to 2,000 rpm, and hold it there for about 3 minutes.
- **6.** Let the engine idle with your foot off the accelerator for 20 seconds.

The readiness codes are erased when the battery is disconnected, and set again only after several days of driving under a variety of conditions.

If a testing facility determines that the readiness codes are not set, you may be requested to return at a later date to complete the test.

If the testing facility determines the readiness codes are still not set, see a dealer.

Continued 575

[▼]Testing of Readiness Codes

^{*1:} Models with the smart entry system have an **ENGINE START/STOP** button instead of an ignition switch.

- 7. Select a nearby, lightly traveled major highway where you can maintain a speed of 50 to 60 mph (80 to 97 km/h) for at least 20 minutes. Drive on the highway in (continuously variable transmission) or 5th (manual). Do not use cruise control. When traffic allows, drive for 90 seconds without moving the accelerator pedal. (Vehicle speed may vary slightly; this is okay.) If you cannot do this for a continuous 90 seconds because of traffic conditions, drive for at least 30 seconds, then repeat it two more times (for a total of 90 seconds).
- **8.** Drive in city/suburban traffic for at least 10 minutes. When traffic conditions allow, let the vehicle coast for several seconds without using the accelerator pedal or the brake pedal.
- **9.** Park the vehicle and leave the engine off for 30 minutes.

Warranty Coverages

■ U.S. Owners

Your new vehicle is covered by these warranties:

New Vehicle Limited Warranty – covers your new vehicle, except for the emissions control systems and accessories, against defects in materials and workmanship.

Emissions Control Systems Defects Warranty and Emissions Performance Warranty – these two warranties cover your vehicle's emissions control systems.

Time, mileage, and coverage are conditional. Please read your warranty booklet for exact information.

Seat Belt Limited Warranty – a seat belt that fails to function properly is covered by a limited warranty. Please read your warranty booklet for details.

Rust Perforation Limited Warranty – all exterior body panels are covered for rust-through from the inside for the specified time period with no mileage limit.

Accessory Limited Warranty – Honda accessories are covered under this warranty. Time and mileage limits depend on the type of accessory and other factors. Please read your warranty booklet for details.

Replacement Parts Limited Warranty – covers all Honda replacement parts against defects in materials and workmanship.

Continued 577

Replacement Battery Limited Warranty – provides prorated coverage for a replacement battery purchased from a dealer.

Replacement Muffler Lifetime Limited Warranty – provides coverage for as long as the purchaser of the muffler owns the vehicle.

Restrictions and exclusions apply to all these warranties. Please read the Honda warranty information booklet that came with your vehicle for precise information on warranty coverages. Your vehicle's original tires are covered by their manufacturer. Tire warranty information is in a separate booklet.

■ Canadian Owners

Please refer to the warranty manual that came with your vehicle.

Authorized Manuals

■ Service Express

For electronic copies of service publications, you can purchase a subscription to Service Express. Visit www.techinfo.honda.com for pricing and options.

For U.S. Owners:

Manuals can be purchased from Helm Incorporated. You can order a manual by phone at (800) 782-4356 (credit card orders only), or online at www.helminc.com.

■ For Canadian Owners:

Please contact a dealer to order any manuals that you may require.

Customer Service Information

Honda dealership personnel are trained professionals.

They should be able to answer all your questions. If you encounter a problem that your dealership does not solve to your satisfaction, please discuss it with the dealership's service manager or general manager. If you are dissatisfied with the decision made by the dealership's management, contact Honda Customer Services.

U.S. Owners:

American Honda Motor Co., Inc. Honda Automobile Customer Services Mail Stop 500-2N-7A 1919 Torrance Blvd. Torrance, CA 90501-2746 Tel: (800) 999-1009

Canadian Owners:

Honda Canada Inc. Customer Relations 180 Honda Boulevard Markham, ON L6C 0H9

Tel: 1-888-9-HONDA-9 Fax: 1-877-939-0909

E-mail: Honda_cr@ch.honda.com

In Puerto Rico and the U.S. Virgin Islands:

Bella International P.O. Box 190816 San Juan, PR 00919-0816

Tel: (787) 620-7546

■ Customer Service Information

When you call or write, please give us the following information:

- Vehicle Identification Number
 - Vehicle Identification Number (VIN), Engine Number and Transmission Number P 572
- Date of purchase
- Odometer reading of your vehicle
- Your name, address, and telephone number
- A detailed description of the problem
- Name of the dealer who sold the vehicle to you

A
ABS (Anti-lock Brake System) 457
Accessories and Modifications 474
Accessory Power Socket 181
Adaptive Cruise Control (ACC) with Low
Speed Follow (LSF) 87, 416
Adding the Coolant 500
Additives
Coolant 499
Engine Oil
Washer 503
Additives, Engine Oil
Adjusting
Armrest
Clock 122
Front Head Restraints
Front Seats
Mirrors
Rear Seats
Steering Wheel
Temperature 106, 110
Adjusting the Clock 122
Adjusting the Sound 210
Agile Handling Assist System 443
Aha TM
Air Conditioning System (Climate Control
System)
Changing the Mode 188, 192
Defrosting the Windshield and
Windows 188, 193

Dust and Pollen Filter 529	Ch
Recirculation/Fresh Air Mode 188, 192	Lá
Sensor	Ch.
Synchronized Mode 195	Clo
Using Automatic Climate Control 190	Cu
Air Conditioning System (Heating	Dis
System) 187	Err
Sensor	Ge
Using Automatic Heating 187	Но
Air Pressure 517, 569, 571	iPc
Airbags 44	Lin
Advanced Airbags 50	Me
After a Collision	M
Airbag Care 57	Re
Event Data Recorder 0	Re
Front Airbags (SRS) 47	Re
Indicator 55, 79	Se
Passenger Airbag Off Indicator 56	Sel
Sensors44	Sta
Side Airbags 51	Th
Side Curtain Airbags 53	US
AM/FM Radio 252	US
Android Auto289	Wa
Anti-lock Brake System (ABS) 457	Audi
Indicator 79	Auth
Apple CarPlay 286	Auto
Armrest 174	. Cu
Audio Remote Controls 201	Auto
Audio System 198, 223	Inc
Adjusting the Sound 210, 245	Auto
Audio/Information Screen 224	. Inc

Changing the Home Screen Icon	
Layout	228
Changing the Screen Interface	242
Closing Apps	244
Customizing the Meter	229
Display Setup	246
Error Messages	293
General Information	296
Home Screen	235
iPod	
Limitations for Manual Operation	247
Menu Customize	243
MP3/WMA/AAC	. 217, 273
Reactivating	
Recommended Devices	297
Remote Controls	201
Security Code	200
Selecting an Audio Source	247
Status Area	241
Theft Protection	200
USB Flash Drives	297
USB Port(s)	199
Wallpaper Setup	233
Audio/Information Screen	. 206, 224
Authorized Manuals	579
Auto Door Locking/Unlocking	137
Customize	. 117, 138
Automatic Brake Hold	454
Indicator	76, 454
Automatic Brake Hold System	
Indicator	76 454

Automatic Lighting 157	Headlights504	Cleaning the Interior 530
Average Fuel Economy 105, 109	High-Mount Brake Light 512	Climate Control System 190
Average Speed 109	Parking/Daytime Running Lights 510	Changing the Mode
	Rear License Plate Light 512	Defrosting the Windshield and
В	Side Turn Signal/Emergency Indicator	Windows 188, 193
D	Lights 510	Dust and Pollen Filter 529
Battery 525	Taillights 512	Recirculation/Fresh Air Mode 188, 192
Charging System Indicator 77, 552	Bulb Specifications 568, 570	Sensors
Jump Starting 546		Synchronized Mode 195
Maintenance (Checking the Battery) 525	С	Using Automatic Climate Control 190
Maintenance (Replacing) 527	C	CMBS [™] (Collision Mitigation Braking
Belts (Seat)	Carbon Monoxide Gas 70	System [™])
Beverage Holders 179	Carrying Cargo 391, 393	Coat Hooks
Bluetooth® Audio 276	Certification Label 572	Collision Mitigation Braking System™
Bluetooth® HandsFreeLink® 333, 356	Changing Bulbs 504	(CMBS [™])
Booster Seats (For Children) 69	Charging System Indicator 77, 552	Compact Spare Tire 537, 569, 571
Brake System451	Child Safety 58	Console Compartment
Anti-lock Brake System (ABS) 457	Childproof Door Locks	Continuously Variable Transmission
Automatic Brake Hold 454	Emergency Trunk Opener 143	Creeping404
Brake Assist System 458	Child Seat 58	Fluid 501
Fluid 502	Booster Seats 69	Kickdown 404
Foot Brake 453	Child Seat for Infants	Operating the Shift Lever 24, 406
Indicator (Red) 74, 554, 555	Child Seat for Small Children 61	Shift Lever Does Not Move 549
Parking Brake 451	Installing a Child Seat with a Lap/Shoulder Seat	Shifting 405
Brightness Control (Instrument Panel) 162	Belt 65	Controls 121
Bulb Replacement 504	Larger Children 68	Coolant (Engine) 499
Brake Light, Tail/Rear Side Marker Light, Rear	Rear-facing Child Seat 60	Adding the Coolant 500
Turn Signal Lights and Back-Up Lights 511	Selecting a Child Seat	Overheating 550
Fog Lights506	Using a Tether	Creeping (Continuously Variable
Front Side Marker Lights 509	Childproof Door Locks 136	Transmission) 404
Front Turn Signal Lights 508	Cleaning the Exterior 532	

Cruise Control 411	Locking/Unlocking the Doors from	Starting 396	, 39
Indicator 84	the Outside	Switch Buzzer	. 15
Cup Holders 179	Lockout Prevention System 133	Engine Coolant	499
Customer Service Information 580	DOT Tire Quality Grading 519	Adding the Coolant	. 50
Customized Features 111, 302	Driver Information Interface 107	Overheating	. 550
	Driving 389	Temperature Gauge	. 10
n	Braking 451	Engine Oil	49
D .	Continuously Variable Transmission 404	Adding	49
Daytime Running Lights 159	Cruise Control 411	Checking	49
Dead Battery 546	Shifting Gear 407	Displaying Oil Life	, 48
Defaulting All the Settings 332	Shifting Position 405	Low Oil Pressure Indicator	, 55
Defrosting the Windshield and	Starting the Engine	Recommended Engine Oil	49
Windows 188, 193	Dust and Pollen Filter 529	ENGINE START/STOP Button	. 15
Devices that Emit Radio Waves 573		EPS (Electric Power Steering) System	. 55
Dimming	E	Exhaust Gas Hazard (Carbon	
Headlights 156	E	Monoxide)	7
Rearview Mirror 165	Eco Assist System 9	Expanded View Driver's Mirror	. 16
Dipstick (Engine Oil) 493	ECON Button	Exterior Care (Cleaning)	. 53
Directional Signals (Turn Signal) 156	Elapsed Time 109	Exterior Mirrors	. 16
Display Button 224	Electric Power Steering (EPS) System 80		
Display Setup 211	Indicator 80, 556	_	
Display/Information Button 107	Electronic Stability Control (ESC) 441	F	
Door Mirrors 166	Emergency 562	Features	. 19
Doors 124	Emergency Engine Stop 545	Filters	
Auto Door Locking 137	Emergency Trunk Opener 143	Dust and Pollen	
Auto Door Unlocking 137	Emissions Testing (Readiness Codes) 575	Oil	49
Door and Trunk Open Indicator 35, 80	Engine	Flat Tire	. 53
Keys 124	Coolant 499	Floor Mats	. 53
Locking/Unlocking the Doors from	Jump Starting 546		

Fluids	G
Brake/Clutch502	Gaso
Continuously Variable Transmission 501	Ec
Engine Coolant	Gá
Manual Transmission 501	Inf
Windshield Washer 503	lns
FM/AM Radio 212, 252	Lo
Fog Light Indicator 82	Re
Folding Down the Rear Seats 173	Gau
Foot Brake 453	Gea
Front Airbags (SRS) 47	Co
Front Head Restraints 170	M.
Front Seat Heaters 185	Glas
Front Seats 167	Glov
Adjusting 167	diov
Front Sensor Camera 414	
Fuel	H
Economy 473	Halo
Gauge 103	Han
Instant Fuel Economy 105, 110	Han
Low Fuel Indicator 78	Au
Range 105, 109	
Recommendation 470	Di
Refueling 470	
Fuel Economy	HF
Fuel Fill Door	HF
Fuses 558	ln
Inspecting and Changing 561	Lir
Locations 558, 559	M.

G	
Gasoline (Fuel)	
Economy	473
Gauge	103
Information	470
Instant Fuel Economy	105, 110
Low Fuel Indicator	78
Refueling	470
Gauges	103
Gear Shift Lever Positions	
Continuously Variable Transmission.	405
Manual Transmission	408
Glass (care)	530, 533
Glove Box	177
Н	
Halogen Bulbs	504, 507
Handling the Unexpected	535
HandsFreeLink® (HFL)	333, 356
Automatic Import of Cellular Phonel	ook and
Automatic Import of Cellular Phonel Call History	
	369
Call History	369 383
Call History Displaying Messages	369 383 333, 356
Call History Displaying Messages HFL Buttons	369 383 333, 356 335, 359
Call History Displaying Messages HFL Buttons HFL Menus	369 383 333, 356 335, 359 334, 358
Call History Displaying Messages HFL Buttons HFL Menus HFL Status Display	369 383 333, 356 335, 359 334, 358 387

Options During a Call	
Phone Setup	,
Phonebook Phonetic Modification	
Receiving a Call	
Receiving a Text Message/E-mail	381
Ring Tone	368
Selecting a Mail Account	382
Speed Dial 34	6, 370
To Set Up Text Message/E-mail	
Options	367
Hazard Warning Button	4
HD Radio™	252
Headlights	156
Aiming	504
Automatic Operation	157
Dimming 15	6, 159
Operating	156
Heaters (Front Seat)	
Heaters (Seat)	186
Heating and Cooling System	
Dust and Pollen Filter	529
Heating System	187
Changing the Mode	
Sensors	189
Using Automatic Heating	187
HFL (HandsFreeLink®) 33	
High Beam Indicator	
Hill Start Assist System 39	
HondaLink®	

1
Identification Numbers 572
Vehicle Identification 572
Ignition Switch 151
Illumination Control 162
Knob 162
Immobilizer System 144
Immobilizer System Indicator 83
Indicators 74
Adaptive Cruise Control (ACC) with Low Speed
Follow (LSF) 87, 416
Anti-lock Brake System (ABS) 79
Automatic Brake Hold 76, 454
Automatic Brake Hold System 76, 454
Brake Depressing 85
Charging System
Collision Mitigation Braking System™
(CMBS [™])
CRUISE CONTROL 84, 412
CRUISE MAIN 84, 411
Door and Trunk Open 35, 80
ECON Mode 84, 410
Electric Power Steering (EPS)
System 80, 556
Fog Light 82
High Beam 82
Immobilizer System 83
Lane Keeping Assist System (LKAS) 88, 436
Lights On 82
Low Fuel 78
Low Oil Pressure 76, 552

Low Tire Pressure/TPMS 81, 446, 449
Maintenance Minder 84, 479
Malfunction Indicator Lamp
Parking Brake and Brake System (Amber) 75
Parking Brake and Brake System
(Red)
Road Departure Mitigation (RDM)
Seat Belt Reminder
Security System Alarm 83
Shift Lever Position 77
Supplemental Restraint System 55, 79
System Message 82
Transmission
Turn Signal 82
Vehicle Stability Assist (VSA®)
System
VSA® OFF 80, 442
Washer Level 84
Information 567
Information Display
Instant Fuel Economy 105, 110
Instrument Panel 73
Brightness Control
Interior Lights 175
Interior Rearview Mirror 165
iPod
1
Jack (Wheel Nut Wrench) 540
Jump Starting 546

K

IX.		
Key Number Tag		125
Keys		124
Keys		124
Number Tag		125
Rear Door Won't Open		136
Remote Transmitter		131
Types and Functions		124
Won't Turn		. 28
Kickdown (Continuously Variable		
Transmission)		404
L		
_		
Lane Keeping Assist System (LKAS)		
LaneWatch™		
Language (HFL)	334,	358
LATCH (Child Seats)		. 63
Lights	156,	504
Automatic		
Bulb Replacement		504
Daytime Running Lights		159

 Fog Lights
 159

 High Beam Indicator
 82

 Interior
 175

 Light Switches
 156

 Lights On Indicator
 82

 Turn Signals
 156

 Load Limits
 393

Locking/Unlocking	124	Safety	477	Low Oil Pressure Indicator	76, 552
Auto Door Locking/Unlocking	137	Service Items	481, 486	Recommended Engine Oil	492
Childproof Door Locks	136	Tires	516	Viscosity	492
From Inside		Transmission Fluid	501	Open Source Licences	300
From Outside	127	Under the Hood	489	Opening	
Keys	124	Malfunction Indicator Lamp	77, 553	Trunk	564
Using a Key		Manual Transmission	407	Opening/Closing	
Low Battery Charge	552	Map Lights	176	Hood	491
Low Fuel Indicator	78	Maximum Load Limit	393	Moonroof	150
Low Oil Pressure Indicator	76, 552	Meters, Gauges	103	Power Windows	147
Low Smart Entry Remote Signal		Mirrors	165	Trunk	141
Strength	126	Adjusting	165	Outside Temperature Display	106, 110
Lower Anchors	63	Door	166	Overheating	550
Lubricant Specifications Chart	568, 570	Exterior	166		
Luggage (Maximum Load Limit)	393	Interior Rearview	165	Р	
		Modifications (and Accessories) 474	r	
N/I		Moonroof	150	Pandora®	270
M		MP3	217, 273	Panic Mode	146
Maintenance	475	Multi-View Rear Camera	468	Parking	467
Adding the Coolant	500			Parking Brake	451
Battery		N		Parking Brake and Brake System Ir	ndicator
Brake/Clutch Fluid	502	IN		(Amber)	75
Cleaning	530	Numbers (Identification)	572	Parking Brake and Brake System Ir	ndicator
Climate Control System	529			(Red)74	4, 554, 555
Coolant	499	0		Passenger Airbag Off Indicator	56
Heating System		O		Passing Indicators	
Maintenance Minder™	479	Odometer	104, 108	Playing <i>Bluetooth</i> ® Audio	220, 276
Oil	493	Oil (Engine)		Power Windows	147
Precautions	476	Adding		Precautions While Driving	403
Remote Transmitter	527	Checking		Rain	403
Replacing Light Bulbs	504	Displaying Oil Life	479, 484	Pregnant Women	42

Puncture (Tire)	537	S		Setting the Clock	
		Safe Driving	21	Shift Lever	24, 405, 407
R		•		Shift Lever Position Indicator .	77
n		Safety Check		Shift Position Indicator	406
Radio (FM/AM)	212, 252	Safety Labels		Shifting (Transmission)	405, 407
Radio (SiriusXM®)	256	Safety Message		Shoulder Anchor	41
Radio Data System (RDS)	213, 254	Seat Belts		Side Airbags	51
Range	105, 109	Adjusting the Shoulder Anchor.		Side Curtain Airbags	53
RDS (Radio Data System)	213, 254	Automatic Seat Belt Tensioners.		Siri Eyes Free	285
Readiness Codes (Emissions Testing) 575	Checking		SiriusXM® Radio	
Rear Defogger/Heated Door Mirror	-	Fastening		Smart Entry with Push Button	Start
Button	163	Installing a Child Seat with a Lap		System	127
Rear Seat Heaters	186	Belt		Snow Tires	524
Rear Seats (Folding Down)	173	Pregnant Women		Song By Voice™ (SBV)	266
Rearview Mirror	165	Reminder		Spare Tire	
Refueling	470	Warning Indicator	· ·	Spark Plugs	568, 570
Fuel Gauge	103	Seat Heaters		Specifications	
Gasoline 470	, 568, 570	Seats		Specified Fuel	
Low Fuel Indicator	78	Adjusting		Speedometer	
Regulations 449	, 519, 573	Front Seat Heaters		SRS Airbags (Airbags)	47
Remote Transmitter	131	Front Seats		Starting the Engine	396, 398
Replacement		Rear Seats		Does Not Start	
Battery	527	Seat Heaters		Engine Switch Buzzer	151
Bulbs	504	Security System		Jump Starting	
Fuses	558, 559	Security System Alarm Indicator		Steering Wheel	
Tires	522	Select Lever		Adjusting	164
Wiper Blade Rubber	513	Operation		Stopping	
Reporting Safety Defects	574	Releasing		Summer Tires	
Resetting a Trip Meter		Won't Move		Supplemental Restraint Syster	
Road Departure Mitigation (RDM).	430	Select/Reset Knob	•	Switches (Around the Steering	
On and Off		Selecting a Child Seat		Wheel)	
		Selector Knob (Audio)	205		

System Message Indicator	82	Transmission	405, 407	U	
		Continuously Variable Transmis	ssion 405	Unlocking the Doors	127
т		Fluid		Unlocking the Front Doors from	127
•		Manual		the Inside	13/
Tachometer	103	Shift Lever Position Indicator	77, 406	USB Adapter Cable	
Temperature		Trip Meter	· ·	USB Flash Drives	
Outside Temperature Display	106, 110	Troubleshooting	535	USB Port(s)	
Temperature Sensor		Blown Fuse	558, 559	Using the Smart Entry with Push Bu	
Time (Setting)	122	Brake Pedal Vibrates	28	System	
Tire Pressure Monitoring Syst	em	Buzzer Sounds When Opening	Door 29	3ystem	127
(TPMS)		Emergency Towing	562		
Indicator		Engine Won't Start	543	V	
Tires		Noise When Braking	29	Vanity Mirrors	7
Air Pressure		Overheating	550	Vehicle Identification Number	
Checking and Maintaining	516	Premium Gasoline	570	Vehicle Stability Assist (VSA®)	
Inspection	516	Puncture/Flat Tire	537	Off Button	
Labeling	517	Rear Door Won't Open	29, 136	Off Indicator	
Puncture (Flat Tire)	537	Select Lever Won't Move	549	System Indicator	
Regulations	519	Warning Indicators	74	Viscosity (Oil)	
Rotation		Trunk	141	Voice Control Operation	
Spare Tire	537, 569, 571	Lid	141	Audio Commands	
Summer	524	Light Bulb	568, 570	Climate Control Commands	
Tire Chains	524	Release Lever	564	General Commands	
Wear Indicators	521	Unable to Open	564	Music Search Commands	
Winter	524	Turn Signals	156	On Screen Commands	
Tools	536	Indicators (Instrument Panel)	82	Phone Commands	
Towing Your Vehicle				Useful Commands	
Emergency	562				
TPMS (Tire Pressure Monitori	ng			Voice Portal Screen	
System)	446			Voice Recognition	
Indicator	81, 557			VSA® (Vehicle Stability Assist)	441

W

Wallpaper	208,	233
Warning and Information		
Messages	90), 9
Warning Indicator On/Blinking		552
Warning Labels		. 7
Warranties (Warranty Manual provi	ded	
separately)		57
Watts		570
Wear Indicators (Tire)		52
Wheel Nut Wrench (Jack Handle)		540
Wi-Fi Connection		283
Window Washers		160
Adding/Refilling Fluid		503
Switch		160
Windows (Opening and Closing)		147
Windshield		160
Cleaning	530,	533
Defrosting/Defogging	188,	193
Washer Fluid		503
Wiper Blades		513
Wipers and Washers		160
Winter Tires		524
Snow Tires		524
Tire Chains		524
Wipers and Washers		160
Checking and Replacing Wiper Blade	S	513
Wireless Charger		182
WMA	217,	273
Worn Tires		516