### **ALL ROADS BACKED BY HONDA.**

## **EXPERIENCE WORRY-FREE** DRIVING



electrical parts and components of the plans. Images used in this brochure are for graphic representation only. Honda reserves the right to make changes at any time without notice or obligation. Please refer to the contract for full details of coverage, limitations, exclusions





honda.ca

Plus HONDA



NS2484

## WHY HONDA PLUS?

## POWER OF DREAMS. POWERFUL PERFORMANCE.

With innovative technologies like Honda Sensing<sup>™</sup>, Collision Mitigation Braking System<sup>™</sup> and next Generation Advanced Compatibility Engineering (ACE<sup>™</sup>) body structure, we continue to establish new standards for a safer tomorrow.

Our Honda Plus suite of Warranty and Protection products also set the industry standard – from Appearance Protection & Owner Comfort to Payment Protection & Extended Warranties – we've got you covered no matter where the road takes you.

Experience worry-free driving.

Ask us about the full Honda Plus line of warranty and protection products. With Honda trained technicians using only genuine Honda parts, we'll get you back on the road fast.

The Honda Plus Comprehensive Extended Warranty Plan offers various coverage options up to 10 years / 160,000km so you can find the one that suits you best. The warranty is fully transferable and ultimately increases the resale value of your vehicle.

With a plan this comprehensive, open up new adventures.

# PREPARE FOR THE UNEXPECTED.

#### HONDA PLUS ROADSIDE ASSISTANCE

Honda Plus Roadside Assistance is designed to protect you anywhere in Canada and the United States. With our 24/7 toll-free emergency help line you can reach us any time. Roadside Assistance coverage is based on years, not distance. Which means you'll be covered no matter how far the road takes you. Honda Plus Roadside Assistance covers the registered vehicle and all authorized drivers. Just one of the many ways Honda gives you total peace of mind.

Standard Factory Roadside Coverage is included with your vehicle

- Emergency Roadside Service
   Trip Interruption Benefits
- Lockout Service
- Winching Service
- Mechanical Breakdown
   Towing Service
- Emergency Transportation

#### **GET OUT AND EXPLORE.**

When you upgrade to an Extended Warranty, your Roadside Assistance is also upgraded to include Car Rental benefits and Tire Road Hazard Service.

#### Car Rental Benefits\*\*

You'll always have a plan B. If your Honda requires a minimum of five hours of repair for a covered breakdown, or Honda Canada does not have the required parts, Honda Plus will help you with a rental vehicle.

#### Road hazards are a very real part of driving

Honda Plus Roadside Assistance with Tire Road Hazard will cover the cost of installation, balancing and the value of the OEM tire.\*\*\*

\*Minimum 14 days prior to departure date.

\*\*Allows up to \$45 per day towards car rental to maximum of 5 days. Cannot be used in conjunction with Trip Interruption Benefits.

\*\*\*Based on tire tread depth. Temporary spare not covered

## **PLAN OPTIONS**

	CIVIC FIT	ACCORD CRV HRV CLARITY INSIGHT	PILOT PASSPORT RIDGELINE ODYSSEY
5 Years/100,000 km*	\$1,548	\$1,788	\$1,888
6 Years/100,000 km*	\$1,628	\$1,828	\$2,128
6 Years/160,000 km*	\$2,228	\$2,448	\$2,888
7 Years/130,000 km*	\$2,148	\$2,348	\$2,768
7 Years/160,000 km*	\$2,388	\$2,648	\$3,228
7 Years/200,000 km*	\$2,788	\$3,148	\$3,948
8 Years/130,000 km*	\$2,548	\$2,948	\$3,768
8 Years/200,000 km*	\$3,148	\$3,648	\$4,588
10 Years/160,000 km*	\$3,268	\$3,788	\$4,788

\* Whichever comes first

Price quotes are in effect as of March 1, 2023 and are subject to change without notice.

All prices listed are MSRP.

Brochure pricing applies to plans registered within 60 days of the vehicle in-service date.

Deferred purchases surcharges apply. See dealer for full details.

Emergency Message Service
Dealer Location Service
Trip Planning Service\*

Traffic Accident Services

For first 3 years

#### INCLUDED WITH YOUR VEHICLE HONDA PLUS

#### FACTORY WARRANTY WARRANTY WARRANTY WARRANTY POWERTRAIN SW/ 60,000 KM COMPREHENSIVE PROTECTION Cylinder block & all internal parts\* POWERTRAIN SW/ 60,000 KM POWERTRAIN SW/ 60,000 KM POWERTRAIN SW/ 60,000 KM Cylinder block & all internal parts\* Engine mounts Engine mounts Engine mounts Flywheel Intake & exhaust manifolds Intake & exhaust manifolds Intake & exhaust manifolds Oil pan (if damaged by the failure of an internal lubricated part) Intake & exhaust manifolds Intake & exhaust manifolds Oil punp Intube & exhaust manifolds Intake & exhaust manifolds Intake & exhaust manifolds Oil punp Intake & exhaust manifolds Intake & exhaust manifolds Intake & exhaust manifolds Intake & exhaust manifolds Oil punp Intake & exhaust manifolds Intake & exhaust manifolds Intake & exhaust manifolds Intake & exhaust manifolds Oil punp Intake & exhaust manifolds Oil punp Intake & exhaust manifolds Intake & exhaust manifolds Intake & exhaust manifolds Intake & exhaust manifolds Valve train & valve cover Intake & exhaust manifolds Intake & exhaust manifolds

#### ENGINE - Electric

Alternator		
Engine wiring harnesses		
Ignition coil		
Oil pressure sender unit		
Starter		
Voltage regulator		

#### ENGINE - Cooling

0		
Cooling fan		
Cooling fan thermoswitch		
Cooling fan timer		
Radiator		
Radiator cap		
Thermostat housing & gasket		
Thermostat, vacuum & coolant hoses		
Water pump		

#### ENGINE - Emissions

Endine Emissions	
Barometric pressure sensor	
Catalytic converter	8 yr / 130,000 km
Crank angle sensor	
Crankshaft speed sensor	
EFI main relay	
Electric load detector	
Engine control module	8 yr / 130,000 km
Evaporative emission two-way valve	
Exhaust Gas Recirculation (EGR) system	
Fast idle thermo valve	
Fuel tank pressure sensor	
Idle air control valve	
Injector resistors	
Injectors	
Intake air temperature sensor	
Knock sensor	
Map sensor	
Oxygen sensor	
Spark detection module	
Throttle body	
Throttle position sensor	

#### INCLUDED WITH YOUR VEHICLE HONDA PLUS

ABS / VSA	FACTORY WARRANTY 3 YR / 60,000 KM	POWERTRAIN 5 YR / 100,000 KM	COMPREHENSIVE PROTECTION PLAN
High pressure hoses			
Low pressure hoses			
Modulator & accumulator			
Power unit pump			
Pressure switch			

#### BRAKES

Booster & check valve		
Calipers – front & rear*		
Master cylinder & wheel cylinder		
Metal lines & fittings		
Parking brake linkage & cables		
Proportioning valves		
Rotors		

#### CLUTCH

Hydraulic line & cable		
Master cylinder		
Pressure plate		
Slave cylinder		

#### CRUISE CONTROL AND ACC

Actuator & valve		
Adaptive cruise control unit		
Check valve		
Collision mitigation system		
Module		

#### TRANSAXLE / TRANSMISSION

Automatic transmission cooler		
Control module		
CV joints		
CV boots & bands		
Differential case & all internal parts		
Drive shafts		
External shift linkage(s)		
Final drive housing & all internal parts		
Gearshift lever for manual transmission		
Lock-up control solenoid		
Paddle shifters		
Pressure control solenoid		
Pressure switch		
Shift control solenoid		
Speed pulser		
Torque converter on automatic transmission		
Transmission assembly & all internal		
lubricated parts*		
Transmission mounts		
Yaw-rate sensor		

\* Customer maintenance required as per Maintenance Minder

SUSPENSION	FACTORY WARRANTY 3 YR / 60,000 KM	POWERTRAIN 5 YR / 100,000 KM	COMPREHENSIVE PROTECTION PLAN
Ball joints			
Coil spring			
Compensator arms & trailing arms			
Control arms			
Front & rear beams			
Knuckles			
Radius rods & bushings			
Rear hub & bearings			
Shafts & bushings			
Shocks, struts & dampers			
Stabilizer bar			
Stabilizer bushings & links			
Strut mounts & bearings			
Wheel bearings			

#### STEERING

0122mmd		
EPS motor		
Output & return hoses		
Power steering pump / motor		
Steering column		
Steering gear housing & all internal parts		
Steering rack assembly		
Steering shaft		
Steering shaft gearbox connector		
Tie rods & tie rod ends		

#### 4-WHEEL DRIVE SYSTEM / AWD

4-wheel drive dual pump assembly		
4-wheel drive transfer case & all internal parts		
CV joints		
CV boots & bands		
Propeller shaft U-joints		
Rear differential assembly*		
Rear differential mounts		
Rear differential propeller shaft & centre bearing		

#### FUEL - SYSTEM

#### SUPPLEMENTAL RESTRAINT SYSTEM (SRS)

Airbags (SRS)		
Airbag module		
All SRS sensors		
Seat belts and buckles		
SRS harness		

#### INCLUDED WITH YOUR VEHICLE HONDA PLUS

AIR CONDITIONING	FACTORY WARRANTY 3 YR / 60,000 KM	POWERTRAIN 5 YR / 100,000 KM	COMPREHENSIVE PROTECTION PLAN
Accumulator			
Air mix control motor & cable			
Blower & function switch			
Blower motor & resistor			
Compressor / Clutch assembly & seal			
Condenser assembly & receiver assembly			
Condenser fan			
Evaporator			
Expansion valve			
Field coil			
Function control motor			
Idler pulley			
Pipes & hoses			
Recirculation control motor			
Thermal protector			
Thermostatic switch			
Wire harness, diodes			

#### HEATING

Heater control		
Heater core		
Pipes & hoses		
Water valve cable		
Wire harness, diodes		

#### DOOR & BODY

Antenna mast or XM antenna mast		
Door latch		
Door lock cylinders		
External trim, body seals, wheel rims & studs, glass, paint, interior trim, upholstery & seat construction. Surface corrosion of body panels (unlimited distance)		
Hinges		
Mechanical moonroof components		
Power door lock actuator		
Release / Control cables for seats, trunk or hatch release, hood & fuel filler door		
Seat belt chime		
Seat heater		
Sideview power mirror actuators		
Sideview power mirror defrosters		
Window regulators		

#### SECURITY SYSTEM

Immobilizer		
Harness		
Security transmitter		

#### INCLUDED WITH YOUR VEHICLE HONDA PLUS

FACTORY

ELECTRICAL	WARRANTY 3 YR / 60,000 KM	POWERTRAIN 5 YR / 100,000 KM	COMPREHENSIVE PROTECTION PLAN
Active Noise Cancellation (ANC)			
Adaptive front lighting system			
All bulletin related software updates			
All cameras			
All genuine Honda electrical accessories			
Audio system, LCD displays, DVD, DVD-A, DVD-ROM, MP3, WMA, tuner, SiriusXM® Canada Satellite Radio, auxiliary input jacks, clock			
Automatic day / night rearview mirror			
Battery Management System (BMS)			
Bulbs – 1 yr / 20 000 km			
Cooling fan motor(s)			
Fuse box – dash & under hood			
HandsFreeLink™ & HomeLink®			
Hard Disk Drive (HDD)			
Honda Satellite-Linked Navigation System™			
Honda Sensing™ Technologies			
Ignition switch, headlight switch, pushbutton			
starter switch, wiper blade switch			
Illuminated steering wheel-mounted controls			
Keyless entry system			
Main & sub wiring harness			
Meter & displays			
Microphones			
Resistors / transistors			
Solenoids & relays except those related to emissions			
Thermo pressure switches			
Tire Pressure Monitoring System (TPMS)			
Washer level warning sensor			
Washer pump – front & rear			
Windshield washer reservoir front & rear, headlight nozzles			
Wiper linkage			

#### SENSORS

All electrical sensors

#### CONTROL UNITS

All control units

#### SEALS & GASKETS

All seals & gaskets on covered parts

#### MANUALLY OPERATED SWITCHES

All manually operated switches

#### MOTORS

All electrical motors

#### FLUIDS & OILS

On all covered repairs

#### FOR HYBRID VEHICLES ONLY

HYBRID / ELECTRIC SYSTEM       3 YRS / 60,000 KM       8 YR / 160,000 KM       PROTECTION PLAN         Ambient air temperature sensors       Battery assembly (including all internal components)       Image: Components (including battery charger cables)       Image: Components (including battery charger cables)         Battery charger (including battery charger cables)       Image: Components (including battery charger cables)       Image: Components (including battery charger cables)         Battery condition monitor module (including software upgrades)       Image: Components (including battery pack coolant pump assembly       Image: Components (including battery pack coolant pump assembly         Battery pack coolant pump assembly       Image: Components and position sensor       Image: Components and position sensor         Brake pedal reaction force system       Image: Components and position sensors       Image: Components and position sensor         Generator position sensor       Image: Components and position sensor       Image: Components and position sensor         Generator rotor       Image: Component and position sensor       Image: Component and position sensor         Generator rotor       Image: Component and position sensor       Image: Component and position sensor         Generator rotor       Image: Component and position sensor       Image: Component and position sensor       Image: Component and position sensor         High voltage and bypass contactors, resistor and fuse       Image: Compone				
Battery assembly (including all internal components)       Including battery charger cables)         Battery charger (including battery charger cables)       Including battery charger (including battery charger cables)         Battery charger control module (including software upgrades)       Including battery charger cables)         Battery pack coolant pump assembly       Including battery current sensor         Battery pack coolant pump assembly       Including battery current sensor         Battery pock coolant position sensor       Including battery current sensor         Brake pedal position sensor       Including battery current sensor         Busbars       Including battery contors and rotors (including all internal components and position sensor)         Generator rotor       Generator rotor         Generator rotor       Including battery charger cables         High speed motor power inverter module fan control relay       Including all internal components)         High voltage and bypass contactors, resistor and fuse       Including all internal components)         Motor control module (including all internal components)       Including all internal components)         Motor control module coolant pump assembly       Including all internal components)         Motor control module coolant pump assembly       Including all internal components)         Motor control module coolant pump assembly       Including all internal components)	HYBRID / ELECTRIC SYSTEM	WARRANTY 3 YRS /	8 YR /	
Battery assembly (including all internal components)       Including battery charger cables)         Battery charger (including battery charger cables)       Including battery charger (including battery charger cables)         Battery charger control module (including software upgrades)       Including battery charger cables)         Battery pack coolant pump assembly       Including battery current sensor         Battery pack coolant pump assembly       Including battery current sensor         Battery pock coolant position sensor       Including battery current sensor         Brake pedal position sensor       Including battery current sensor         Busbars       Including battery contors and rotors (including all internal components and position sensor)         Generator rotor       Generator rotor         Generator rotor       Including battery charger cables         High speed motor power inverter module fan control relay       Including all internal components)         High voltage and bypass contactors, resistor and fuse       Including all internal components)         Motor control module (including all internal components)       Including all internal components)         Motor control module coolant pump assembly       Including all internal components)         Motor control module coolant pump assembly       Including all internal components)         Motor control module coolant pump assembly       Including all internal components)	Ambient air temperature sensors			
Battery charger control module Battery condition monitor module (including software upgrades) Battery pack coolant pump assembly Battery pack coolant pump assembly Battery pack coolant pump assembly Battery module service connector Brake pedal position sensor Brake pedal position sensor Brake pedal position sensor Brake pedal reaction force system Busbars Drive motor stators and rotors (including all internal components and position sensors) Generator rotor Generator rotor Generator rotor rot rote sensor High speed motor power inverter module fan control relay High voltage and bypass contactors, resistor and fuse High voltage power cables Motor and gear powered brake cylinder / actuator Motor control module (including all internal components) Motor control module / Battery pack coolant radiator Motor control module coolant expansion tank Motor control module coolant pump assembly Motor current sensor Motor current sensor Motor power inverter module all internal components) Motor control module coolant pump assembly Motor current sensor Motor control module coolant pump assembly Motor current sensor Motor control module coolant pump assembly Motor current sensor Motor control module coolant pump assembly Motor current sensor Motor control module coolant pump assembly Motor current sensor Motor control module coolant pump assembly Motor current sensor Motor control module coolant pump assembly Motor current sensor Motor control module coolant pump assembly Motor current sensor Motor control module coolant pump assembly Motor current sensor Motor control module coolant pump assembly Motor current sensor Motor control module coolant pump assembly Motor current sensor Motor control module coolant pump assembly Motor current sensor Motor control module coolant pump assembly Motor current sensor Motor control module coolant pump assembly Motor current sensor Motor control module coolant pump assembly Motor current sensor Motor control module coolant pump assembly Motor current sensor Motor control module coolant pump	Battery assembly (including all internal			
Battery condition monitor module (including software upgrades)       Software upgrades)         Battery pack coolant pump assembly       Battery current sensor         Battery unrent sensor       Software upgrades)         Battery current sensor       Software upgrades)         Battery current sensor       Software         Brake pedal position sensor       Software         Brake pedal reaction force system       Software         Busbars       Drive motor stators and rotors (including all internal components and position sensors)       Software         Generator position sensor       Generator rotor       Software         Generator rotor       Generator temperature sensor       Software         High speed motor power inverter module fan control relay       Software       Software         High voltage and bypass contactors, resistor and fuse       Software       Software         High voltage and bypass contactors, resistor and fuse       Software       Software         Motor commutation sensor       Motor control module (including all internal components)       Software       Software         Motor control module coolant expansion tank       Software       Software       Software       Software         Motor control module coolant pump assembly       Software       Software       Software       Software       Software	Battery charger (including battery charger cables)			
software upgrades)       Image: Control of the sensor         Battery pack coolant pump assembly       Image: Control of the sensor         Battery module service connector       Image: Control of the sensor         Brake pedal position sensor       Image: Control of the sensor         Brake pedal reaction force system       Image: Control of the sensor         Busbars       Image: Control of the sensor         Drive motor stators and rotors (including all internal components and position sensors)       Image: Control of Control of Control of Control of the sensor         Generator rotor       Image: Control of Control of Control of the sensor       Image: Control of Control control control of Control of Control control	Battery charger control module			
Battery current sensor       Battery module service connector         Battery module service connector       Brake pedal position sensor         Brake pedal reaction force system       Busbars         Busbars       Drive modor stators and rotors (including all internal components and position sensors)       Generator position sensor         Generator position sensor       Generator stator       Generator temperature sensor         High speed motor power inverter module fan control relay       High voltage and bypass contactors, resistor and fuse         High voltage power cables       Motor and gear powered brake cylinder / actuator         Motor control module (including all internal components)       Motor control module (secondant expansion tank         Motor control module coolant expansion tank       Motor control module coolant pump assembly         Motor current sensor       Motor current sensor         Motor drive module capacitor       Motor current sensor         Motor control module coolant pump assembly       Motor current sensor         Motor current sensor       Motor current sensor         Motor power inverter module (including all internal components)       Motor current sensor         Motor control module coolant pump assembly       Motor control module coolant pump assembly         Motor control module capacitor       Motor current sensor         Motor power inverter module (including all interna	software upgrades)			
Battery module service connector       Battery module service connector         Brake pedal position sensor       Brake pedal reaction force system         Busbars       Drive motor stators and rotors (including all internal components and position sensors)         Generator position sensor       Generator rotor         Generator stators and rotors (including all internal components and position sensors)       Generator rotor         Generator rotor       Generator temperature sensor         High speed motor power inverter module fan control relay       High voltage and bypass contactors, resistor and fuse         High voltage power cables       Motor and gear powered brake cylinder / actuator         Motor control module (including all internal components)       Motor control module (secolant expansion tank         Motor control module coolant pump assembly       Sessembly         Motor current sensor       Motor current sensor         Motor current sensor       Motor current sensor         Motor control module coolant pump assembly       Motor current sensor         Motor current sensor       Motor current sensor         Motor power inverter module (including all internal components)       Motor current sensor         Motor control module coolant pump assembly       Motor control module coolant pump assembly         Motor control module capacitor       Motor control module forecup and the sequence and the sensor and the	Battery pack coolant pump assembly			
Brake pedal position sensor       Brake pedal reaction force system         Brake pedal reaction force system       Brake pedal reaction force system         Busbars       Drive motor stators and position sensors)         Generator position sensor       Generator position sensor         Generator position sensor       Generator stator         Generator stator       Generator temperature sensor         High speed motor power inverter module fan control relay       High voltage and bypass contactors, resistor and fuse         Migh voltage power cables       Motor and gear powered brake cylinder / actuator         Motor commutation sensor       Motor control module (including all internal components)         Motor control module / Battery pack coolant radiator       radiator         Motor control module coolant expansion tank       Motor control module coolant pump assembly         Motor control module relay       Motor current sensor         Motor current sensor       Motor current module (including all internal components)         Motor control module coolant pump assembly       Motor current sensor         Motor control module colant pump assembly       Motor current sensor         Motor current sensor       Motor power inverter module (including all internal components)         Motor power inverter module (including all internal components)       Motor current sensor         Motor control module	Battery current sensor			
Brake pedal reaction force system         Busbars         Drive motor stators and rotors (including all internal components and position sensors)         Generator position sensor         Generator rotor         Generator stator         Generator temperature sensor         High speed motor power inverter module fan control relay         High voltage and bypass contactors, resistor and fuse         Motor and gear powered brake cylinder / actuator         Motor commutation sensor         Motor control module (including all internal components)         Motor control module / Battery pack coolant radiator         Motor control module coolant expansion tank         Motor control module colant pump assembly         Motor control module colant pump assembly         Motor control module colant pump assembly         Motor control module relay         Motor control module relay         Motor control module colant pump assembly         Motor control module colant pump assembly         Motor control module capacitor         Motor power inverter module (including all internal components)         Motor power inverter module (including all internal components)         Motor power inverter module (including all internal components)         Motor power inverter module / Battery module fan assembly         Motor power inverter module /	Battery module service connector			
Busbars	Brake pedal position sensor			
Drive motor stators and rotors (including all internal components and position sensors) Generator position sensor Generator rotor Generator stator Generator temperature sensor High speed motor power inverter module fan control relay High voltage and bypass contactors, resistor and fuse High voltage power cables Motor and gear powered brake cylinder / actuator Motor commutation sensor Motor control module (including all internal components) Motor control module coolant expansion tank Motor control module coolant expansion tank Motor control module coolant pump assembly Motor current sensor Motor current sensor Motor current sensor Motor drive module capacitor Motor power inverter module (including all internal components) Motor power inverter module / Battery module fan assembly	Brake pedal reaction force system			
internal components and position sensors) Generator position sensor Generator rotor Generator stator Generator temperature sensor High speed motor power inverter module fan control relay High voltage and bypass contactors, resistor and fuse High voltage power cables Motor and gear powered brake cylinder / actuator Motor commutation sensor Motor control module (including all internal components) Motor control module coolant expansion tank Motor control module coolant pump assembly Motor control module capacitor Motor current sensor Motor current sensor Motor drive module capacitor Motor power inverter module (including all internal components) Motor power inverter module (including all internal components) Motor power inverter module (including all inter	Busbars			
Generator rotor       Generator stator         Generator stator       Generator temperature sensor         High speed motor power inverter module fan control relay       Generator temperature sensor         High voltage and bypass contactors, resistor and fuse       Generator temperature sensor         High voltage power cables       Motor and gear powered brake cylinder / actuator         Motor commutation sensor       Motor control module (including all internal components)         Motor control module / Battery pack coolant radiator       Motor control module coolant expansion tank         Motor control module coolant pump assembly       Generator function generation         Motor control module capacitor       Motor current sensor         Motor current sensor       Motor current sensor         Motor power inverter module (including all internal components)       Motor current sensor         Motor control module relay       Motor control module relay         Motor control module relay       Motor current sensor         Motor power inverter module (including all internal components)       Motor power inverter module (including all internal components)         Motor current sensor       Motor current sensor       Motor current sensor         Motor power inverter module (including all internal components)       Motor current sensor       Motor current sensor         Motor power inverter module / Battery module fan				
Generator stator Generator stator Generator temperature sensor High speed motor power inverter module fan control relay High voltage and bypass contactors, resistor and fuse High voltage power cables Motor and gear powered brake cylinder / actuator Motor commutation sensor Motor control module (including all internal components) Motor control module coolant expansion tank Motor control module coolant pump assembly Motor current sensor Motor drive module capacitor Motor power inverter module (including all internal components) Motor control module relay Motor current sensor Motor drive module (including all internal components) Motor power inverter module / Battery module fan assembly Notage converter module / Battery module fan assembly Voltage converter module	Generator position sensor			
Generator temperature sensor       Image: Sensor Sensor         High speed motor power inverter module fan control relay       Image: Sensor Sen	Generator rotor			
High speed motor power inverter module fan control relay       Image: Control relay         High voltage and bypass contactors, resistor and fuse       Image: Control relay         High voltage power cables       Image: Control relay         Motor and gear powered brake cylinder / actuator       Image: Control relay         Motor commutation sensor       Image: Control relay         Motor control module (including all internal components)       Image: Control relay         Motor control module coolant expansion tank       Image: Control relay         Motor control module coolant pump assembly       Image: Control relay         Motor current sensor       Image: Control relay         Motor power inverter module (including all internal components)       Image: Control relay         Motor power inverter module / Battery module final assembly       Image: Control relay         Motor control module capacitor       Image: Control relay         Motor power inverter module / Battery module fina assembly       Image: Control relay <td>Generator stator</td> <td></td> <td></td> <td></td>	Generator stator			
control relay       Image and bypass contactors, resistor and fuse         High voltage and bypass contactors, resistor and fuse       Image and bypass contactors, resistor and fuse         High voltage power cables       Image and bypass contactors, resistor and gear powered brake cylinder / actuator         Motor and gear powered brake cylinder / actuator       Image and bypass control powered brake cylinder / actuator         Motor commutation sensor       Image and bypass control module (including all internal components)         Motor control module / Battery pack coolant radiator       Image and bypass control module coolant expansion tank         Motor control module coolant pump assembly       Image and bypass a	Generator temperature sensor			
and fuse       Image: Constraint of the second				
Motor and gear powered brake cylinder /       actuator         Motor commutation sensor       Motor control module (including all internal components)         Motor control module / Battery pack coolant radiator       radiator         Motor control module coolant expansion tank       radiator         Motor control module coolant pump assembly       radiator         Motor control module relay       Motor current sensor         Motor current sensor       Motor current sensor         Motor power inverter module (including all internal components)       motor power inverter module /         Motor power inverter module /       Battery module fan assembly         Motor power inverter module /       Battery module fan assembly         Motor power inverter module /       Battery module fan assembly         Motor power inverter module /       Battery module fan assembly         Motor power inverter module /       Motor power inverter module /         Battery module fan assembly       Motor power inverter module /         Battery module fan assembly       Motor power inverter module /         Battery module fan assembly       Motor power inverter module /         Battery module fan assembly       Motor power inverter module /         Motor for position sensor       Motor power inverter module /         Motor for position sensor       Motor for position sensor				
actuator       Image: Constraint of the second	High voltage power cables			
Motor control module (including all internal components)       Image: Components of the second				
components)       Image: Components of the second sec	Motor commutation sensor			
radiator Motor control module coolant expansion tank Motor control module coolant pump assembly Motor control module relay Motor current sensor Motor power inverter module (including all internal components) Motor power inverter module / Battery module fan assembly Traction motor rotor position sensor Voltage converter module	components)			
tank Motor control module coolant pump assembly Motor control module relay Motor current sensor Motor drive module capacitor Motor power inverter module (including all internal components) Motor power inverter module / Battery module fan assembly Traction motor rotor position sensor Voltage converter module	radiator			
assembly Motor control module relay Motor control module relay Motor current sensor Motor drive module capacitor Motor power inverter module (including all internal components) Motor power inverter module / Battery module fan assembly Traction motor rotor position sensor Voltage converter module Motor Sensor Motor Power inverter Motor Power inverter Motor Sensor Motor Power inverter Motor Power P	tank			
Motor current sensor       Image: Constraint of the sensor         Motor drive module capacitor       Image: Constraint of the sensor         Motor power inverter module (including all internal components)       Image: Constraint of the sensor         Motor power inverter module /       Battery module fan assembly         Battery module fan assembly       Image: Constraint of the sensor         Voltage converter module       Image: Constraint of the sensor				
Motor drive module capacitor       Image: Components of the component of the componen	Motor control module relay			
Motor power inverter module (including all internal components) Motor power inverter module / Battery module fan assembly Traction motor rotor position sensor Voltage converter module	Motor current sensor			
internal components) Motor power inverter module / Battery module fan assembly Traction motor rotor position sensor Voltage converter module				
Battery module fan assembly	internal components)			
Voltage converter module	Battery module fan assembly			
Water pump assembly	0			
	Water pump assembly			

INCLUDED WITH YOUR VEHICLE HONDA PLUS