



## FEATURES AND SPECIFICATIONS.

# REMOTE ENGINE START SYSTEM II

### MAINTAIN YOUR COOL.

Comfort and convenience can be yours with just the push of two buttons. On days when it's hotter than 7.5° C (45.5° F), it will automatically turn the air conditioner on in the AUTO mode. On vehicles equipped with automatic climate control, the remote engine starter will automatically set the car's interior temperature to 22° C regardless of the last A/C setting.

And to make braving the elements even easier, you can check the car's interior temperature on the remote's simple to read LCD display, when engine is running with remote engine starter.

When ambient temperature is lower than 7.5C (45.5F), the windshield defroster mode is automatically set and the rear defogger/heated door mirror is turned on.

### CHECK VEHICLE'S CONDITION.

START/STOP ENGINE

PANIC BUTTON

MEMORY SEAT FEATURE\*

INSIDE CABIN TEMPERATURE FEEDBACK

\* Only on vehicles equipped with the Memory Seat feature



LOCK/UNLOCK VEHICLE DOORS

TRUNK OPEN/POP FEATURE

Remote Communication	2-Way LCD
Remotes <sup>4</sup>	1 Remote
Range	Up to 120 meters
Security	•
Keyless Entry	•
Trunk Release <sup>3</sup>	•
Panic Button	•
System Check	•
Run-time	10 or 20 mins
Automatic Climate Control <sup>2</sup>	•
In-car Temperature Feedback <sup>2</sup>	•
Keyless Memory Setting <sup>1</sup>	•
Reception Feedback	•

- 1 Only on vehicles equipped with this feature.
- 2 Only on vehicles equipped with the automatic climate control.
- 3 Only on vehicles equipped with this feature.
- 4 One additional remote is available for purchase.



GENUINE ACCESSORIES



GENUINE ACCESSORIES

Call 1-888-9HONDA9 for the Dealer nearest you.  
Visit [www.honda.ca](http://www.honda.ca)

## THE KEY TO A GOOD START BEGINS HERE.

The system is pre-wired for your specific vehicle model with no splicing required and built to seamlessly integrate with your immobilizer and security system. NOTE: Honda Remote Engine Start System II should only be installed by an authorized Honda technician.



Contact your helpful Honda sales representative for more information.



\* If in an open area, a range up to 450 meters may be achieved.

## THE KEY TO GETTING STARTED DOESN'T REQUIRE A KEY.

Unlock the secret to a good start with the all-new Honda Remote Engine Start System II. Designed to warm your vehicle in the winter and cool it down in the summer, it allows you to start your car from up to 120 meters away without using a key. The remote also enables you to lock and unlock your vehicle and features a reception failure indicator to let you know if the signal to your car is being blocked.

The Remote Engine Start System II carries 3-year/60,000 Km warranty when installed in a new vehicle at the time of purchase by your Honda Dealer, which means you'll enjoy the benefits of a remote controlled car for years to come.

## FOR ADDED PEACE OF MIND.

The Honda Remote Engine Start System II has a number of built-in features to ensure your safety at all times:

- « Car doors remain locked while engine is warming up
- « To avoid accidental operation, there are two buttons that must be pressed consecutively to start and stop the engine
- « Integrated into the vehicle security system for vehicle protection
- « In order to reduce carbon-monoxide build-up, there is a maximum of two consecutive starts with the remote

## A REMOTE TO SATISFY THE STATUS SEEKERS.

	Transmitter Is Communicating
	Transmitter Cannot Communicate With Vehicle
	System Checking Status
	Engine Is Running
	Engine Is Stopping
	Idling Remaining Time
	Inside Car Temperature Range *
	Memory Seat Application **
	Door Lock Is On Unlock Position
	Door Or Trunk/Tailgate Is Open
	Hood Is Open
	Ignition Key Is Inside Vehicle For Smart Start Vehicles Or On
	Panic Alarm Has Been Triggered
	Continuous Start Inhibition Mode
	Shifter Is Not In Park Position

\* For vehicles equipped with Auto A/C.

\*\* Feature available only for vehicles equipped with Memory Seat feature.